aowoka Professional Hair Dryer

Aowoka Professional Hair Dryer User Manual

Model: Professional Hair Dryer

1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Keep this manual for future reference.

- **Water and Electricity:** Do not use this appliance near water (e.g., in a bathroom, near a sink, or in a shower). Never immerse the appliance in water or any other liquid.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- **Power Cord:** Always inspect the power cord for damage before use. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard. Do not wrap the cord around the appliance.
- **Overheating Protection:** The appliance is equipped with an automatic overheating protection system. If it overheats, it will shut down automatically. Unplug the appliance and allow it to cool down for a few minutes before restarting.
- **Ventilation:** Ensure the air inlet and outlet are not blocked during use. Blockage can lead to overheating.
- **Storage:** Always unplug the appliance after use and store it in a cool, dry place.

2. Product Overview

The Aowoka Professional Hair Dryer is designed for efficient and gentle hair drying and styling. It features advanced technology for fast drying, frizz reduction, and hair protection.



Figure 2.1: Front view of the Aowoka Professional Hair Dryer.

Key Features:

- **High-Speed Brushless Motor:** Reaches 160,000 RPM for rapid drying, reducing heat exposure.
- **Advanced Ionic Technology:** Emits up to 500 million negative ions to reduce frizz, enhance shine, and moisturize hair.
- **Intelligent Heat Control:** Monitors air temperature 110 times per second to maintain a constant, safe temperature and prevent heat damage.
- **Low Noise Operation:** Engineered with 8-layer noise reduction technology, operating below 56 dB.
- **Lightweight and Ergonomic:** Weighs approximately 400 grams for comfortable handling during extended use.
- **Magnetic Attachments:** Includes a magnetic concentrator nozzle and a magnetic diffuser for versatile styling.



Figure 2.2: Illustration of the hair dryer's fast drying capabilities, highlighting the 160,000 RPM motor and estimated drying times for various hair lengths.



Figure 2.3: Visual comparison of hair treated with and without negative ions, showcasing the benefits of the ionic technology for shine, smoothness, and frizz reduction.



Figure 2.4: Illustration emphasizing the hair dryer's low noise level and lightweight design, demonstrating its comfort and quiet operation.

---

3. Package Contents

Verify that all items are present in the package:

- Aowoka Professional Hair Dryer Unit
- Magnetic Concentrator Nozzle
- Magnetic Diffuser
- User Manual (this document)

---

4. Setup

Follow these steps for initial setup:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check the hair dryer and accessories for any signs of damage. Do not use if damaged.
3. **Attach Nozzle (Optional):** Select the desired magnetic attachment (concentrator nozzle or diffuser) and simply place it onto the front of the hair dryer. The magnetic connection will secure it in place.
4. **Plug In:** Insert the power plug into a suitable electrical outlet. Ensure your hands are dry.

---

5. Operating Instructions

Familiarize yourself with the controls and functions of your Aowoka Professional Hair Dryer.

Controls:

- **Power On/Off Button:** Located on the handle. Press once to turn on, press again to turn off.
- **Speed Settings Button:** Adjusts the airflow speed. The hair dryer offers 3 speed settings (Low, Medium, High).
- **Temperature Settings Button:** Adjusts the heat level. The hair dryer offers 4 temperature settings (Cool, Warm, Hot, and Constant Temperature Mode).
- **Cold Shot Button:** Press and hold to deliver a burst of cool air to set your style. Release to return to the previous heat setting.

Using the Attachments:

- **Concentrator Nozzle:** Ideal for precise styling and smoothing hair. Direct the airflow to specific sections of hair while brushing.
- **Diffuser:** Designed for curly or wavy hair. It disperses air evenly to enhance natural curls, reduce frizz, and add volume. Place sections of hair into the diffuser bowl and lift towards the scalp.

Intelligent Heat Control:

The hair dryer continuously monitors the air temperature to prevent extreme heat damage. This feature automatically adjusts the heat output to maintain an optimal and consistent temperature, protecting your hair and scalp.

---

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your hair dryer.

Cleaning the Air Filter:

The rear air inlet filter can accumulate dust and hair, which may affect performance. Clean it regularly:

1. **Unplug:** Always unplug the hair dryer from the power outlet before cleaning.
2. **Remove Filter:** Gently twist or pull the rear filter cover to remove it (refer to product diagram if available).
3. **Clean:** Use a soft brush or a dry cloth to remove any dust, lint, or hair from the filter mesh. Do not use water.
4. **Reattach:** Securely reattach the filter cover.

General Care:

- Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure the appliance is completely dry before storing or using again.
- Do not wrap the power cord tightly around the appliance, as this can damage the cord.

7. Troubleshooting

If you encounter any issues, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Hair dryer does not turn on.	No power supply. Power cord damaged.	Check if the plug is securely inserted into the outlet. Try a different outlet. If the cord is damaged, do not use and contact support.
Hair dryer stops during use.	Overheating protection activated. Air inlet/outlet blocked.	Unplug and allow to cool for 5-10 minutes. Check and clean the air filter. Ensure vents are clear.
Weak airflow.	Air filter is dirty or blocked.	Clean the air filter as described in the Maintenance section.
Hair is still frizzy.	Ionic function not fully effective. Incorrect drying technique.	Ensure the hair dryer is used correctly. For best results, dry hair from roots to ends. Consider using a lower heat setting.

8. Specifications

- **Brand:** Aowoka
- **Model:** Professional Hair Dryer
- **Motor Speed:** 160,000 RPM (Brushless Motor)
- **Negative Ions:** Up to 500 Million
- **Power:** 1600 Watts
- **Noise Level:** Below 56 dB
- **Weight:** Approximately 400 grams
- **Speed Settings:** 3 (Low, Medium, High)
- **Temperature Settings:** 4 (Cool, Warm, Hot, Constant Temperature Mode)
- **Heat Control:** Intelligent, monitors 110 times/second
- **Material:** Plastic
- **Power Source:** Corded Electric
- **Attachments:** Magnetic Concentrator Nozzle, Magnetic Diffuser

9. Warranty and Support

This Aowoka Professional Hair Dryer comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Aowoka customer service through the retailer where the product was purchased or visit the official Aowoka website for contact information.

© 2024 Aowoka. All rights reserved.