CANTENDO RL52

CANTENDO RL52 Remote Control User Manual

Model: RL52 | Brand: CANTENDO

Introduction

This manual provides comprehensive instructions for the CANTENDO RL52 remote control, designed as a direct replacement for the original NEC Lighting Remote Control RL52. It offers the same functionality and button layout as the genuine remote, ensuring seamless operation of your compatible NEC LED ceiling lights. Please refer to this guide for proper setup, operation, and troubleshooting.





Figure 1: Front view of the CANTENDO RL52 remote control with clearly labeled buttons.

Compatibility

The CANTENDO RL52 remote control is specifically designed to be compatible with the following NEC LED ceiling light models:

- 7LKZ640SG
- 7LKZ641LSG
- 9LKZ642SG
- 12LKZ643SG
- 15LKZ644SG

Important Note: This is not a universal remote control. It is intended solely as a replacement for the original RL52 remote and will only function with the listed compatible NEC ceiling light models.



Figure 2: The RL52 remote control shown alongside other compatible remote models, illustrating its design within the product family.

Setup

The CANTENDO RL52 remote control requires no complex setup or pairing. Simply insert the batteries, and it will be ready for use with your compatible NEC LED ceiling light.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals are aligned correctly as indicated inside the compartment.
4. Close the battery compartment cover securely.





Figure 3: Rear view of the remote control, illustrating the battery compartment.

Operating Instructions

The RL52 remote control provides intuitive access to all primary functions of your NEC LED ceiling light. Familiarize yourself with the button layout and their corresponding actions:



Figure 4: Angled view of the remote control, showing button details.

Sleep Timer (30 / 60): Press to set the light to turn off automatically after 30 or 60 minutes.

(All Lights): Activates all lights to full brightness.

(Dimming): Adjusts the brightness level of the light.

(Security Light): Turns on a low-level security or night light.

(Cycle): Cycles through different light modes or settings.

(Off): Turns off the light.

CH1 / CH2 Switch: Selects the operating channel if your light fixture supports multiple channels.

For detailed information on specific light functions and advanced settings, please consult the instruction manual provided with your NEC ceiling light fixture or visit the manufacturer's official website.



Figure 5: Demonstrating the remote control in use with a ceiling light.

Maintenance

To ensure the longevity and optimal performance of your CANTENDO RL52 remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners, solvents, or wet cloths, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).

- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical shocks and drops, which can damage its internal circuitry.



Figure 6: The remote control on a table, ready for use or storage.

Troubleshooting

If you encounter issues with your CANTENDO RL52 remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote is unresponsive or not working.	◦ Batteries are dead or inserted incorrectly. ◦ Remote is out of range or obstructed. ◦ Ceiling light is not compatible.	◦ Replace batteries with new ones, ensuring correct polarity (+/-). ◦ Move closer to the ceiling light and ensure no obstructions. ◦ Verify your ceiling light model is listed in the "Compatibility" section.
Buttons are not responding consistently.	◦ Low battery power. ◦ Infrared emitter is dirty or obstructed.	◦ Replace batteries. ◦ Clean the infrared emitter at the front of the remote with a soft cloth.
Remote's directional range seems limited.	◦ Characteristic of replacement remotes.	◦ Ensure direct line of sight to the ceiling light's receiver. ◦ Point the remote directly at the light fixture.

If the problem persists after trying these solutions, please contact customer support for further assistance.

Specifications

Feature	Detail
Model Number	RL52
Brand	CANTENDO
Compatible Devices	NEC LED Ceiling Lights (Models: 7LKZ640SG, 7LKZ641LSG, 9LKZ642SG, 12LKZ643SG, 15LKZ644SG)
Connectivity Technology	Infrared (IR)
Batteries Required	Yes (AAA batteries, not included)
Product Dimensions	15 x 5 x 1.5 cm (approximately 5.9 x 2.0 x 0.6 inches)
Item Weight	40 grams (approximately 1.4 ounces)
Special Feature	Replacement for original RL52 remote, full functionality

Warranty and Support

This CANTENDO RL52 remote control is designed for reliable performance. In the event of a malfunction, such as loss or unresponsiveness, it serves as an ideal replacement or spare unit for your compatible NEC LED ceiling light. For further assistance or inquiries, please refer to the seller's contact information on the product purchase page or through your order details.

© 2025 CANTENDO. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.