Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Suirviz U5PRO

Suirviz U5PRO Cordless Vacuum Cleaner Instruction Manual

Model: U5PRO

Contents Assembly Charging Operation Maintenance Troubleshooting Specifications Warranty & Support Safety Instructions Package

1. Important Safety Instructions

Read all instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material (e.g., chlorine bleach, ammonia cleaner, drain cleaner).
- Do not use in an enclosed space where vapors are present from oil base paints, paint thinner, mothproofing substances, flammable dust, or other explosive or toxic vapors.
- Do not pick up hard or sharp objects such as glass, nails, screws, coins, etc.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.

- Use only the charger supplied by the manufacturer to recharge.
- Do not incinerate the appliance even if it is severely damaged. The batteries can explode in a fire.
- This appliance is intended for household use only.

2. Package Contents

Carefully unpack your Suirviz U5PRO Cordless Vacuum Cleaner and check that all components are present and in good condition. If any items are missing or damaged, contact customer support.

- Main Motor Unit (Handheld Vacuum)
- Extension Wand
- Motorized Brush Head
- Crevice Tool
- Wall Mount Dock
- Power Adapter
- User Manual



Image 1: Illustration of all components included in the Suirviz U5PRO Cordless Vacuum Cleaner package. This includes the main unit, extension wand, brush head, crevice tool, wall mount, and power adapter.

3. Assembly Instructions

Follow these steps to assemble your Suirviz U5PRO Cordless Vacuum Cleaner.

3.1 Attaching the Extension Wand and Brush Head

1. Insert the top end of the extension wand into the main motor unit until it clicks securely into place.
2. Insert the motorized brush head onto the bottom end of the extension wand until it clicks securely into place.



Image 2: Diagram showing how to connect the extension wand to the main unit and the motorized brush head to the extension wand.

3.2 Attaching Accessories (Crevice Tool)

For handheld use or specific cleaning tasks, you can attach the crevice tool directly to the main motor unit or to the extension wand.

- To attach the crevice tool, align it with the air inlet on the main unit or the end of the extension wand and push until it fits snugly.
- To remove, press the release button (if present) and pull the accessory off.

4. Charging the Battery

The Suirviz U5PRO is powered by a Lithium-Ion battery. Ensure the battery is fully charged before first use.

1. Connect the power adapter to the charging port on the main motor unit.
2. Plug the power adapter into a standard wall outlet (240 Volts).
3. The charging indicator light will illuminate, typically red during charging and turning green or off when fully charged.
4. A full charge takes approximately 5 hours. Do not overcharge the battery.

5. For optimal battery life, avoid completely draining the battery before recharging.



Image 3: Diagram showing the charging port location on the main unit and how to connect the power adapter.

5. Operating Instructions

Learn how to effectively use your Suirviz U5PRO Cordless Vacuum Cleaner for various cleaning tasks.

5.1 Powering On/Off and Suction Modes

- To turn on the vacuum, press the power button located on the main unit. The vacuum will start in standard suction mode.
- To increase suction power, press the mode button (if available) to switch to MAX mode.
- To turn off the vacuum, press the power button again.

5.2 Cleaning Different Surfaces

- **Hard Floors:** Use the motorized brush head in standard mode for daily cleaning of hard floors (wood, tile, laminate).
- **Carpets and Rugs:** For carpets and rugs, switch to MAX mode for deeper cleaning. The motorized brush head is effective on these surfaces.
- **Above-Floor Cleaning:** Detach the extension wand and brush head to use the main unit as a handheld vacuum. Attach the crevice tool for tight spaces, corners, and upholstery.



Image 4: Visual guide demonstrating the vacuum being used on a hard floor and with the crevice tool for handheld cleaning.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

6.1 Emptying the Dust Cup

1. Ensure the vacuum is turned off and unplugged from charging.
2. Locate the dust cup release button on the main unit. Press it to detach the dust cup.
3. Hold the dust cup over a trash bin and press the bottom release latch to open the dust cup and empty its contents.
4. Close the dust cup bottom and reattach the dust cup to the main unit until it clicks.



Image 5: Step-by-step illustration of detaching and emptying the vacuum's dust cup.

6.2 Cleaning the Filters

The Suirviz U5PRO uses a HEPA filter. Clean filters regularly to maintain suction power.

1. With the dust cup detached, remove the filter assembly. This typically involves twisting or pulling the filter out.
2. Tap the HEPA filter gently over a trash bin to remove loose dust.
3. Rinse the HEPA filter and foam filter under cold running water until the water runs clear.
4. Allow filters to air dry completely for at least 24 hours before reinserting them. Do not use a hairdryer or other heating methods.
5. Reassemble the filters and dust cup once completely dry.

Image 6: Visual guide on how to remove, clean, and dry the HEPA filter and foam filter.

6.3 Cleaning the Brush Roll

1. Turn off the vacuum and detach the motorized brush head.
2. Locate the brush roll access latch or screws on the bottom of the brush head. Open or unscrew to remove the brush roll.
3. Use scissors or a brush to remove any tangled hair, string, or debris from the brush roll.
4. Reinsert the clean brush roll and secure the access latch/screws.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged.	Charge the battery for 5 hours.
Low suction power.	Dust cup is full. Filters are dirty. Brush roll is clogged. Air inlet/outlet is blocked.	Empty the dust cup. Clean and dry the filters. Remove debris from the brush roll. Check for and remove any blockages.
Brush roll not spinning.	Brush roll is clogged with hair/debris. Brush head is not properly attached.	Clean the brush roll. Ensure the brush head is securely attached.
Vacuum stops suddenly during use.	Battery is depleted. Overheating protection activated.	Recharge the battery. Turn off the vacuum and allow it to cool down for at least 30 minutes before resuming use. Check for blockages.

8. Product Specifications

Model	U5PRO
Brand	Suirviz
Type	Cordless Stick Vacuum
Filter Type	HEPA Filter
Power Source	Battery Powered (Lithium-Ion)
Voltage	240 Volts
Battery Charge Time	Approximately 5 Hours
Dust Cup Capacity	800 Milliliters

Item Weight	3.3 Pounds
Dimensions (L x W x H)	15.9"L x 11.5"W x 7.4"H
Recommended Surfaces	All floors (Carpet, Hard Floor)
Included Components	Crevice Tool

9. Warranty and Customer Support

Suirviz products are manufactured to high-quality standards. For information regarding your product's warranty, please refer to the warranty card included in your package or visit the official Suirviz website.
If you encounter any issues or have questions about your Suirviz U5PRO Cordless Vacuum Cleaner, please contact our customer support team:

- **Website:** www.suirviz.com/support (*Placeholder URL*)
- **Email:** support@suirviz.com (*Placeholder Email*)
- **Phone:** 1-800-XXX-XXXX (*Placeholder Number*)

Please have your model number (U5PRO) and purchase date ready when contacting support.

© 2026 Suirviz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F28QV5DT

More documents and user manuals: **https://manuals.plus/**