GameSir G7 Pro

GameSir G7 Pro Wireless Gaming Controller User Manual

Model: G7 Pro | Brand: GameSir

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your GameSir G7 Pro Wireless Gaming Controller. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.


Image: The GameSir G7 Pro Wireless Gaming Controller, featuring its unique Zenless Zone Zero Edition design.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- GameSir G7 Pro Wireless Gaming Controller (Zenless Zone Zero Edition)
- Extra Faceplate (Transparent White)
- Charging Station
- 3M Type-C Cable
- 2.4G Wireless Dongle

- Carrying Case
- Two Extra D-Pads (different shapes)
- Eight Interchangeable Thumbsticks
- Four Silicone Thumbstick Covers
- Acrylic Keychain (Zenless Zone Zero themed)
- GameSir Sticker
- ZZZ In-Game Item Pack Redemption Card
- Xbox Game Pass Ultimate Card (1 month)

Image: A visual representation of the GameSir G7 Pro Zenless Zone Zero Edition controller and its comprehensive accessories.

Video: Official unboxing of the GameSir G7 Pro Zenless Zone Zero Edition, showcasing all included items.

PRODUCT OVERVIEW

The GameSir G7 Pro is a high-performance wireless gaming controller designed for Xbox Series X|S, Xbox One, Windows PC, and Android devices. It features advanced technologies for precision and responsiveness.

Key Features:

- **TMR Joysticks:** Hall Effect technology for drift-free, precise control and extended lifespan.
- **Hall Effect Analog Triggers:** Provides smooth, consistent control with quick toggling to Micro Switch mode for rapid responses.
- **Optical Micro Switch ABXY Buttons:** Designed for tactile feedback and durability.
- **Mechanical Micro Switch D-pad:** Ensures crisp and responsive inputs.
- **1000Hz Polling Rate:** Available on PC via wired and 2.4G wireless connections for ultra-responsive gaming.
- **Tri-Mode Connectivity:** Wired (Xbox/PC), 2.4G Wireless (Xbox/PC), and Bluetooth (Android).
- **Four Remappable Buttons:** Two mini bumpers (R5/L5) and two lockable back buttons (R4/L4) for custom controls.
- **Smart Auto Start-Stop Charging Station:** Integrated 1200mAh battery with convenient charging.
- **Customizable Faceplate:** Three-part magnetic swappable faceplate and extra D-pads for personalization.
- **GameSir Nexus App:** Full customization options including gyro settings, stick curve adjustments, and button mapping.

Video: An overview of the GameSir G7 Pro Wireless Gaming Controller's features and compatibility.

SETUP

Initial Connection:

1. **For Xbox Consoles/PC (2.4G Wireless):** Insert the 2.4G wireless dongle into an available USB port on your Xbox console or PC. The controller will automatically connect.
2. **For Xbox Consoles/PC (Wired):** Connect the controller to your Xbox console or PC using the provided 3M Type-C cable.
3. **For Android (Bluetooth):** Ensure your Android device's Bluetooth is enabled. Put the controller into Bluetooth pairing mode (refer to the specific button combination in the quick start guide). Select the controller from your device's Bluetooth settings.

Charging the Controller:

The controller features a built-in 1200mAh battery. To charge:

- Place the controller onto the included charging station. The station is designed for auto start-stop charging.
- Alternatively, connect the 3M Type-C cable directly to the controller and a power source.

OPERATING INSTRUCTIONS

Trigger Adjustment:

The controller allows seamless switching between Hall Effect analog triggers and Micro Switch triggers. This feature is particularly useful for different game genres:

- **Hall Effect Analog:** Ideal for racing games or any scenario requiring precise, gradual input.
- **Micro Switch:** Provides lightning-fast, clicky responses, perfect for first-person shooter (FPS) games.

Refer to the quick start guide for the exact switch mechanism located on the controller's underside.

Image: Diagram illustrating the Hall Effect Analog and Micro Switch trigger stop mechanism.

Remappable Buttons:

The controller features four extra remappable buttons: two mini bumpers (R5/L5) and two lockable back buttons (R4/L4). These can be customized to perform various functions, enhancing your gameplay experience. Use the GameSir Nexus app for advanced remapping.

CUSTOMIZATION

The GameSir G7 Pro offers extensive customization options to tailor the controller to your preferences:

- **Swappable Faceplate:** The three-part magnetic faceplate can be easily removed and replaced with the included transparent white faceplate or other compatible G7 series faceplates.
- **Interchangeable D-Pads:** Two extra D-pads with different shapes are provided to suit various gaming styles.
- **Interchangeable Thumbsticks:** Eight additional thumbsticks of varying heights and textures are included, allowing you to find your preferred feel and control.

Image: The GameSir G7 Pro controller showcasing its swappable faceplate and various interchangeable components.

GAMESIR NEXUS APP

For full customization and advanced settings, download the GameSir Nexus app. The app allows you to:

- Adjust gyro settings.
- Fine-tune stick curve adjustments.
- Map buttons to mouse functions.
- Update controller firmware.

Image: Screenshot of the GameSir Nexus app interface, demonstrating customization options.

MAINTENANCE

Cleaning:

Regularly clean your controller with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the surface or internal components.

Battery Care:

The integrated 1200mAh battery is designed for long gaming sessions. To prolong battery life, avoid fully discharging the controller frequently. Store the controller in a cool, dry place when not in use.

TROUBLESHOOTING

Connection Issues:

- **Controller not connecting wirelessly:** Ensure the 2.4G dongle is properly inserted and the controller is in the correct wireless mode. For Bluetooth, verify pairing mode is active on the controller and enabled on your Android device.
- **Intermittent connection:** Check for interference from other wireless devices. Ensure the controller and dongle are within range. Update controller firmware via the GameSir Nexus app.

Stick Drift:

The GameSir G7 Pro features TMR Joysticks designed to be drift-free. If you experience any stick drift, recalibrate the joysticks using the GameSir Nexus app.

Buttons Unresponsive:

Ensure the controller is fully charged. If specific buttons are unresponsive, check for any physical obstructions. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	GameSir G7 Pro
Connectivity	2.4G Wireless, Wired (USB-C), Bluetooth
Compatibility	Xbox Series X|S, Xbox One, Windows PC, Android
Joysticks	TMR (Hall Effect)
Triggers	Hall Effect Analog / Micro Switch (switchable)
ABXY Buttons	Optical Micro Switch
D-pad	Mechanical Micro Switch (circular, interchangeable)
Polling Rate (PC)	1000Hz (wired & 2.4G)
Battery	1200mAh (rechargeable, included)
Remappable Buttons	4 (R5/L5 mini bumpers, R4/L4 back buttons)
Audio Port	3.5mm (supported on Xbox & PC via wired & 2.4G)

Dimensions	10.04 x 8.35 x 7.72 inches (Package)
Weight	4.24 pounds (Item)

WARRANTY AND SUPPORT

Warranty Information:

GameSir offers a 12-month replacement service for this product. If you encounter any issues with your controller, please refer to the warranty terms provided with your purchase or contact GameSir customer support directly.

Customer Support:

For technical assistance, troubleshooting, or warranty claims, please contact GameSir customer support through the official GameSir website or via the Amazon messaging system. Please provide your product model number and a detailed description of the issue for efficient service.