**XINFUTE RM-L1210+G Pro**

# XINFUTE RM-L1210+G Pro Universal TV Remote Control User Manual

Model: RM-L1210+G Pro | Brand: XINFUTE

## Introduction

This manual provides detailed instructions for the XINFUTE RM-L1210+G Pro Universal TV Remote Control. This remote is designed to operate a wide range of televisions, including models from Samsung, Sony, LG, and Sharp, among others. It serves as a direct replacement for many original remote control units and offers straightforward setup and operation.




*Image: Front view of the remote control, highlighting the layout and functions of various buttons.*



*Image: Side profile of the remote control, illustrating its ergonomic design.*

## Setup

### Battery Installation

The XINFUTE RM-L1210+G Pro remote control requires two (2) AA batteries (not included). Follow these steps to install the batteries:



*Image: Rear view of the remote control, displaying the closed battery compartment.*

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.




*Image: Back of the remote control with the battery compartment open, illustrating the correct orientation for battery insertion.*

## Operating Instructions

### General Functions

The RM-L1210+G Pro remote control is designed for intuitive use. Most buttons will function similarly to an original TV remote. Below are some key functions:

- **POWER**: Turns the TV on or off.
- **MUTE**: Mutes or unmutes the TV audio.
- **Number Buttons (0-9)**: Directly select TV channels.

- **VOL+** / **VOL-**: Adjusts the volume up or down.
- **CH+** / **CH-**: Changes the channel up or down.
- **MENU**: Accesses the TV's main menu.
- **INFO**: Displays channel or program information.
- **SOURCE**: Selects input sources (HDMI, AV, etc.).
- **Navigation Buttons (Up, Down, Left, Right) & OK**: Navigate menus and confirm selections.
- **RETURN** / **EXIT**: Returns to the previous screen or exits a menu.
- **Netflix, YouTube, Prime Video, Rakuten TV, Google Play**: Dedicated buttons for quick access to streaming services.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next)**: Control media playback.

## Programming and Code Setup

The RM-L1210+G Pro is a universal remote control designed to work with most TV models directly. In some cases, a simple setup might be required. The remote offers several methods for programming:

### Method 1: Setting with Brand (Direct Code Entry)

This method allows you to program the remote by selecting a specific brand code.

1. Identify your TV brand from the list below.
2. Press and hold the **SET** button.
3. While holding **SET**, press the corresponding number button for your TV brand (e.g., **SET + 1** for Samsung).
4. Release both buttons. The remote is now set for your brand.

**Brand Codes for Direct Setup**

| Brand | Code | Brand | Code |
|---|---|---|---|
| Samsung | SET + 1 | Sony | SET + 2 |
| LG | SET + 3 | Sharp | SET + 4 |
| Panasonic | SET + 5 | Toshiba | SET + 6 |
| Philips | SET + 7 | Haier | SET + 8 |
| Hisense | SET + 9 | Skyworth | SET + 0 |
| Konka | SET + F1 | Walton | SET + F2 |
| Other Brands | SET + F3 | | |

### Method 2: Setting with Code (Automatic Search)

If your TV brand is not listed or the direct code entry does not work, use this method:

1. Ensure your TV is turned on.
2. Press and hold the **SET** button, then press the **POWER** button. The indicator light on the remote will turn on.
3. Release both buttons.
4. Point the remote at your TV and press the **POWER** button repeatedly, about once every 1-2 seconds, until your TV turns off.
5. Once the TV turns off, immediately press the **SET** button to save the code. The indicator light will turn off.

6. Test the remote's functions. If some functions do not work, repeat the process as the remote may have found a partial match.

### Method 3: One Key Search

This method is a simplified automatic search.

1. Ensure your TV is turned on.
2. Press and hold the **SET** button until the volume symbol appears on your TV screen.
3. Immediately release the **SET** button.
4. Test the remote's functions. If not all keys are working, repeat the process.

### Method 4: One By One Search

This method allows for a more granular search if other methods fail.

1. Ensure your TV is turned on.
2. Press and hold the **SET** button, then press the **POWER** button. The indicator light will turn on.
3. Release both buttons.
4. Point the remote at your TV and press the **CH+** button repeatedly, about once every 1-2 seconds, until your TV turns off.
5. Once the TV turns off, immediately press the **SET** button to save the code. The indicator light will turn off.
6. Test the remote's functions. If some functions do not work, repeat the process.

### Method 5: Automatic Search (Alternative)

An alternative automatic search method.

1. Ensure your TV is turned on.
2. Press and hold the **SET** button, then press the **POWER** button. The indicator light will turn on.
3. Release both buttons.
4. Point the remote at your TV and press the **POWER** button. The volume symbol should appear on your TV screen.
5. Immediately press the **SET** button to save the code. The indicator light will turn off.
6. Test the remote's functions.




*Image: Packaging of the remote control, showing the programming instructions and brand code table printed on the back.*

## Maintenance

To ensure the longevity and proper functioning of your XINFUTE RM-L1210+G Pro remote control, follow these maintenance guidelines:

- **Cleaning**: Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the surface or internal components.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AA). Remove batteries if the remote will not be used for an extended period to prevent leakage.

- **Storage**: Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Handling**: Avoid dropping the remote control or subjecting it to strong impacts, as this can damage internal circuitry.

## Troubleshooting

If you encounter issues with your XINFUTE RM-L1210+G Pro remote control, try the following solutions:

- **Remote not responding**:
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm the remote is pointed directly at the TV.
- **Some buttons not working or incorrect functions**:
  - Re-attempt the programming steps (Method 1, 2, 3, 4, or 5) to ensure the correct code is set for your TV model.
  - If using an automatic search method, try repeating the process as the remote might have found a partial match initially.
- **TV not responding to any programming method**:
  - Verify that your TV is turned on before starting the programming process.
  - Ensure the remote's infrared emitter is not covered.
  - Some older or very new TV models might have limited compatibility.

## Specifications

| Feature | Detail |
|---|---|
| Model Number | RM-L1210+G Pro |
| Brand | XINFUTE |
| Product Dimensions | 6 x 3 x 1 inches |
| Item Weight | 2.82 ounces |
| Batteries Required | 2 AA batteries (not included) |
| Connectivity Technology | Infrared |
| Special Features | Ergonomic design, No programming required for most models |
| Compatible Devices | Television |
| Max Number of Supported Devices | 1 |

## Warranty and Support

**Warranty Information**: This product comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product will work as described.

**Customer Support**: All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact the seller within 24 hours of receipt. For further assistance, refer to the seller's contact information provided at the point of purchase or on the product packaging.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question