Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RC802N YUI2

XINFUTE RC802N YUI2 Remote Control User Manual

For TCL Thomson LCD TV Models 55C2US, 65C2US

Introduction

This user manual provides detailed instructions for the XINFUTE RC802N YUI2 remote control. This remote is a direct replacement designed for seamless compatibility with TCL Thomson LCD TV models 55C2US and 65C2US. No programming is required; simply insert batteries and begin use.

Package Contents

- 1 x XINFUTE RC802N YUI2 Remote Control
- *Note: Batteries are not included.*

Setup

Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment with slots for two AAA batteries.

After installing the batteries, the remote control is ready for use with compatible TCL Thomson LCD TVs without any additional setup or pairing.

Operating Instructions

The XINFUTE RC802N YUI2 remote control is designed for intuitive operation. Point the remote directly at your TCL Thomson LCD TV for optimal performance.



Figure 2: Front view of the RC802N YUI2 remote control.

Button Functions

Button	Function
Power (Red)	Turns the TV on or off.
Mute	Mutes or unmutes the TV sound.
Number Keys (0-9)	Direct channel selection.
PRE-CH	Switches to the previously viewed channel.
Volume Up/Down (+/-)	Adjusts the TV volume.
Channel Up/Down (Triangle Up/Down)	Changes TV channels.
Navigation Arrows (Up, Down, Left, Right)	Navigates through menus and options.

Button	Function
OK	Confirms selections in menus.
Home (House icon)	Accesses the TV's home screen or smart TV interface.
Settings (Gear icon)	Opens the TV's settings menu.
Back (Curved arrow)	Returns to the previous screen or menu.
EXIT	Exits the current menu or application.
GUIDE	Displays the electronic program guide (EPG).
TEXT	Activates or deactivates teletext.
SUBT.	Toggles subtitles on or off.
Netflix	Direct access to the Netflix application.
Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward)	Controls media playback.
ZOOM	Adjusts the screen zoom level.

Maintenance

Cleaning the Remote Control

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive cleaning materials, as these can damage the remote's surface or internal components.

Battery Care

- Replace batteries when the remote's response becomes sluggish or stops working.
- Always replace both batteries at the same time with new ones of the same type (AAA).
- Remove batteries if the remote control will not be used for an extended period to prevent leakage and potential damage.
- Dispose of used batteries according to local regulations.

Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote is unresponsive:**
  - Ensure the batteries are correctly installed with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Certain buttons do not work:**
  - This remote is designed for specific TCL Thomson TV models. Ensure your TV model (55C2US, 65C2US) is

compatible.

- Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris that might be interfering with button presses.

Specifications

Feature	Detail
Model Number	RC802N YUI2
Compatible TV Models	TCL Thomson LCD TV 55C2US, 65C2US
Power Source	2 x AAA Batteries (not included)
Material	ABS Material
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Color	As Shown (Typically Black)
Special Feature	Ergonomic Design

Warranty and Support

Warranty Information

This XINFUTE remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use.

Customer Support

For any questions, concerns, or issues regarding your remote control, please contact the seller directly within 24 hours of receiving your purchase. All goods are inspected before shipment to ensure quality.
For general inquiries about XINFUTE products, you may visit the XINFUTE Store on Amazon.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2H88NNW

More documents and user manuals: **https://manuals.plus/**