Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SAMSAIMO 1533P

SAMSAIMO Electric Stand Mixer Model 1533P User Manual

Model: 1533P

1. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the appliance.
- To protect against risk of electrical shock, do not immerse the mixer base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts. Keep hands, hair, and clothing, as well as spatulas and other utensils, away from beaters during operation to reduce the risk of injury to persons and/or damage to the mixer.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer service for examination, repair, or electrical or mechanical adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.
- Do not let cord contact hot surfaces, including the stove.
- Remove beaters from mixer before washing.

2. Product Overview

2.1 What's in the Box

Carefully unpack all components and check against the list below. Ensure all parts are present and in good condition.



Image: Contents of the SAMSAIMO Electric Stand Mixer box. It shows the main red stand mixer unit, a 5-quart stainless steel mixing bowl, a clear splash guard, a flat beater, a wire whisk, and a dough hook.

- SAMSAIMO Stand Mixer Unit
- 5.5QT Stainless Steel Mixing Bowl
- Splash Proof Cover
- Dough Hook
- Flat Beater
- Wire Whisk

2.2 Key Features



Image: Illustrates three key features of the mixer. Top: A close-up of the mixer's base showing a non-slip foot and the 'LOCK' indicator, highlighting its stable, anti-slip design. Middle: The mixer head tilted upwards, demonstrating the tilt-head design for easy accessory installation and bowl access. Bottom: A hand adding an egg yolk through the splash guard into the mixing bowl, showcasing the splash protection feature.

- **Powerful 660W Motor:** Provides efficient mixing for various recipes.
- **10-Speed Control with Pulse Function:** Offers precise control from gentle stirring to high-speed whipping.
- **Planetary Mixing Action:** Ensures thorough mixing by reaching all areas of the bowl.
- **Tilt-Head Design:** Allows for easy access to the bowl and attachments.
- **Anti-Slip Suction Feet:** Keeps the mixer stable on your countertop during operation.
- **Splash Guard:** Prevents ingredients from splashing out of the bowl during mixing.



Image: A cutaway view of the mixer's internal motor mechanism, emphasizing its 660W power. Icons indicate features such as low noise operation (Volume < 60dB), overheating protection, and high power output.

3. Getting Started

3.1 Before First Use

1. Unpack the mixer and all accessories.
2. Wash the mixing bowl, dough hook, flat beater, and wire whisk in warm, soapy water. Rinse thoroughly and dry. These parts are also dishwasher safe.
3. Wipe the main unit with a damp cloth. Do not immerse the motor base in water.
4. Ensure the mixer is placed on a stable, flat, and dry surface.

3.2 Assembly

1. **Place the Mixing Bowl:** Place the stainless steel mixing bowl onto the base of the mixer. Turn it clockwise until it locks securely into place.
2. **Attach an Accessory:** Ensure the mixer is unplugged. Push the tilt-head release button and lift the motor head. Insert the desired accessory (dough hook, flat beater, or wire whisk) into the attachment shaft. Rotate the accessory counter-clockwise until it clicks into place.
3. **Lower the Head:** Gently push the tilt-head release button again and lower the motor head until it locks into position.
4. **Attach Splash Guard (Optional):** Place the splash guard over the mixing bowl, aligning the opening with the attachment.

4. Operation

4.1 Attaching and Detaching Accessories

To attach, align the accessory with the shaft and push upwards, then rotate counter-clockwise until it locks. To detach, push upwards and rotate clockwise to release.

4.2 Using the Tilt-Head

To raise the motor head, press the tilt-head release button located on the side of the mixer and lift the head until it locks in the raised position. To lower, press the button again and gently push the head down until it locks into place.

4.3 Speed Control Guide

The mixer features 10 speed settings and a Pulse (P) function. Always start at a lower speed and gradually increase as needed.



Image: A visual guide demonstrating the recommended speed levels for each attachment. The Dough Hook is shown for kneading bread, pizza, and spaghetti, with recommended speeds from Level 1-6. The Beater is shown for mixing salad, cookies, mashed potatoes, and crepes, with recommended speeds from Level 1-7. The Whisk is shown for quickly whipping cream, egg whites, cake batter, and sauces, with recommended speeds from Level 8-10.

Attachment	Recommended Speed Range	Typical Use
Dough Hook	Level 1-6	Kneading bread dough, pizza dough, pasta dough.
Flat Beater	Level 1-7	Mixing batters, cookies, cakes, mashed potatoes, crepes.
Wire Whisk	Level 8-10	Whipping cream, egg whites, meringues, light batters, sauces.

4.4 Pulse Function (P)

The Pulse function provides short bursts of high-speed mixing. Turn the speed dial to 'P' and hold it for as long as you need the pulse action. Release to stop.

5. Care and Maintenance

5.1 Cleaning

- **Always unplug the mixer before cleaning.**
- **Mixing Bowl, Dough Hook, Flat Beater, Wire Whisk:** These accessories are made of stainless steel and are dishwasher safe. They can also be washed by hand in warm, soapy water, then rinsed and dried thoroughly.
- **Main Unit (Motor Base):** Wipe the exterior of the mixer with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the motor base in water or any other liquid.
- **Splash Guard:** Wash in warm, soapy water or place on the top rack of the dishwasher.

5.2 Storage

Ensure the mixer and all accessories are clean and dry before storing. Store the mixer in a dry place, away from direct sunlight and out of reach of children.

6. Troubleshooting

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power outlet not working; mixer head not fully locked down.	Check power cord connection; test outlet with another appliance; ensure mixer head is fully lowered and locked.
Attachments not mixing properly.	Attachment not fully secured; wrong attachment for task; too much/too little ingredient.	Ensure attachment is clicked into place; use correct attachment for recipe; adjust ingredient quantities.
Excessive noise or vibration.	Mixer not on a flat surface; bowl not locked; heavy load.	Place mixer on a stable, flat surface; ensure bowl is locked; reduce load if mixing very thick dough.
Motor stops during operation.	Overheating protection activated.	Turn off and unplug the mixer. Let it cool down for at least 20-30 minutes before restarting. Reduce load if consistently stopping.

7. Specifications



Image: A side view of the SAMSAIMO Stand Mixer with measurement lines indicating its compact dimensions: approximately 13.8 inches in depth, 7.6 inches in width (base), and 11.5 inches in height.

Feature	Detail
Model Number	1533P
Brand	SAMSAIMO
Power	660W (Motor), 450W (Rated)
Voltage	120V
Speeds	10 + Pulse
Bowl Capacity	5.5 Quarts (Stainless Steel)
Product Dimensions (D x W x H)	13.7"D x 8.3"W x 12.6"H

Feature	Detail
Material	Stainless Steel (Bowl, Attachments), Plastic (Housing)
Controls Type	Push Button / Rotary Dial

8. Warranty and Support

SAMSAIMO products are manufactured to high-quality standards. For warranty information or technical support, please refer to the documentation included with your purchase or visit the official SAMSAIMO store page on Amazon: SAMSAIMO Store.

© 2024 SAMSAIMO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2HHTVQB

More documents and user manuals: **https://manuals.plus/**