Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE XMRM-M6

XINFUTE XMRM-M6 Remote Control User Manual

For Mi TV Stick 4K and Compatible Mi TV Models

Introduction

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your XINFUTE XMRM-M6 remote control. This remote is designed for use with the Mi TV Stick 4K and is compatible with specific Mi TV models including L32M6-6ARG, L50M6-6ARG, L55M6-ARG, and L55M6-ESG.
The XMRM-M6 is an RF (Radio Frequency) remote control featuring voice control capabilities, offering an ergonomic design for comfortable use.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included). Ensure correct polarity when inserting the batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, matching the positive (+) and negative (-) terminals as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating the correct placement for two AAA batteries.

2. Pairing the Remote Control

Since this is an RF remote, it typically requires pairing with your Mi TV Stick 4K or compatible Mi TV. The exact pairing process may vary slightly depending on your device's software version. Refer to your Mi TV Stick 4K or Mi TV's on-screen instructions for the most accurate pairing steps. A common pairing method is as follows:

1. Ensure your Mi TV Stick 4K or Mi TV is powered on and displaying the home screen.
2. Bring the remote control close to your Mi TV Stick 4K or Mi TV (within 20 cm).
3. Press and hold the **Home** button (often represented by a house icon) and the **Back** button (arrow icon) simultaneously for a few seconds.

4. Release the buttons when you see a pairing confirmation message on your TV screen.
5. Follow any additional on-screen prompts to complete the pairing process.

Operating the Remote Control

The XMRM-M6 remote control features an intuitive layout for easy navigation and control of your Mi TV Stick 4K or compatible Mi TV.



Image: Front view of the XINFUTE XMRM-M6 remote control, displaying its ergonomic design and button layout.

Button Functions:

- **Power Button** ( ): Turns the TV Stick/TV on or off.
- **Voice Assistant Button** (Google Assistant icon): Activates the voice assistant for commands and searches.
- **Navigation Ring (Up, Down, Left, Right)**: Navigates through menus and content.
- **OK/Select Button** (Center of navigation ring): Confirms selections.
- **Back Button** (←): Returns to the previous screen or menu.
- **Home Button** (House icon): Returns to the main home screen.
- **Menu/Options Button** (Three horizontal lines icon): Opens context-sensitive menus or options.
- **Volume Up (+)** / **Volume Down (-)**: Adjusts the audio volume.
- **App Shortcut Buttons** (e.g., Netflix, Okko, Kinopoisk, Ivi): Direct access to specified applications.

Maintenance

Cleaning

To maintain the remote control's appearance and functionality, clean it regularly:

- Use a soft, dry cloth to wipe the surface of the remote control.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

Battery Replacement

Replace the batteries when the remote control's response becomes sluggish or stops functioning. Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

Storage

When not in use for extended periods, it is recommended to remove the batteries from the remote control to prevent leakage and potential damage.

Troubleshooting

Problem	Possible Cause	Solution
Remote control is not responding.	Dead or incorrectly installed batteries. Remote is not paired. Obstruction between remote and device.	Replace batteries with new AAA batteries, ensuring correct polarity. Re-pair the remote control (refer to 'Pairing the Remote Control' section). Ensure no objects are blocking the signal path.
Voice control is not working.	Microphone blocked. Software issue. Remote not properly paired for voice functions.	Ensure the microphone on the remote is not covered. Restart your Mi TV Stick 4K or Mi TV. Re-pair the remote control. Check device settings for voice input.
Buttons are sticky or unresponsive.	Dirt or debris under buttons.	Clean the remote control as described in the 'Maintenance' section. Avoid spilling liquids on the remote.

Problem	Possible Cause	Solution
Remote disconnects frequently.	Low battery power. Interference.	Replace batteries. Ensure there are no strong sources of RF interference nearby (e.g., Wi-Fi routers, other wireless devices). Try re-pairing the remote.

Specifications

- **Model:** XMRM-M6 (also compatible with XMRM-M3)
- **Type:** TV Remote Control (RF with Voice Function)
- **Material:** ABS Material
- **Color:** As Shown (typically black)
- **Power Source:** 2 x AAA Batteries (not included)
- **Product Dimensions:** Approximately 6 x 3 x 1 inches (15.24 x 7.62 x 2.54 cm)
- **Item Weight:** Approximately 2.82 ounces (80 grams)
- **Compatible Devices:** Mi TV Stick 4K, Mi TV models L32M6-6ARG, L50M6-6ARG, L55M6-ARG, L55M6-ESG
- **Special Feature:** Ergonomic design

Warranty Information

This XINFUTE remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.
The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact the retailer or manufacturer directly. It is recommended to contact support within 24 hours of receiving your purchase if you encounter any initial issues.
Please have your product model number (XMRM-M6) and proof of purchase available when contacting support.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2HJR9VV

More documents and user manuals: **https://manuals.plus/**