Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Slypadan SLY-15-MOTION-2PACK

Slypadan 15" Motion Sensor Outdoor Wall Sconce Instruction Manual

Model: SLY-15-MOTION-2PACK

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Slypadan 15" Motion Sensor Outdoor Wall Sconce. This product is designed for outdoor use, featuring a durable metal construction with a matte black finish and thick glass panels for weather resistance. It includes a motion sensor and offers multiple lighting modes to enhance your outdoor lighting experience.



Image: Slypadan 15" Motion Sensor Outdoor Wall Sconce, showcasing its design and size.

Safety Information

Please read all instructions carefully before installation and use. Retain this manual for future reference.

- Always turn off the power at the circuit breaker before beginning installation.
- Consult a qualified electrician if you are not familiar with electrical installations.
- Ensure all connections are secure and properly insulated.
- Do not exceed the maximum wattage specified for the bulb (100W Max, E26 socket).
- This fixture is designed for outdoor use only.

What's in the Box

Your package should contain the following items:

- Slypadan 15" Motion Sensor Outdoor Wall Sconce (2 units)
- Instruction Manual
- Mounting Hardware

Specifications

Brand	Slypadan
Model Number	SLY-15-MOTION-2PACK
Color	Black
Material	Metal, Glass
Dimensions (L x W x H)	6.38" x 5" x 14.75"
Bulb Base	E26 (Bulb not included)
Max Wattage	100W
Voltage	120 Volts (AC)
Special Features	Motion Sensor, Dusk to Dawn
Water Resistance Level	Waterproof
Mounting Type	Wall Mount



Image: Detailed product dimensions and specifications.

Setup and Installation

The outdoor wall sconces are designed for easy installation. Follow these general steps:

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Ensure the mounting surface is clean and stable.
2. **Mount the Bracket:** Attach the provided mounting bracket to your existing electrical box using the included hardware.
3. **Wire Connections:** Connect the fixture's wires to your household wiring according to local electrical codes. Typically, this involves connecting live to live, neutral to neutral, and ground to ground. Use wire nuts to secure connections.
4. **Attach the Fixture:** Carefully align the fixture with the mounting bracket and secure it in place using the provided screws.
5. **Install Bulb:** Insert an E26 base bulb (max 100W, not included) into the socket. The open-bottom design allows for easy bulb replacement.
6. **Restore Power:** Turn the power back on at the circuit breaker.



Image: Close-up of the updated motion sensor, standard E26 bulb base, and open-bottom design for easy access.

Operating Instructions

Your Slypadan outdoor wall sconce features two primary lighting modes:

1. ON/OFF Mode (Motion Sensor)

In this mode, the light operates based on motion detection and ambient light levels:

- During the daytime, the light will remain off.
- At night, the light will stay at 0% brightness (off) without movement.
- When motion is detected, the light will turn on to 100% brightness.
- After a period of no detected motion, the light will return to 0% brightness (off).



Image: Visual representation of the motion sensor's ON/OFF mode, showing light behavior during day and night with motion.

2. Manual Override Mode

This mode allows you to keep the light continuously on for an extended period:

- While the light is in either the 'Dual-bright' mode (if applicable to your bulb) or the standard 'ON/OFF' motion sensor mode, quickly turn the wall switch 'OFF' and then 'ON' again within 2 seconds.
- The light will then turn on and stay at 100% brightness for approximately 8 hours.
- It will remain on until the Dusk-to-Dawn sensor detects sufficient ambient light in the morning, at which point it will revert to its default motion sensor operation.

Maintenance

Regular maintenance ensures optimal performance and longevity of your outdoor wall sconce.

Cleaning

To clean the fixture:

1. Ensure power is off at the circuit breaker.
2. Wipe the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or glass.
3. The open-bottom design facilitates easy cleaning of the interior glass and bulb.

Bulb Replacement

To replace the bulb:

1. Ensure power is off at the circuit breaker and the bulb has cooled completely.
2. Unscrew the old E26 base bulb from the socket.
3. Screw in a new E26 base bulb (max 100W).
4. Restore power at the circuit breaker.



Image: Illustration of the fixture's weather-resistant features, including waterproof, snowproof, stormproof, and sunproof capabilities.

Troubleshooting

If you encounter issues with your outdoor wall sconce, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power, loose wiring, faulty bulb, sensor obstructed	Check circuit breaker. Verify wire connections. Replace bulb. Ensure sensor is clear.
Motion sensor not detecting	Sensor obstructed, incorrect mode, sensor range issues	Clear obstructions from sensor. Ensure light is in ON/OFF mode. Adjust sensor angle if possible.
Light stays on continuously	Manual override mode active, constant motion, faulty sensor	Toggle wall switch OFF/ON to exit manual override. Check for continuous motion in sensor range. Contact support if sensor is faulty.

Warranty and Support

This Slypadan product comes with a**3-Year Warranty**, guaranteeing its quality and performance under normal use. For any questions, technical assistance, or warranty claims, please contact Slypadan customer support through the retailer where the product was purchased.
Additionally, a 30-day refund/replacement policy is typically offered by the retailer for eligible returns.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Is there a picture manual available for the Slypadan SLY-15-MOTION-2PACK outdoor wall sconce?

Yes, the Slypadan SLY-15-MOTION-2PACK instruction manual includes several visual aids and illustrations to assist with installation and operation. While a standalone "picture-only" manual is not provided, the standard manual contains the following images: Product...

Read full answer

Open the live page

https://manuals.plus/asin/B0F2MSQXJZ

More documents and user manuals: **https://manuals.plus/**