Royalty Line RLPKM1600

Royalty Line RLPKM1600 Stand Mixer User Manual

Model: RLPKM1600

Introduction

The Royalty Line RLPKM1600 Stand Mixer is a powerful and efficient kitchen appliance designed to simplify your cooking and baking tasks. With its 1600W motor and six-speed settings, it offers precise control for mixing, kneading, and whipping. The 6-liter stainless steel mixing bowl provides ample capacity for large batches, making it ideal for preparing bread, cakes, and other homemade delicacies. This manual provides essential information for safe operation, assembly, usage, cleaning, and maintenance of your stand mixer.

Important Safety Instructions

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before assembly, disassembly, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands, hair, clothing, as well as spatulas and other utensils away from moving parts during operation to prevent injury and damage to the appliance.
- Never operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Use only attachments and accessories recommended by the manufacturer.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always ensure the head is locked down before operating.

Product Components

Familiarize yourself with the various parts of your Royalty Line RLPKM1600 Stand Mixer:



Image: Royalty Line RLPKM1600 Stand Mixer with its main components labeled. This includes the 6-liter stainless steel mixing bowl, the whisk attachment, the scraper, the flat beater, and the dough hook.

- **Motor Unit:** The main body containing the motor and control dial.
- **Tilt-Head Release Button:** For lifting the motor head.
- **Speed Control Dial:** To select desired speed settings (1-6) and Pulse function.
- **6-Liter Stainless Steel Mixing Bowl:** Large capacity bowl for ingredients.
- **Splash Guard:** Transparent cover to prevent splattering during mixing, with a pouring spout.
- **Dough Hook:** For kneading heavy mixtures like bread or pizza dough.
- **Flat Beater:** For medium-heavy mixtures like cake batter, cookies, or mashed potatoes.
- **Whisk:** For light mixtures like whipping cream, egg whites, or light batters.

- **Scraper:** A flexible tool for scraping down the sides of the bowl.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash the mixing bowl, splash guard, and all attachments (dough hook, flat beater, whisk, scraper) in warm, soapy water. Rinse thoroughly and dry completely. Wipe the motor unit with a damp cloth.
3. **Placement:** Place the stand mixer on a clean, dry, flat, and stable surface. Ensure there is enough space around the appliance for proper ventilation and operation.
4. **Lift Motor Head:** Press the tilt-head release button and lift the motor head until it locks into place.
5. **Attach Mixing Bowl:** Place the stainless steel mixing bowl onto the base, aligning the grooves, and turn it clockwise until it locks securely.
6. **Attach Accessory:** Select the appropriate attachment for your task (dough hook, flat beater, or whisk). Insert the attachment into the shaft and turn it counter-clockwise until it clicks into place.
7. **Lower Motor Head:** Press the tilt-head release button again and gently lower the motor head until it locks into its operating position. Ensure the attachment is correctly positioned inside the bowl.
8. **Attach Splash Guard:** If desired, place the splash guard over the mixing bowl, ensuring it fits snugly.

Operating Instructions

The Royalty Line RLPKM1600 features a planetary mixing action for thorough ingredient incorporation and a versatile speed control system.



Image: A close-up view of the Royalty Line RLPKM1600 Stand Mixer, highlighting the speed control dial and the tilt-head release button, indicating ease of use and control.

1. **Add Ingredients:** With the motor head lowered and the desired attachment in place, add your ingredients to the mixing bowl. The tilt-head design allows for easy access.
2. **Plug In:** Connect the power cord to a suitable electrical outlet (220-240V, 50/60Hz).
3. **Select Speed:** Turn the speed control dial to the desired setting (1-6).
    - **Speed 1-2 (Low):** Ideal for slow mixing, combining dry ingredients, or kneading heavy doughs with the dough hook.
    - **Speed 3-4 (Medium):** Suitable for mixing batters, creaming butter and sugar, or mashing potatoes with the flat beater.
    - **Speed 5-6 (High):** Best for whipping cream, egg whites, or light batters with the whisk attachment.
4. **Pulse Function:** For short bursts of high power, turn the dial to the 'P' (Pulse) setting and hold. Release to stop. This is useful for quickly incorporating ingredients or for precise mixing.
5. **Monitor Mixing:** Observe the mixing process. The transparent splash guard allows you to see the contents. Use the pouring spout to add liquids or other ingredients gradually during operation.
6. **Stop Operation:** When mixing is complete, turn the speed control dial to the '0' (Off) position. Unplug the appliance from the power outlet.
7. **Remove Bowl and Attachment:** Press the tilt-head release button to lift the motor head. Remove the attachment by turning it clockwise and pulling it down. Then, unlock the mixing bowl by turning it counter-clockwise and lifting it off the base.

Cleaning and Maintenance

Proper cleaning and maintenance will ensure the longevity and optimal performance of your stand mixer.

1. **Always Unplug:** Before cleaning, always ensure the appliance is unplugged from the power supply.
2. **Mixing Bowl and Attachments:** The stainless steel mixing bowl and attachments (dough hook, flat beater, whisk, splash guard) are generally dishwasher safe. However, for best results and to maintain their finish, hand washing with warm, soapy water is recommended. Rinse thoroughly and dry immediately.
3. **Motor Unit:** Wipe the exterior of the motor unit with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the motor unit in water or any other liquid.
4. **Stubborn Residue:** For stubborn food residue, soak the bowl and attachments in warm, soapy water for a few minutes before cleaning.
5. **Storage:** Ensure all parts are completely dry before storing. Store the stand mixer in a clean, dry place, preferably in its original packaging or covered to protect it from dust.

Troubleshooting

If you encounter any issues with your Royalty Line RLPKM1600 Stand Mixer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet faulty; motor head not locked down.	Ensure the power cord is securely plugged into a working outlet. Check if the motor head is fully lowered and locked.
Attachment does not reach ingredients at the bottom of the bowl.	Attachment not properly installed or bowl not seated correctly.	Ensure the attachment is fully inserted and twisted into place. Verify the mixing bowl is securely locked onto the base.
Unusual noise or vibration during operation.	Overloading; unstable surface; foreign object in bowl.	Reduce the amount of ingredients. Ensure the mixer is on a stable, flat surface. Check for any foreign objects. If the noise persists, discontinue use and contact support.
Motor stops during operation.	Overheating protection activated; power interruption.	Unplug the mixer and let it cool down for at least 30 minutes. Reduce the load if you were mixing heavy ingredients. Check your power supply.

If the problem persists after attempting these solutions, please contact Royalty Line customer support.

Specifications



Image: Technical drawing showing the dimensions of the Royalty Line RLPKM1600 Stand Mixer: approximately 34 cm (length) x 17 cm (width) x 33 cm (height).

- **Brand:** Royalty Line
- **Model Number:** RLPKM1600
- **Power:** 1600W
- **Voltage:** 220-240 V, 50/60 Hz
- **Motor Type:** High-performance motor with planetary mixing action
- **Speed Settings:** 6 speeds + Pulse function
- **Bowl Capacity:** 6 Liters
- **Bowl Material:** Stainless Steel
- **Housing Material:** Robust plastic with a modern finish
- **Included Accessories:** Dough hook, flat beater, whisk, scraper
- **Safety Features:** Secure locking system, overheating protection

- **Cable Length:** 1 meter
- **Dimensions (L x W x H):** Approximately 34 cm x 17 cm x 33 cm
- **Weight:** Approximately 5.3 kg
- **Certification:** CE certified

Warranty Information

Your Royalty Line RLPKM1600 Stand Mixer comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for any warranty claims.

Customer Support

For technical assistance, spare parts, or any questions regarding your Royalty Line RLPKM1600 Stand Mixer, please contact Royalty Line customer service. Contact details can typically be found on the product packaging, the official Royalty Line website, or your purchase documentation.
When contacting support, please have your model number (RLPKM1600) and proof of purchase ready.

© 2024 Royalty Line. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question