Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Auertech AU0001

Auertech Portable Washer and Dryer Combo Set (Model AU0001) Instruction Manual

Your Guide to Efficient Laundry Care

Introduction

Thank you for choosing the Auertech Portable Washer and Dryer Combo Set. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Designed for compact living spaces such as apartments, RVs, and dorms, this combo set offers a convenient and effective laundry solution.



Image: The Auertech Portable Washer and Dryer Combo Set, featuring a white top-load washer and a compact blue front-load dryer.

Safety Information

Please read all instructions carefully before using the appliance. Keep this manual for future reference. Improper use can lead to serious injury or damage.

- Ensure the appliance is placed on a stable, level surface.
- Connect to a grounded electrical outlet as specified in the manual.
- Do not operate the appliance with a damaged power cord or plug.
- Keep children and pets away from the appliance during operation.
- Do not overload the washer or dryer beyond their specified capacities.
- Always unplug the appliance before cleaning or performing maintenance.
- Do not wash or dry items that have been soiled with flammable substances.

What's in the Box

Your Auertech Portable Washer and Dryer Combo Set includes the following components:

- Portable Washer
- Portable Dryer
- Drain Hose
- User Manual



Image: An overview of the accessory kit, including the bottom cover, water inlet hose, faucet adapter, drain hose, and user manual.

Specifications

Feature	Specification
Brand	Auertech
Model Number	AU0001
Washer Capacity	28 Pounds
Dryer Capacity	1.5 Cu.Ft (up to 10 lbs per cycle)

Feature	Specification
Washer Dimensions (D x W x H)	23" x 23" x 36"
Dryer Dimensions (D x W x H)	19" x 15.8" x 22"
Washer Motor Wattage	400 watts
Dryer Rated Input	850W
Number of Washing Programs	10
Number of Water Levels	5
Number of Drying Cycles	5
Drum Material	Stainless Steel
Control Type	Digital Control Panel, Knob
Special Features	Baby Care Mode, Quick Wash, Safety Child Lock, Tub Clean

Setup

Follow these steps for initial setup of your washer and dryer combo set:

1. **Unpacking and Placement:** Carefully remove all packaging materials. Place the washer and dryer on a firm, level surface. Ensure there is adequate space around both units for ventilation and access.
2. **Install Bottom Cover:** Attach the bottom cover to the washer unit as instructed in the included user manual.
3. **Connect Water Inlet Hose:** Connect the water inlet hose to a suitable water source (e.g., kitchen sink faucet) using the provided quick-connect adapter. Ensure a secure connection to prevent leaks.
4. **Connect Drain Hose:** Insert the drain hose into a sink or a designated drainage area. The built-in drain pump will manage water removal.
5. **Adjustable Feet:** Use the adjustable feet on the washer to ensure the unit is perfectly level, which helps reduce vibration and noise during operation.
6. **Power Connection:** Plug both the washer and dryer into separate, grounded electrical outlets.



Image: The portable washer highlighting its built-in drain pump for convenient water drainage and efficient cleaning capabilities.

Operating Instructions - Washer

Operating your Auertech portable washer is straightforward:

1. **Load Laundry:** Open the top lid and place your clothes into the stainless steel inner tub. Do not exceed the 28 lbs capacity.
2. **Add Detergent/Softener:** Use the designated dispenser options for detergent and softener.
3. **Select Program:** Use the digital control panel to select one of the 10 washing programs (e.g., Standard, Bulky, Soft, Quick Wash, Spin Only, Wash Only, Soak, Rinse & Spin, Tub Air Dryer, Tub Clean).
4. **Choose Water Level:** Select the appropriate water level from the 5 available options based on your load size.
5. **Start Cycle:** Press the 'Start/Pause' button to begin the wash cycle.
6. **Child Lock:** To activate the Safety Child Lock, press and hold the 'Water Level' and 'Program Delay' buttons for 3 seconds. This prevents accidental changes during operation.



Image: The smart control panel of the Auertech washer, detailing the 10 washing programs and 5 water level options.



Image: Illustration of how to activate the Safety Child Lock and the 24-hour delay start function on the washer.

Operating Instructions - Dryer

For optimal drying results, follow these steps:

1. **Load Laundry:** Open the dryer door and place washed clothes inside. Do not exceed the 10 lbs capacity per cycle to ensure efficient drying and prevent damage.
2. **Select Drying Program:** Use the knob control to select one of the 5 drying cycles (e.g., Cooling refresh, Anti-wrinkle, Standard clothing, Bulk clothing).
3. **Start Cycle:** Turn the knob to the desired drying time/mode to begin. The 850W motor and 149°F heat will provide fast and fabric-friendly drying.



Image: The blue portable dryer, illustrating its compact dimensions (19x15.8x22 inches) and electrical specifications (120V, 60Hz, 850W rated input).



Image: The portable dryer's control panel with 5 auto-modes: Cooling refresh, Cool (0-20 mins), Anti-wrinkle (20-60 mins), Standard clothing (60-120 mins), and Bulk clothing (120-200 mins).

Maintenance

Regular maintenance ensures the longevity and optimal performance of your appliance:

- **Tub Clean:** Utilize the 'Tub Clean' program on the washer periodically to prevent residue buildup and maintain hygiene.
- **Dryer Filter:** Regularly clean the detachable outlet filter in the dryer to ensure proper airflow and drying efficiency. Refer to the user manual for specific instructions on how to remove and clean the filter.
- **Exterior Cleaning:** Wipe down the exterior of both units with a soft, damp cloth. Avoid abrasive cleaners.
- **Hose Inspection:** Periodically check the water inlet and drain hoses for any signs of wear, kinks, or leaks.



Image: A transparent view of the washer's internal components, highlighting the stainless steel inner tub, powerful 400W motor, and rotating pulsator for efficient cleaning.

Troubleshooting

If you encounter any issues with your Auertech Portable Washer and Dryer Combo Set, please refer to the following common troubleshooting tips. For more detailed solutions, consult the comprehensive user manual.

- **Unit Not Starting:** Ensure both units are properly plugged into a grounded electrical outlet and the power button is pressed. Check if the lid/door is securely closed.
- **Water Leakage:** Verify that all hose connections (inlet and drain) are tight and correctly installed. Do not overload the washer.
- **Excessive Vibration/Noise:** Confirm the unit is on a level surface and the adjustable feet are properly set. Ensure the load is balanced inside the drum.
- **Clothes Not Drying Properly:** Check that the dryer filter is clean and not obstructed. Ensure the dryer is not overloaded. Select the appropriate drying program for the fabric type and load size.
- **Error Codes:** If an error code appears on the display, refer to the specific error code section in your user manual

for diagnostic steps.

Warranty and Support

For warranty information, product support, or to purchase replacement parts, please refer to the contact details provided in your original purchase documentation or visit the official Auertech website. Keep your proof of purchase for warranty claims.

The Auertech customer support team is available to assist you with any questions or concerns regarding your portable washer and dryer combo set.

© 2025 Auertech. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What is the empty weight of the Auertech AU0001 portable washer?

Based on the available specifications for the Auertech Portable Washer and Dryer Combo Set (Model AU0001), the exact net weight (empty weight) of the units is not explicitly listed in the provided manual text....

Read full answer

Open the live page

https://manuals.plus/asin/B0F2N8TZ96

More documents and user manuals: **https://manuals.plus/**