Teamson Home FT0324RR

Teamson Home 38.5" Indoor/Outdoor Modern Curved Faux Slate Waterfall Fountain

Model: FT0324RR

Product Overview

The Teamson Home 38.5" Modern Curved Waterfall Fountain is designed to enhance both indoor and outdoor environments. This elegant water feature, constructed from durable polyresin and fiberglass, features a faux slate finish and integrated LED lights, creating a tranquil atmosphere with the gentle cascade of water. Its robust design ensures longevity and resistance to various weather conditions.





Image: The Teamson Home 38.5" Curved Faux Slate Waterfall Fountain, showcasing its modern design and integrated lighting.

Safety Instructions

Please read and understand all safety instructions before operating this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the fountain from the power outlet before performing any maintenance, cleaning, or assembly.
- Ensure the power cord and plug are not damaged. Do not operate the fountain if the cord is frayed or damaged.
- Use only with a Ground Fault Circuit Interrupter (GFCI) protected outlet, especially for outdoor use.
- Do not allow children or pets to play with the fountain.
- Keep the power adapter and electrical connections dry. Do not submerge the adapter in water.
- Place the fountain on a stable, level surface to prevent tipping.
- Do not operate the pump without water. This can damage the pump.

- Protect the fountain from freezing temperatures by draining and storing it indoors during winter months.

Package Contents

Before assembly, carefully inspect the packaging and ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Fountain Unit (Curved Faux Slate Structure with Integrated LED Lights)
- Water Pump with Adjustable Flow
- Power Adapter
- Decorative Pebbles (may be included or sold separately)



Image: Visual representation of the fountain's key features and components.

Setup and Assembly

Follow these steps to set up your new waterfall fountain:

1. **Choose Location:** Select a stable, level surface for your fountain, either indoors or outdoors. Ensure it is near a suitable power outlet. For outdoor use, a GFCI outlet is recommended.
2. **Unpack:** Carefully remove all components from the packaging.
3. **Connect Pump:** Locate the water pump and the tubing inside the fountain unit. Connect the pump's outlet nozzle to the end of the tubing. Ensure a secure fit.
4. **Place Pump:** Place the connected pump into the reservoir at the base of the fountain. Ensure the pump is fully submerged when the reservoir is filled with water.
5. **Fill with Water:** Fill the fountain's reservoir with distilled water to prevent mineral buildup. Ensure the water level is sufficient to fully submerge the pump, but do not overfill. The water capacity is approximately 1.98 gallons.
6. **Arrange Pebbles:** If included, carefully place the decorative pebbles around the base of the fountain, ensuring they do not obstruct the water flow or pump access.
7. **Connect Power:** Plug the power adapter into the fountain's power cord, then plug the adapter into a wall outlet.



Image: Detail of the fountain's base, showing the area where the pump is placed and water is collected, illuminated by LED lights.

Operation

Once assembled and filled with water, operating your fountain is straightforward:

- **Power On:** Plug the power adapter into a suitable electrical outlet. The pump will begin circulating water, and the LED lights will illuminate automatically.
- **Water Level:** Regularly check the water level in the reservoir. Due to evaporation, especially in dry or warm environments, water levels will decrease. Always ensure the pump remains fully submerged to prevent damage. Top up with distilled water as needed.
- **Flow Adjustment:** The water pump may have an adjustable flow rate. Refer to the pump's specific instructions for details on how to adjust the water flow to your preference.
- **LED Lights:** The integrated LED lights are designed to operate automatically when the fountain is powered on, providing a mesmerizing glow.



Image: A detailed view of the water cascading over the faux slate surface, highlighting the effect of the integrated LED lighting.

Maintenance

Regular maintenance will ensure the longevity and optimal performance of your fountain:

- **Water Replacement:** Change the water in the reservoir every 1-2 weeks, or more frequently if the water appears cloudy or dirty. Always use distilled water to minimize mineral buildup.
- **Cleaning the Fountain:** Periodically clean the fountain's surfaces to prevent algae and mineral deposits. Use a soft cloth

and a mild soap solution. For stubborn mineral deposits, a vinegar solution can be used. Rinse thoroughly.

- **Pump Cleaning:** Unplug the fountain and remove the pump. Disassemble the pump according to its instructions (usually involves removing the cover and impeller). Clean any debris, mineral buildup, or algae from the pump and impeller using a small brush. Rinse thoroughly and reassemble.
- **Algae Prevention:** To inhibit algae growth, you may add a small amount of algaecide specifically designed for fountains, or a few drops of bleach, to the water periodically.
- **Winterization (Outdoor Use):** If using the fountain outdoors in areas with freezing temperatures, it is crucial to drain all water from the fountain and pump. Clean the unit thoroughly and store it indoors in a dry, protected area to prevent damage from ice expansion.

Troubleshooting

Refer to this section for common issues and their solutions:

Problem	Possible Cause	Solution
No water flow or weak flow	Low water level Pump clogged with debris Kinked tubing Pump not receiving power	Add distilled water to cover pump Clean pump and impeller Straighten tubing Check power connection and outlet
LED lights not working	Power issue Damaged LED unit	Check power connection Contact customer support if lights are integrated and not replaceable
Excessive splashing	Water level too high Pump flow too strong Improper placement of decorative elements	Reduce water level slightly Adjust pump flow to a lower setting Rearrange pebbles or other decorative items
Noisy pump	Low water level Debris in pump Pump not seated correctly	Add distilled water Clean pump Ensure pump is firmly placed on the reservoir bottom
Algae or mineral buildup	Hard water Lack of regular cleaning	Use distilled water Clean fountain and pump regularly; consider algaecide or small amount of bleach

Product Specifications

- **Model Number:** FT0324RR
- **Dimensions (L x W x H):** 13.39" x 8.66" x 38.58" (34.01 cm x 22 cm x 97.99 cm)
- **Item Weight:** 12.57 Pounds (5.7 kg)
- **Water Capacity:** 1.98 gallons (7.5 liters)
- **Material:** Durable Polyresin and Fiberglass
- **Power Source:** Corded Electric
- **Special Features:** Integrated LED Lights, Rust Resistant



Image: Diagram illustrating the precise dimensions of the fountain.

Warranty and Support

For warranty information, product registration, or technical support, please refer to the manufacturer's official website or contact Teamson Home customer service. Keep your purchase receipt as proof of purchase for any warranty claims.
Visit the Teamson Home Store for more products and information.