WINNY POOL CLEANER WPC-200SE

WINNY POOL CLEANER Cordless Robotic Pool Cleaner Instruction Manual

Model: WPC-200SE
Brand: WINNY POOL CLEANER

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your WINNY POOL CLEANER Cordless Robotic Pool Cleaner. Please read this manual thoroughly before initial use and retain it for future reference.
The WINNY POOL CLEANER Cordless Robotic Pool Cleaner is designed for automatic vacuuming of above-ground pools up to 645 sq.ft. It features a cordless design, self-parking capability, and a dual filtration system for effective debris collection.

Safety Information

Always follow basic safety precautions when using electrical appliances, especially near water. This device is designed for underwater use only. Do not operate the cleaner out of water. Keep hands, hair, and loose clothing away from moving parts. Ensure the charging port is dry before charging. Do not allow children to operate the cleaner without adult supervision.

Product Overview

The WINNY POOL CLEANER Robotic Pool Cleaner is a compact and efficient device for maintaining your pool's cleanliness. Key features include:

- **Outstanding Cleaning Performance:** Powerful suction and a dual-blade system for thorough debris and leaf capture.
- **Exceptional Dual Filtration System:** Features a unique dual-layer filtration system (180µm + cotton foam) for enhanced debris capture, including sand and leaves.
- **Cordless Convenience & Self-Parking:** Tangle-free cordless design with automatic self-parking when the battery is low.
- **Smart Navigation System:** Automatically reverses upon encountering obstacles and returns to the shore when the battery is low.
- **Versatile Compatibility:** Ideal for above-ground pools with flat bottoms (maximum slope < 15°) and compatible with various pool liners (PVC, tiles, vinyl, or gunite) and shapes (round, rectangular, or oval). Recommended for pools up to 645 square feet.



Figure 1: WINNY POOL CLEANER Cordless Robotic Pool Cleaner. This image shows the transparent black robotic pool cleaner from a slightly elevated front-right angle, highlighting its handle and compact, circular design with visible internal components.

Setup

1. **Handle Installation:** Attach the handle to the main unit using the provided screws. Ensure it is securely fastened.
2. **Prepare for Submersion:** Before placing the cleaner in the pool, ensure all flaps and covers are properly closed and secured.
3. **Submersion and Air Release:** Gently place the cleaner into the pool water. Allow it to submerge fully, ensuring all trapped air bubbles escape from the unit. This process helps the cleaner achieve proper buoyancy and operation.

Operating Instructions

1. **Power On:** Once fully submerged and air-free, locate the power button (typically on the top or side of the unit) and press it to activate the cleaner.
2. **Initiate Cleaning Cycle:** The cleaner will begin its automatic cleaning cycle, navigating the pool floor. It is designed to clean your entire pool in approximately 75 minutes per cycle.
3. **Obstacle Avoidance:** The smart navigation system allows the robot to automatically reverse when encountering obstacles,

preventing damage and ensuring continuous operation.

4. **Self-Parking Feature:** When the battery level is low, the cleaner will autonomously return to the shore for easy retrieval and recharging.

Maintenance

Regular maintenance ensures optimal performance and longevity of your pool cleaner.

1. **Retrieval:** After the cleaning cycle is complete or the unit self-parks, use the provided hook (attachable to any standard pool pole) to carefully retrieve the cleaner from the pool.
2. **Accessing the Filter:** Once out of the water, unclip the designated spots on the unit to lift off the top cover, revealing the dual-layer filtration mesh.
3. **Cleaning the Filter:** Remove the filtration mesh. Thoroughly rinse the mesh and the internal compartment of the cleaner with clean water to remove all collected debris, leaves, sand, and other particles. **Note:** If the pool is heavily soiled, clean the filter every 30 minutes to prevent clogging and potential damage to the unit.
4. **Reassembly:** Ensure all components are clean and dry before reassembling the filter and securing the top cover.
5. **Charging:** After cleaning, charge the unit for approximately 4 hours to prepare it for the next cleaning cycle.

Troubleshooting

If you encounter any issues with your WINNY POOL CLEANER, please refer to the comprehensive troubleshooting guide in the full product manual or contact customer support for assistance.

Specifications

Feature	Detail
Model Name	25WPC-200SE
Power Source	Battery Powered
Special Features	Cordless, Dual Filtration System, Lightweight, Self Propelled, Waterproof
Assembly Required	No
Battery Type	1 Lithium Ion batteries required. (included)
Charging Time	4 Hours
Item Weight	9.2 pounds
Product Dimensions	10"L x 7"W x 12"H
Material	Plastic
Color	Transparent Black
Manufacturer	WINNY POOL CLEANER

Warranty & Support

For warranty information, technical support, or any inquiries regarding your WINNY POOL CLEANER Robotic Pool Cleaner, please refer to the contact details provided in the product packaging or visit the official WINNY POOL CLEANER website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question