Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Furmubei SG2402

Furmubei Portable Baby Swing SG2402 Instruction Manual

Model: SG2402 | Brand: Furmubei

1. Introduction

This manual provides essential information for the safe and effective use of your Furmubei Portable Baby Swing SG2402. Please read all instructions carefully before assembly and use. Keep this manual for future reference.

Key Features:

- Foldable & Portable Design: Compact for storage or travel.
- 5-Speed Adjustable Swing & Timer Function: Offers 5 swing speeds and 3 timer settings (10/15/30 mins).
- Soothing Sounds & Engaging Toys: Includes 6 melodies with 3 volume levels and a removable toy bar.
- Comfort & Safety: Features a cozy deep seat, soft cushion, adjustable 5-point harness, and non-slip feet.
- Certified Safety: US CPSIA & ASTM Certified, crafted from non-toxic, odor-free materials.

2. Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Never leave child unattended.
- Always use the restraint system.
- Do not use this product once your child can sit up unaided or attempts to climb out.
- This product is not intended for prolonged periods of sleep.
- Maximum weight recommendation: 20 lbs (9 kg).
- Recommended age: 0-9 months.
- Ensure the swing is placed on a flat, level surface.
- Keep away from open flames, heaters, and other heat sources.
- Regularly check all parts for wear and tear. Discontinue use if any part is damaged.
- Only use accessories and replacement parts approved by the manufacturer.



Image: Detailed view of the baby swing highlighting its safety features including the fixed pillowcase to prevent suffocation, the three-point safety harness, non-slip foot pads, and adjustable straps. The fabric is noted as skin-friendly and breathable. CPSC and CPSIA certification logos are also shown.

3. Setup

Assembly is required. Please follow the steps below carefully. A screwdriver is needed for assembly.

1. Unpack all components and verify against the parts list in the user manual.
2. Assemble the main frame by connecting the metal tubes. Ensure the spring buttons click into place securely.
3. Attach the swing motor units to the top of the frame. Secure with screws provided.
4. Connect the curved support bars for the seat to the motor units. Fasten with screws.
5. Install the fabric seat onto the frame, ensuring all straps and buckles are correctly positioned and secured.
6. Attach the toy bar by clipping it into the designated slots on the frame.
7. Insert 4 x 1.5V AA batteries (not included) into the battery compartment located on the control panel.

Your browser does not support the video tag.

Video: Official Furmubei guide on how to install the baby swing, demonstrating the assembly process step-by-step.



Image: Visual guide illustrating correct and incorrect arm installation for the baby swing. Incorrect installation may lead to music playing without the swing function, requiring reinstallation.

4. Operating Instructions

Familiarize yourself with the control panel for optimal use.

Control Panel Functions:

- **Power Button:** Press to turn the swing on or off.
- **Swing Speed Adjustment:** Use the speed buttons to select one of 5 swing speeds. Indicators will light up to show the current speed.
- **Music Selection:** Press the music button to cycle through 6 built-in melodies.
- **Volume Control:** Adjust the music volume to one of 3 levels.

- **Timer Settings:** Select a timer duration of 10, 15, or 30 minutes. The swing will automatically stop after the set time.



Image: The control panel of the baby swing, detailing buttons for adjusting swing speed, selecting music, and setting the timer. It also indicates the requirement for 4 x 1.5V batteries.

Your browser does not support the video tag.

Video: Official Furmubei video demonstrating the features and operation of the portable baby swing, including swing speeds, music, and timer functions.

5. Maintenance

- The fabric seat and cushion are detachable and machine washable. Refer to the care label for specific washing instructions.
- Wipe down the plastic and metal parts of the frame with a damp cloth and mild soap. Do not use abrasive cleaners.
- Ensure the swing is completely dry before reassembling or storing.
- Store the swing in a cool, dry place away from direct sunlight when not in use.



Image: The detachable and washable fabric seat of the baby swing being placed into a washing machine for cleaning.

6. Specifications

Feature	Detail
Brand	Furmubei
Model	SG2402
Dimensions (D x W x H)	31.5"D x 22.05"W x 31.5"H (Open)
Folded Dimensions	18" x 5" x 14"
Maximum Weight Recommendation	20 Pounds (9 kg)
Recommended Age	0-9 Months

Feature	Detail
Power Source	4 x 1.5V AA Batteries (not included)
Material Type	Polyester
Safety Certifications	US CPSIA & ASTM Certified



Image: A diagram illustrating the product dimensions (height, width, depth) of the baby swing, along with its weight capacity (19.84 lbs) and recommended age range (0-9 months).

7. Troubleshooting

- **Swing not operating:** Check if batteries are correctly installed and not depleted. Ensure all frame connections are secure and screws are tightened. Refer to the setup section for correct arm installation.
- **Music not playing:** Verify batteries are functional. Check volume settings.
- **Unstable:** Ensure the swing is on a flat, level surface and all frame components are fully engaged and locked.

- **Excessive noise:** Check for any loose parts or obstructions. Ensure the fabric seat is correctly attached and not rubbing against the frame.

8. Warranty and Support

For warranty information or customer support, please contact Furmubei directly through their official channels or the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

© 2026 Furmubei. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2YQGJ8J

More documents and user manuals: **https://manuals.plus/**