Salutrobusto B0F32PQFQD

Salutrobusto Massage Office Chair with Heat and 8 Vibration Points Instruction Manual

Model: B0F32PQFQD

1. Important Safety Information

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- This chair is designed for indoor use only.
- Do not stand on the chair.
- Keep children away from the chair during assembly and use.
- Maximum weight capacity: 400 pounds. Do not exceed this limit.
- For massage and heating functions, ensure the power cord is not damaged and is connected to a suitable power source. Disconnect power when not in use or during cleaning.

2. Package Contents

Verify that all parts are included in the package before beginning assembly.

- Backrest
- Seat Cushion with Armrests
- Headrest
- Footrest
- Gas Lift Cylinder
- Star Base
- Casters (5x)
- Mechanism Plate

- Massage Remote Control
- Power Adapter
- Assembly Hardware (screws, washers, Allen wrench)

3. Assembly Instructions

Follow these steps to assemble your Salutrobusto Office Chair. It is recommended to have two people for assembly.

Step 1: Attach Casters to Base

Insert the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.

Step 2: Install Gas Lift Cylinder

Place the gas lift cylinder into the center hole of the star base.

Step 3: Attach Mechanism Plate to Seat Cushion

Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism plate faces the front of the seat. Secure with screws using the provided Allen wrench.

Step 4: Connect Seat to Gas Lift

Carefully place the assembled seat cushion onto the gas lift cylinder, ensuring it is centered and stable.

Step 5: Attach Backrest to Seat Cushion

Align the backrest with the mounting brackets on the seat cushion. Secure with screws. Ensure a firm connection.

Step 6: Install Headrest

Slide the adjustable headrest into the designated slots at the top of the backrest. Adjust to your preferred height.



Image: Illustration showing the adjustable headrest being slid into the backrest, with arrows indicating vertical adjustment.

Step 7: Attach Footrest

Attach the retractable footrest mechanism to the underside of the seat, following the specific instructions in the included diagram. Ensure it slides smoothly.



Image: A person demonstrating the chair's recline function and the extended footrest. The image also shows the chair in working, reading, and napping positions.

4. Operating Instructions



Image: An overview of the Salutrobusto Massage Office Chair, highlighting its massage and heating zones, adjustable headrest, and retractable footrest.

4.1 Chair Adjustments

- **Height Adjustment:** Use the lever located under the seat on the right side to raise or lower the chair. Lift the lever while seated to lower, or lift the lever while standing to raise.
- **Recline Function:** Pull the recline lever (typically on the left side under the seat) to adjust the backrest angle from 90° to 135°. Release the lever to lock the desired position.
- **Adjustable Headrest:** The headrest can be moved up or down by hand to provide optimal neck support.
- **Retractable Footrest:** Pull the footrest out from under the seat when needed, and push it back in for storage.
- **360° Swivel:** The chair base allows for full 360-degree rotation.
- **Linkage Armrests:** The armrests are designed to move with the recline of the backrest, maintaining support for your arms.



Image: Diagram illustrating the movement of the linkage armrests in both resting and working positions, highlighting their ergonomic design.

4.2 Massage and Heating Functions

Connect the power adapter to the chair's power input and then to a wall outlet. Use the remote control to operate the massage and heating features.



Image: Visual representation of the chair's massage and heating zones, along with icons indicating 8 massage points, 5 modes, 4 areas, 3 timer settings, 2 strength levels, and independent heat function.

- **Power On/Off:** Press the power button on the remote to activate or deactivate the massage and heating functions.
- **Massage Points:** The chair features 8 vibration points targeting the back, waist, and legs.
- **Massage Modes:** Select from 5 different massage modes to customize your experience.
- **Intensity Levels:** Adjust the massage strength between High and Low settings.
- **Target Areas:** Choose to focus massage on specific areas: back, lumbar, seat, or legs.
- **Timer Function:** Set the massage duration for 15, 30, or 60 minutes. The unit will automatically shut off after the selected time.
- **Heating Function:** Activate the independent heating function for soothing warmth in the lumbar area. This can be used with or without the massage function.

5. Maintenance and Care

- **Cleaning:** Wipe the chair with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately.

Avoid harsh chemicals or abrasive cleaners.

- **Fabric Care:** The chair is upholstered with wear-resistant leather. Avoid direct sunlight exposure to prevent fading and cracking.
- **Moving the Chair:** When moving the chair, lift it rather than dragging it to prevent damage to the base and casters.
- **Regular Checks:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Power Cord:** Inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

6. Troubleshooting

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift cylinder is faulty or lever is not engaged.	Ensure the lever is fully pulled. If issue persists, contact customer support for gas lift replacement.
Massage/Heating function not working.	Power adapter not connected, remote battery low, or internal wiring issue.	Check power adapter connection to chair and wall outlet. Ensure remote control has working batteries. If still not working, contact customer support.
Chair is wobbly or unstable.	Loose screws or improper assembly.	Check and tighten all assembly screws. Ensure the gas lift is properly seated in the base.
Footrest does not extend/retract smoothly.	Obstruction or mechanism issue.	Check for any obstructions. Ensure the footrest was installed correctly. Apply a silicone-based lubricant if needed.

7. Product Specifications

- **Brand:** Salutrobusto
- **Model:** B0F32PQFQD
- **Color:** Black
- **Product Dimensions:** 27"D x 27"W x 40"H
- **Back Style:** Solid Back
- **Arm Style:** Pillow-Top
- **Reclining Position Count:** 3 (90°-135°)
- **Massage Points:** 8 Vibration Points
- **Massage Modes:** 5
- **Heat Function:** Independent Lumbar Heat
- **Weight Capacity:** Up to 400 pounds
- **Item Weight:** 60 pounds
- **UPC:** 768825900218



Image: Detailed diagram showing the various dimensions of the Salutrobusto Massage Office Chair, including seat width, backrest height, and overall chair dimensions.

8. Warranty and Support

Salutrobusto is committed to providing high-quality products and excellent customer service.

- **Parts Replacement Policy:** We offer a 12-month parts replacement policy from the date of purchase.
- **Customer Support:** Our customer service team is available 24/7 to address any questions or concerns you may have regarding your product. Please contact us directly for assistance.
- **Protection Plans:** Extended protection plans may be available for purchase separately. Refer to your retailer for details.

© 2025 Salutrobusto. All rights reserved.