Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RXUJYC 7.0 Cuft Large Fireproof Home Safe

RXUJYC 7.0 Cuft Large Fireproof Home Safe Instruction Manual

Brand: RXUJYC

Model: 7.0 Cuft Large Fireproof Home Safe

Introduction

Thank you for choosing the RXUJYC 7.0 Cuft Large Fireproof Home Safe. This safe is designed to protect your valuables, including documents, jewelry, cash, and ammunition, from theft and damage. It features a robust steel construction, a dual alarm system, an internal LED light, and multiple unlocking methods for enhanced security and convenience. Please read this manual carefully before operating your safe to ensure proper setup and usage.





Image: The RXUJYC 7.0 Cuft Large Fireproof Home Safe with its door open, revealing multiple shelves and ample storage space for various items.

Setup

1. Unpacking and Initial Inspection

- Carefully remove the safe from its packaging.
- Inspect the safe for any signs of damage that may have occurred during transit. If damage is found, contact customer support immediately.
- Ensure all included components are present: Safe box x 1, Anti-Scratch Pad x 1, Expansion Bolt x 4, Manual x 1, Spare Key x 2.

2. Battery Installation

The safe requires batteries for the electronic keypad and LED light. The external battery case allows for easy replacement.

- Locate the battery compartment, typically on the inside of the door or near the keypad.
- Insert the required number of AA batteries (not included) according to the polarity markings.
- Close the battery compartment cover securely.



Image: A detailed view of the safe's digital keypad and the external battery box, illustrating where batteries are inserted for power.

3. Setting Your Personal Password

Upon first use, or after battery replacement, you will need to set your personal password.

1. With the safe door open, press the reset button (usually a small red button located on the inside of the door near the hinge or battery compartment).
2. The indicator light on the keypad will flash, indicating it's ready for a new code.
3. Enter your desired 3-8 digit password, then press the "#" key to confirm.
4. Test the new password with the door open to ensure it works correctly before closing the safe.

4. Mounting the Safe

For enhanced security, it is highly recommended to anchor the safe to a wall or floor using the provided expansion bolts.

1. Choose a suitable location for the safe, ensuring it is level and stable.
2. Mark the drilling points through the pre-drilled holes at the back or bottom of the safe onto the wall or floor.

3. Drill pilot holes using an appropriate drill bit for your wall/floor material.
4. Align the safe with the drilled holes and insert the expansion bolts.
5. Tighten the bolts securely to firmly attach the safe.



Image: An illustration demonstrating the three-step process for securely mounting the safe to a wall or floor using the provided expansion bolts.

Operating Instructions

1. Unlocking the Safe

The safe offers two methods for unlocking:

- **Using the Digital Keypad:** Enter your personal password (3-8 digits) followed by the "#" key. The green indicator light will illuminate. Turn the handle clockwise within 5 seconds to open the door.
- **Using the Emergency Key:** In case of forgotten password or dead batteries, the emergency key can be used. Locate the emergency keyhole (often concealed behind a removable panel on the keypad). Insert the emergency

key and turn it while simultaneously turning the handle to open the safe. **Important:** Do not store emergency keys inside the safe.



Image: A visual guide detailing the two primary methods to unlock the safe: using the digital keypad with a password and using the emergency key for access.

2. Locking the Safe

To lock the safe, simply close the door and turn the handle counter-clockwise until it is fully engaged. The safe will automatically lock.

3. Anti-Theft Alarm System

The safe is equipped with an anti-theft alarm system:

- If an incorrect password is entered three consecutive times, the alarm will sound, and the keypad will lock for a short period.
- The alarm will also activate if the safe experiences strong vibrations or attempts at forced entry.
- To silence the alarm, enter the correct password.



Image: A depiction of the safe's anti-theft system, showing an alarm siren and a visual representation of how the safe deters unauthorized access.

4. Mute Mode

You can set the safe to silent mode to avoid disturbing others. Refer to your specific model's instructions for activating/deactivating mute mode. Note that even in mute mode, the alarm will still sound if an incorrect password is entered multiple times.

5. Removable Shelf and LED Light

The safe includes a removable shelf to customize storage space. The built-in LED light automatically illuminates when the door is opened, providing visibility in low-light conditions.



Image: The safe's interior, illustrating how the removable shelf can be adjusted or removed to accommodate items of various sizes.

Maintenance

- **Battery Replacement:** When the battery power is low, the indicator light may flash or the keypad may become unresponsive. Replace all batteries in the external battery case with new AA batteries.
- **Cleaning:** Clean the exterior of the safe with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- **Key Care:** Keep your spare keys in a secure location outside the safe. If a key is lost, note the serial number on the keyhole and contact customer support for a replacement.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Safe does not open with password.	Incorrect password entered; batteries are low or dead.	Re-enter the correct password. Replace batteries in the external battery case. Use the emergency key.
Keypad is unresponsive.	Dead batteries.	Replace batteries in the external battery case.
Alarm sounds unexpectedly.	Incorrect password attempts; strong vibrations.	Enter the correct password to silence. Avoid placing the safe in areas prone to heavy vibrations.
Forgot password.	Password forgotten.	Use the emergency key to open the safe. Reset the password following the "Setting Your Personal Password" instructions.

Specifications

Brand: RXUJYC

Product Dimensions: 12.21"D x 13.78"W x 27.56"H

Lock Type: Electronic Combination Lock, Key

Color: Black

Capacity: 6.2 Cubic Feet (Note: Product title states 7.0 Cuft, but specifications list 6.2 Cuft. Please refer to actual internal measurements for precise capacity.)

Material: Alloy Steel

Special Features: Alarm System, Anti-Theft, Combination Lock, Fireproof, Removable Shelf

Mounting Type: Floor Mount

Included Components: Anti-Scratch Pad x 1, Expansion Bolt x 4, Manual x 1, Safe box x 1, Spare Key x 2

Item Weight: 18.5 Kilograms

Alarm: Audible

Warranty and Support

RXUJYC is committed to providing quality products and customer satisfaction.

- **Missing Parts:** If you encounter any missing parts upon receiving or during the use of this product, please contact our customer support for a free replacement.
- **Product Defects:** Should any defects be found due to transportation or manufacturing, please notify us, and we will address the issue promptly.
- **Lost Keys:** In the event of lost keys, please provide the serial number located on the keyhole, and we can assist in providing a new set.
- For further assistance or inquiries, please refer to the contact information provided with your purchase or on the official RXUJYC website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F3887C47

More documents and user manuals: **https://manuals.plus/**