Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RM-L1718

XINFUTE RM-L1718 Universal TV Remote Control User Manual

Model: RM-L1718

1. Product Overview

The XINFUTE RM-L1718 is a universal replacement remote control designed for various TV brands, including CHIQ, AKAI, CHANGHONG, JVC, and OK TV. This remote functions as a direct replacement for original units, offering immediate usability without complex programming.

It is constructed from durable ABS material and comes in an "As Shown" color, typically black. The package includes one remote control; batteries are not included.



Figure 1: Front view of the RM-L1718 remote control.



Figure 2: Back view of the RM-L1718 remote control.



Figure 3: Side and front view of the RM-L1718 remote control.

2. Setup Instructions

The RM-L1718 remote control is designed for immediate use with compatible televisions. No complex pairing or programming is required.

1. **Install Batteries:** Locate the battery compartment on the back of the remote control. Slide the cover off.
2. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Replace the battery compartment cover.
4. The remote control is now ready for use. Point it towards your television and begin operation.

Note: Batteries are not included with the remote control.

3. Operating Instructions

This section outlines the basic functions of the RM-L1718 remote control.

- **Power Button ( ):** Turns the television on or off.
- **Number Pad (0-9):** Used to directly enter channel numbers.
- **Volume Up/Down (+/-):** Adjusts the television's volume level.
- **Channel Up/Down (P▲/P▼):** Changes the television channel sequentially.
- **Navigation Buttons (◄ ▲ ▼ ►):** Used to navigate menus and select options.
- **OK Button:** Confirms selections in menus.
- **Back Button (←):** Returns to the previous screen or menu.
- **Home Button (⌂):** Accesses the television's main home screen or smart TV interface.
- **Dedicated App Buttons:** Direct access to streaming services such as Netflix, YouTube, Prime Video, and Google Play.
- **Mute Button ( ):** Mutes or unmutes the television's audio.
- **Info Button (INFO):** Displays information about the current program or input.
- **EPG Button (EPG):** Accesses the Electronic Program Guide.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries or different types of batteries.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

5. Troubleshooting

If you experience issues with your RM-L1718 remote control, refer to the following common problems and solutions:

- **Remote is not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with two new AAA batteries.
  - Ensure there is a clear line of sight between the remote control and the television's infrared receiver. Obstructions can block the signal.
  - Verify that the television is powered on.
- **Specific buttons are not working:**
  - This could indicate low battery power. Replace the batteries.
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris that might be obstructing the button mechanism.
- **Remote does not control my TV:**
  - Confirm that your TV brand (CHIQ, AKAI, CHANGHONG, JVC, OK TV) is listed as compatible. While universal, compatibility can vary.

- Ensure batteries are fresh and correctly installed.

6. Specifications

Feature	Detail
Model Number	RM-L1718
Brand	XINFUTE
Compatible Devices	Television (CHIQ, AKAI, CHANGHONG, JVC, OK TV)
Max Number of Supported Devices	1
Material	ABS Material
Color	As Shown (Typically Black)
Batteries Required	2 x AAA batteries (not included)
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Special Feature	Ergonomic design

7. Warranty Information

This XINFUTE RM-L1718 remote control comes with a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.
For warranty claims or inquiries, please retain your proof of purchase.

8. Customer Support

Our products undergo thorough inspection before shipment. If you are not satisfied with your purchase or encounter any issues, please contact our customer support team within 24 hours of receiving your product.
Please refer to your purchase documentation or the seller's contact information for specific support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F38G8328

More documents and user manuals: **https://manuals.plus/**