Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

D-BUGG UTV-1114

D-BUGG DBRM-L1098+X PLUS Universal Remote Control User Manual

Model: UTV-1114

Introduction

This manual provides detailed instructions for the D-BUGG DBRM-L1098+X PLUS Universal Remote Control, model UTV-1114. This remote is designed for use with various LCD, LED, HD, and 3D televisions, offering a simplified control experience with dedicated buttons for popular streaming services. Please read this manual thoroughly before use to ensure proper operation and to maximize the remote's functionality.

Safety Information

- Do not expose the remote control to direct sunlight, heat sources, or extreme temperatures.
- Avoid dropping the remote or subjecting it to strong impacts.
- Do not immerse the remote control in water or any other liquid.
- Keep out of reach of children to prevent accidental ingestion of batteries.
- Dispose of used batteries according to local regulations. Do not incinerate batteries.

Package Contents

Verify that all items are present in the package:

- 1 x D-BUGG DBRM-L1098+X PLUS Universal Remote Control
- 1 x User Manual (this document)



Image: The D-BUGG DBRM-L1098+X PLUS Universal Remote Control sealed in its clear plastic retail packaging, showing the remote and part of the cardboard backing.

Product Overview

The DBRM-L1098+X PLUS remote features an ergonomic design with clearly labeled buttons for intuitive control of your television and streaming services.



Image: A detailed top-down view of the D-BUGG DBRM-L1098+X PLUS Universal Remote Control, highlighting the layout of all buttons, including the navigation pad, number keys, and dedicated streaming service buttons.

Key Features:

- **Power Button:** Turns the TV on or off.
- **Number Pad (0-9):** For direct channel input.
- **Volume Up/Down:** Adjusts the television volume.
- **Channel Up/Down:** Changes television channels.
- **Navigation Pad (Up, Down, Left, Right, ENTER):** For menu navigation and selection.
- **Netflix Button:** Direct access to the Netflix application.
- **YouTube Button:** Direct access to the YouTube application.
- **Hulu Button:** Direct access to the Hulu application.
- **Source/Input:** Selects input sources (HDMI, AV, etc.).
- **Menu/Settings:** Accesses TV menu or settings.
- **Aspect:** Adjusts screen aspect ratio.
- **Sleep:** Sets a sleep timer for the TV.
- **3D:** Activates or deactivates 3D mode (if supported by TV).

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.

4. Replace the battery cover by sliding it back into place until it clicks securely.

Note: Batteries are not included and must be purchased separately.

2. Initial Use (No Programming Required)

The DBRM-L1098+X PLUS Universal Remote Control is designed for immediate use with most modern LCD, LED, HD, and 3D TV brands without complex programming. Simply install the batteries, point the remote at your TV, and begin using it.
If the remote does not respond to your TV immediately, it may require a simple code search or brand-specific setup. Refer to the "Troubleshooting" section for further assistance if direct operation is not achieved.

Operating Instructions

Basic TV Control:

- **Power On/Off:** Press the **POWER** button once.
- **Volume Adjustment:** Use the **VOL+** and **VOL-** buttons.
- **Channel Change:** Use the **CH+** and **CH-** buttons, or enter the channel number directly using the number pad.
- **Mute:** Press the **MUTE** button to silence the TV. Press again to unmute.
- **Input/Source Selection:** Press the **SOURCE** button to cycle through available input sources (e.g., HDMI 1, AV, TV). Use the navigation arrows and **ENTER** to select.

Streaming Service Access:

The remote features dedicated buttons for quick access to popular streaming platforms:

- Press the **NETFLIX** button to launch the Netflix application.
- Press the **YOUTUBE** button to launch the YouTube application.
- Press the **HULU** button to launch the Hulu application.

Note: Your TV must be a smart TV with these applications installed and connected to the internet for these buttons to function. Functionality may vary based on TV model and software version.

Advanced Functions:

- **Aspect Mode:** Press the **ASPECT** button to change the screen's aspect ratio (e.g., 16:9, 4:3, Zoom).
- **Sleep Timer:** Press the **SLEEP** button to set a timer for the TV to automatically turn off. Repeated presses may cycle through different time intervals.
- **3D Mode:** If your TV supports 3D, press the **3D** button to activate or deactivate 3D display.
- **Menu/Settings:** Use the **MENU** or **SETTINGS** button to access your TV's on-screen display for picture, sound, and other settings.

Maintenance

Cleaning:

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the remote's surface or internal components.

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Troubleshooting

- **Remote is not working:**
  - Ensure batteries are installed correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote and the TV's infrared sensor.
  - Point the remote directly at the TV.
- **Specific buttons are not working (e.g., Netflix, YouTube):**
  - Confirm your TV is a smart TV and has the respective applications installed.
  - Ensure your TV is connected to the internet.
  - Some older smart TV models or specific brands may not fully support direct app launch buttons from universal remotes.
- **Remote controls some functions but not others:**
  - While designed for broad compatibility, some advanced or brand-specific functions may not be fully supported by all universal remotes.
  - Try resetting the remote by removing batteries for 30 seconds and reinserting them.

Specifications

Model Number	UTV-1114 (DBRM-L1098+X PLUS)
Compatibility	LCD, LED, HD, and 3D Televisions
Power Source	2 x AAA Batteries (not included)
Dimensions	8.66 x 1.77 x 0.79 inches (22 x 4.5 x 2 cm)
Weight	5.3 ounces (150 grams) without batteries
Color	Black
Special Features	Dedicated Netflix, YouTube, Hulu buttons; Aspect, Sleep, 3D functions

Warranty and Support

For warranty information or technical support, please refer to the retailer where the product was purchased or visit the official D-BUGG website. Keep your purchase receipt as proof of purchase.

© 2025 D-BUGG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F3B3M28K

More documents and user manuals: **https://manuals.plus/**