PCTTOIL NC301 NC300 NC299 Outer Bowl Lid

PCTTOIL Outer Bowl Lid User Manual

Brand: PCTTOIL | **Model:** NC301 NC300 NC299 Outer Bowl Lid

1. Introduction

This manual provides essential information for the proper use and maintenance of your PCTTOIL Outer Bowl Lid, designed as a replacement part for specific Ninja Creami Ice Cream Maker models. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

2. Compatibility

The PCTTOIL Outer Bowl Lid is specifically designed to be compatible with the following Ninja Creami Ice Cream Maker models:

- NC299AMZ
- NC300
- NC300C
- NC301
- CN301CO
- CN305A
- NC301HNV
- NC301HRD
- NC301HRG
- NC301HSL
- NC301HWH
- NC301RGBBB
- NC301WHBBB

Note: This lid is NOT compatible with Ninja Creami Deluxe (NC500 series) ice cream makers.



Image: Visual guide showing compatible Ninja Creami models for the PCTTOIL Outer Bowl Lid.

3. Product Features

- **Premium Quality Material:** Crafted from high-quality, BPA-free polycarbonate for durability.
- **Secure & Leak-Proof Design:** Engineered for a precise fit to prevent spills and ensure a tight seal.
- **Easy Installation:** Snaps on effortlessly without the need for tools.
- **Easy Cleaning:** Smooth surface resists food residue and is dishwasher-safe.



Image: Close-up view of the lid, emphasizing its material quality and safety features.



Image: Detailed features of the lid, including its sealing mechanism and paddle latch.

4. Setup

To prepare your Ninja Creami for use with the PCTTOIL Outer Bowl Lid, follow these steps:

1. Ensure your Ninja Creami machine is unplugged and clean.
2. Place the inner pint container (not included) filled with your ingredients into the outer bowl.
3. Align the PCTTOIL Outer Bowl Lid onto the outer bowl. Ensure the paddle latch is in the open position.
4. Press down firmly and rotate the lid clockwise until it locks securely into place. You should hear a click.
5. Place the assembled outer bowl with the lid onto the Ninja Creami motor base.
6. Push the outer bowl handle up until it clicks into place, securing it to the motor base.

Your browser does not support the video tag.

Video: Demonstration of installing the outer bowl lid and assembling it with the Ninja Creami machine. This video shows how to correctly attach the lid and place the assembly onto the machine base.

5. Operating

Once the PCTTOIL Outer Bowl Lid is securely installed on your Ninja Creami machine, you can proceed with your desired ice cream or frozen treat preparation. Refer to your original Ninja Creami instruction manual for specific program settings and recipe guidelines.

1. Ensure the machine is plugged in and the power indicator light is on.
2. Select your desired program (e.g., Ice Cream, Sorbet, Gelato) on the Ninja Creami control panel.
3. Press the START button to begin the processing cycle.
4. The machine will automatically stop once the cycle is complete.
5. To remove the outer bowl, press the release button on the side of the motor base and pull the handle down.
6. Carefully remove the outer bowl and then detach the PCTTOIL Outer Bowl Lid by rotating it counter-clockwise.



Image: The PCTTOIL Outer Bowl Lid shown alongside a Ninja Creami Ice Cream Maker, illustrating its intended use.

6. Maintenance

Proper cleaning and maintenance will extend the life of your PCTTOIL Outer Bowl Lid.

- **After Each Use:** Disassemble the lid from the outer bowl. Wash the lid with warm, soapy water. Rinse thoroughly.
- **Dishwasher Safe:** The PCTTOIL Outer Bowl Lid is dishwasher-safe. Place it on the top rack for best results.
- **Drying:** Allow all parts to air dry completely before reassembling or storing.
- **Storage:** Store the lid in a clean, dry place away from direct sunlight.



Image: Visual guide demonstrating both hand washing and dishwasher cleaning methods for the lid.

7. Troubleshooting

If you encounter any issues with your PCTTOIL Outer Bowl Lid, please refer to the following common solutions:

- **Lid Not Sealing Properly:** Ensure the lid is correctly aligned with the outer bowl and rotated clockwise until it clicks into place. Check for any food debris or obstructions on the sealing gasket.
- **Difficulty Attaching/Removing Lid:** Ensure the paddle latch is in the correct position (open for removal, closed for secure attachment). Apply firm, even pressure when attaching or removing.
- **Machine Not Starting:** Verify that the outer bowl with the lid is securely locked onto the motor base. The machine has safety features that prevent operation if components are not correctly assembled.

For further assistance, please consult your Ninja Creami machine's original manual or contact PCTTOIL customer support.

8. Specifications

Feature	Detail
Brand	PCTTOIL
Model Number	NC301 NC300 NC299 Outer Bowl Lid
Material	BPA Free Plastic
Color	Black
Item Weight	6.3 ounces (0.18 Kilograms)
Product Dimensions	2 x 2 x 0.04 inches
Dishwasher Safe	Yes
Microwaveable	No
UPC	658370899511

9. Warranty and Support

For any questions, concerns, or support regarding your PCTTOIL Outer Bowl Lid, please contact the manufacturer directly through their official channels. Specific warranty details may vary; please retain your proof of purchase for any warranty claims.