XINFUTE RG51G(1)/CEFU1

Instruction Manual for XINFUTE Air Conditioner Remote Control

Model: RG51G(1)/CEFU1

1. Introduction

This manual provides detailed instructions for the operation and maintenance of your XINFUTE RG51G(1)/CEFU1 Air Conditioner Remote Control. This remote is designed to be compatible with specific Danby, Midea, and Seasons air conditioner models, including DAC100EB9WDB and DAC120EB9WDB-6. Please read this manual thoroughly before use to ensure proper functionality and extend the life of your remote control.



Figure 1: Front view of the RG51G(1)/CEFU1 Remote Control. This image displays the remote's display screen and all primary control buttons, including power, mode, temperature, and fan speed.

2. Setup

2.1 Battery Installation

The remote control requires **two (2) AAA batteries** (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.



Figure 2: Front and back view of the remote control. The back view clearly shows the battery compartment cover, indicating where batteries should be inserted.

3. Operating Instructions

Familiarize yourself with the buttons and their functions to effectively control your air conditioner.



Figure 3: Angled view of the remote control, providing a clear perspective of the button layout for easy identification and operation.

3.1 Button Functions

Button	Description
Power (Red Button)	Turns the air conditioner ON or OFF.
TEMP ▲ / ▼	Adjusts the desired temperature setting. ▲ increases temperature, ▼ decreases temperature.
MODE	Cycles through operating modes: Auto, Cool, Dry, Fan, Heat (if applicable to your AC unit).

Button	Description
FAN	Adjusts the fan speed (e.g., Auto, Low, Medium, High).
SLEEP (Moon Icon)	Activates or deactivates the sleep mode, which adjusts temperature for comfortable sleep and energy saving.
TIMER ON / OFF	Sets the timer for the air conditioner to turn ON or OFF automatically.
°C/°F	Switches the temperature display between Celsius and Fahrenheit.
LIGHT (Light Bulb Icon)	Controls the display light on the air conditioner unit (if available).
LOCK (Padlock Icon)	Locks the remote control buttons to prevent accidental changes. Press again to unlock.
SWING (Fan with Arrows)	Controls the vertical swing of the air conditioner's louvers.

4. Maintenance

4.1 Cleaning the Remote Control

To maintain the appearance and functionality of your remote control:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, dampen the cloth slightly with water and a mild detergent, then wipe dry immediately.
- Do not use abrasive cleaners, alcohol, or corrosive liquids, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's display becomes dim or the remote stops responding. Refer to Section 2.1 for battery installation instructions. Dispose of used batteries responsibly according to local regulations.

5. Troubleshooting

If you encounter issues with your remote control, refer to the following common problems and solutions:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner's receiver.
- **Short operating range:**
  - Batteries may be low; replace them.
  - Ensure no strong light sources (e.g., direct sunlight, fluorescent lights) are interfering with the infrared signal.

- **Display is dim or blank:**
  - Batteries are likely depleted; replace them immediately.

If the problem persists after trying these solutions, please contact customer support.

6. Specifications

Feature	Detail
Model Number	RG51G(1)/CEFU1
Brand	XINFUTE
Compatible AC Models	DAC100EB9WDB, DAC120EB9WDB-6 (Danby, Midea, Seasons)
Power Supply	2 x AAA Batteries (not included)
Connectivity Technology	Infrared (IR)
Material	ABS Material
Color	As Shown (Typically White/Light Gray)
Product Dimensions	Approximately 4 x 3 x 1 inches
Item Weight	Approximately 2.4 ounces
Special Feature	Original Replacement Unit

7. Warranty and Support

7.1 Warranty Information

This XINFUTE remote control comes with a**one-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact the seller or manufacturer within 24 hours of receipt. For further assistance or technical support, please refer to the contact information provided by your retailer or the manufacturer's official website.
Please note that specific contact details are not provided in this manual. Refer to your purchase documentation for support contacts.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question