Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY AMT-ERF3A69-BT-Silver-RE

Allimity ERF3A69 Replacement Voice Remote Control User Manual

Model: AMT-ERF3A69-BT-Silver-RE

1. Introduction

Thank you for choosing the Allimity ERF3A69 Replacement Voice Remote Control. This remote is designed to provide seamless control over your compatible Sharp and Hisense Smart TVs, offering voice command capabilities and direct access buttons for popular streaming services. This manual will guide you through the setup, operation, and maintenance of your new remote control.





Figure 1: Front view of the Allimity ERF3A69 Replacement Voice Remote Control, showcasing its ergonomic design and button layout.

2. Product Overview

The Allimity ERF3A69 remote control is a direct replacement designed for specific Sharp and Hisense Smart TV models. It features:

- **Voice Control Functionality:** Enables hands-free command input for compatible TVs.
- **Dedicated App Buttons:** Quick access to popular streaming services like Netflix, Google Play, YouTube, Sling, Fandango Now, and Tikilive.
- **Standard TV Controls:** Includes power, volume, channel, navigation, and media playback buttons.
- **Durable Plastic Construction:** Designed for longevity and comfortable handling.



Figure 2: Angled view of the remote, providing a clearer look at the various buttons and their labels.

3. Setup and Pairing

Before using your new remote control, it must be paired with your compatible Sharp or Hisense Smart TV. The exact pairing process may vary slightly depending on your TV model. Refer to your TV's user manual for specific instructions if these general steps do not work.

3.1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover.
3. Insert two AAA batteries (not included), ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

3.2. Initial Pairing

For voice and advanced functions, the remote typically needs to be paired via Bluetooth with your TV. For basic IR functions, simply pointing the remote at the TV's IR sensor should work.

1. Ensure your TV is powered on.
2. On your TV, navigate to the **Settings** menu.
3. Look for options such as **Remotes & Accessories**, **Bluetooth Settings**, or **System Settings**.
4. Select the option to **Add a new device** or **Pair remote control**.
5. Follow the on-screen prompts. This usually involves pressing and holding specific buttons on the new remote (e.g., the 'OK' button and 'Back' button simultaneously, or the 'Home' button and 'Back' button) until a pairing indicator light flashes on the remote or a message appears on the TV screen.
6. Once the remote appears in the list of discoverable devices on your TV, select it to complete the pairing process.

Important: When using the remote, aim it directly at the TV's sensor. Avoid any obstacles that might block the signal.

4. Operating Instructions

This section outlines the general functions of the remote control buttons.

- **Power Button ( ):** Turns the TV on or off.
- **Voice Button (Microphone icon):** Activates the voice control feature. Press and hold to speak commands.
- **Navigation Pad (Directional Arrows and OK):** Use the arrow buttons to navigate menus and select options with the 'OK' button.
- **Back (←):** Returns to the previous screen or menu.
- **Home (Circle icon):** Returns to the TV's main home screen.
- **Play/Pause (▶‖):** Controls media playback.
- **Volume Up/Down (VOL +/-):** Adjusts the TV's volume level.
- **Mute (Speaker with cross-out icon):** Mutes or unmutes the TV's audio.
- **Channel Up/Down (CH ^/v):** Changes TV channels.
- **TV Button:** Switches input source or returns to live TV.
- **Dedicated App Buttons (Netflix, Google Play, YouTube, Sling, Fandango Now, Tikilive):** Directly launch the respective applications.
- **CC (Closed Captioning):** Toggles closed captions on/off.
- **NRT (Next/Repeat):** Functionality may vary by TV model or app.
- **MTS (Multi-channel Television Sound):** Selects audio modes (e.g., stereo, SAP).



Figure 3: Example of the remote control in use, demonstrating its ergonomic fit for comfortable operation.

5. Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Wipe the remote with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in liquid.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

6. Troubleshooting

If you encounter issues with your remote control, try the following solutions:

- **Remote not responding:**
  - Check if the batteries are inserted correctly and have sufficient charge. Replace them if necessary.
  - Ensure there are no obstacles between the remote and the TV's sensor.
  - Re-pair the remote control with your TV (refer to Section 3.2).
- **Voice control not working:**
  - Ensure the remote is properly paired via Bluetooth.
  - Check your TV's settings to ensure voice control is enabled.
  - Speak clearly and hold the remote closer to your mouth when using voice commands.
- **Specific buttons not working:**
  - Clean the remote's surface and buttons to remove any dirt or debris that might be obstructing them.
  - Some buttons' functionality may depend on the active app or TV input.

If the problem persists after trying these steps, please contact ALLIMITY customer support for further assistance.

7. Specifications

Attribute	Detail
Model Number	ERF3A69 (AMT-ERF3A69-BT-Silver-RE)
Product Material	Plastic
Color	Black
Product Dimensions	5 x 2 x 0.6 inches
Item Weight	1 ounces
Power Source	2 x AAA Batteries (not included)
Connectivity	Infrared (IR) and Bluetooth (for voice/advanced features)

8. Compatible TV Models

This remote control is compatible with the following Sharp and Hisense Smart TV models:

- HU50U7A, HU55U7AG, HU65U7AG
- HU55A6125UW, HU58A6100UW, HU65A6125UW, HU65A6127UW
- HU75M5060UW
- LC-43N6100, LC-43N5000, LC-43N7000
- LC-50N7000, LC-50N5000, LC-50N6000
- LC-55Q7530U, LC-55N6000, LC-55N8003U, LC-58N7503U, LC-55N7000
- LN-60N7000, LC-60N6200
- LC-65N7000, LC-65N5200, LC-65N9000
- LN-75N8000, LC-75N8003U, LC-75Q7570U

If your TV model is not listed, please contact ALLIMITY customer support to verify compatibility before purchase.

9. Warranty and Support

ALLIMITY products are designed for reliability and performance. If you experience any issues with your remote control, or if the product you received does not function as expected, please contact ALLIMITY customer support directly. We are committed to helping you resolve any problems and ensure your satisfaction.

For returns or replacements, please refer to the retailer's return policy where the product was purchased. Typically, a refund or replacement policy is available for a specified duration from the date of purchase.

Manufacturer: ALLIMITY inc

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F437S9QR

More documents and user manuals: **https://manuals.plus/**