Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TECLAST ArtPad Pro

TECLAST ArtPad Pro 12.7-inch Tablet User Manual

Model: ArtPad Pro

1. Introduction

Welcome to the TECLAST ArtPad Pro user manual. This guide will help you understand and utilize all the features of your new 12.7-inch tablet, designed for creativity, productivity, and entertainment. Please read this manual carefully before using your device.

2. What's in the Box

Verify that all items are present in your package:

- TECLAST ArtPad Pro Tablet
- T-Pen Stylus
- Power Adapter (Note: Adapter specifications may vary by region)
- USB Data Cable
- SIM Ejector Tool
- Maintenance Card
- User Manual (this document)



Image: Contents of the ArtPad Pro package. Shows the tablet, T-Pen, power adapter, USB cable, SIM ejector tool, and user manual.

3. Device Layout and Overview

Familiarize yourself with the physical features of your TECLAST ArtPad Pro tablet.



Image: Front and back view of the TECLAST ArtPad Pro tablet, highlighting its sleek design.

3.1 Front View

- **12.7-inch IPS Display:** High-resolution 2176x1600 screen.
- **Front Camera (8MP):** Located at the top bezel, used for video calls and face recognition.

3.2 Rear View

- **Rear Camera (13MP) with Flash:** For taking photos and videos.
- **TECLAST Logo:** Brand identification.

3.3 Side Views



Image: Detailed side view of the ArtPad Pro, showing the power button, volume controls, USB-C port, and speaker grilles.

- **Power Button:** Press and hold to power on/off or restart. Press briefly to sleep/wake the screen.
- **Volume Buttons:** Adjust the device's volume.
- **USB Type-C Port:** For charging, data transfer, and connecting peripherals.
- **SIM/TF Card Slot:** Insert your Nano-SIM card(s) and/or microSD card for expanded storage.
- **Speakers:** Quad speakers for immersive audio experience.
- **Microphones:** Built-in microphones for voice input.

4. Setup

4.1 Initial Power On

1. Press and hold the **Power Button** until the TECLAST logo appears on the screen.
2. Follow the on-screen prompts to select your language, region, and accept the terms and conditions.

4.2 Wi-Fi Connection

1. During initial setup or later, go to **Settings** > **Network & internet** > **Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the password if prompted and tap **Connect**.

4.3 SIM Card and MicroSD Card Installation

The ArtPad Pro supports dual Nano-SIM cards and a microSD card for storage expansion up to 1TB.

1. Locate the SIM/TF card slot on the side of the tablet.
2. Insert the **SIM Ejector Tool** into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray, ensuring correct orientation.
4. Carefully push the tray back into the tablet until it clicks into place.
5. Restart the tablet for the changes to take effect.



Image: Diagram showing how to insert SIM cards and a microSD card into the tablet's tray.

4.4 T-Pen Stylus Usage

The included T-Pen stylus offers 4096 levels of pressure sensitivity and tilt detection for precise drawing and writing.

- The T-Pen is ready to use out of the box; no pairing is required.
- Use it with pre-installed apps like Art Note or other compatible drawing/note-taking applications.
- The stylus features palm rejection technology for a natural writing experience.



Image: A user utilizing the T-Pen stylus on the ArtPad Pro for creative work.

5. Operating Instructions

5.1 Basic Navigation and Gestures

- **Tap:** Select an item or open an app.
- **Swipe:** Navigate through home screens, menus, or scroll through content.
- **Pinch-to-Zoom:** Zoom in or out on photos, maps, and web pages.
- **Long Press:** Access contextual menus or move app icons.
- **Swipe Down from Top:** Access Quick Settings and notifications.

5.2 Art OS Features (Android 15)

The ArtPad Pro runs on Android 15 with TECLAST's Art OS enhancements, offering a personalized and efficient user experience.



Image: Art OS interface displaying Standard Mode, Pastel Mode, and Ink Mode for various user scenarios.

- **Art Space:** One-tap switching between Standard Mode, Pastel Mode, and Ink Mode (optimized for reading).
- **Smart Button:** Customize actions for single tap, double tap, or long press to launch apps or system functions.
- **Quick Sidebar:** Intuitive control for multi-window operations.
- **AI Control:** Customize app launches and system functions with tap/long press gestures.

5.3 Display Settings

- Navigate to **Settings** > **Display** to adjust brightness, dark theme, screen timeout, and font size.
- The 12.7-inch 2176x1600 IPS display offers a 4:3 aspect ratio for an expansive viewing area.

5.4 Camera Usage

The tablet features an 8MP front camera and a 13MP rear camera with AI enhancements.

1. Open the **Camera** app.
2. Switch between front and rear cameras using the icon on the screen.
3. Tap the shutter button to take photos or start/stop video recording.
4. Explore different modes like Portrait, Panorama, and Pro mode if available.

5.5 Audio Settings (Symphony Sound System)

The ArtPad Pro features a Symphony Sound System with four 9CC large-diameter dual-magnetic circuit speakers and Art Tune X algorithm for a 4D audio experience.

- Adjust volume using the physical volume buttons or through**Settings** > **Sound & vibration**.
- Experience enhanced audio for music, movies, and games with Sound Theater 3.0 technology.

5.6 Connectivity

- **Wi-Fi:** Supports AC Wi-Fi for fast internet access. Manage in**Settings** > **Network & internet**.
- **Bluetooth 5.2:** Connect wireless headphones, speakers, and other Bluetooth devices. Manage in**Settings** > **Connected devices**.
- **4G LTE:** Use cellular data for internet access on the go. Ensure a SIM card is installed and activated.
- **GPS/GLONASS/BDS/Galileo:** Integrated 4-satellite positioning system with A-GPS for precise navigation.

5.7 Storage Management

The tablet comes with 256GB UFS storage, 8GB LPDDR4 RAM (expandable to 20GB with virtual RAM), and supports up to 1TB microSD expansion.

- Check storage usage in **Settings** > **Storage**.
- Manage files using the pre-installed File Manager app.

5.8 Battery and Charging

The ArtPad Pro is equipped with a 10000mAh battery and supports 30W PD fast charging.

- Connect the USB Type-C cable to the tablet and the power adapter to a wall outlet to charge.
- For optimal charging speed, use the provided 30W power adapter.
- Monitor battery level in the status bar or **Settings** > **Battery**.

5.9 Security Features

- **Face Recognition:** Set up face unlock in **Settings** > **Security & privacy** > **Face unlock**.
- You can also set up a PIN, pattern, or password for device security.

5.10 Google Gemini AI Assistant

Integrated with Google Gemini AI, the tablet offers features like automatic document creation, chart analysis, image generation, and content creation.

- Access Gemini through its dedicated app or by voice command (if configured).

5.11 Widevine L1 Certification

With Widevine L1 certification, you can enjoy high-definition streaming content from platforms like Netflix, YouTube, and Amazon Prime Video.

5.12 Wireless Projection

Connect your tablet to a larger screen, such as a TV or projector, wirelessly.

1. Ensure your TV/projector supports wireless display (e.g., Miracast, Chromecast).
2. Go to **Settings** > **Connected devices** > **Connection preferences** > **Cast**.
3. Select your display device from the list to mirror your tablet's screen.

6. Maintenance

6.1 Cleaning the Device

- Use a soft, lint-free cloth to wipe the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.

6.2 Battery Care

- Avoid exposing the tablet to extreme temperatures (hot or cold).
- Do not fully discharge the battery frequently; try to keep it above 20%.
- Use only the original charger or certified compatible chargers.

6.3 Software Updates

- Regularly check for system updates to ensure optimal performance and security.
- Go to **Settings** > **System** > **System update** to check for and install available updates.
- Ensure your device is sufficiently charged and connected to Wi-Fi before performing an update.

7. Troubleshooting

If you encounter issues with your tablet, try the following solutions:

7.1 Device Not Turning On

- Ensure the battery is charged. Connect the charger and wait a few minutes before trying to power on.
- Press and hold the Power Button for 10-15 seconds to force a restart.

7.2 Wi-Fi Connection Issues

- Toggle Wi-Fi off and on again in Quick Settings.
- Restart your Wi-Fi router.
- Forget the network and reconnect by re-entering the password.

7.3 Slow Performance or Apps Crashing

- Close unused background apps.
- Clear cache for problematic apps (**Settings** > **Apps** > [App Name] > **Storage & cache** > **Clear cache**).
- Ensure you have sufficient free storage space.
- Restart the tablet.

7.4 Charging Contact Issues

- Ensure the USB-C cable is fully inserted into both the tablet and the power adapter.
- Try a different USB-C cable and power adapter to rule out faulty accessories.
- Gently clean the USB-C port on the tablet with a dry, soft brush to remove any dust or debris.
- Avoid putting strain on the cable while charging.

7.5 Screen Flickering During Initial Setup

Some users have reported screen flickering during the first boot after initial setup, especially when copying data from another tablet. If this occurs:

- When the "Quick Setup" (Home) alert message appears, select "Manage".
- Within the management options, clear the data and cache for the "Quick Setup" application.
- This should resolve the flickering issue.

7.6 T-Pen Not Responding

- Ensure the screen is clean and free of obstructions.
- Restart the tablet.
- Test the T-Pen in different applications.

8. Specifications

Feature	Specification

Feature	Specification
Brand	TECLAST
Model	ArtPad Pro
Operating System	Android 15
Processor	MediaTek Helio G99 (Octa-core, 2.2 GHz)
GPU	Mali-G57 MC2
RAM	8GB LPDDR4 (expandable to 20GB virtual RAM)
Internal Storage	256GB UFS
Expandable Storage	microSD up to 1TB
Display Size	12.7 inches
Display Type	IPS LCD
Resolution	2176x1600 pixels (2K Ultra HD)
Aspect Ratio	4:3
Refresh Rate	90Hz
Rear Camera	13MP
Front Camera	8MP
Battery	10000mAh
Charging	30W PD Fast Charging (USB Type-C)
Wi-Fi	802.11ac (Dual-band)
Bluetooth	5.2
Cellular	4G LTE (Dual SIM support)
Navigation	GPS/GLONASS/BDS/Galileo, A-GPS
Sensors	Gyroscope, Gravity Sensor, Light Sensor, Magnetic Sensor
Stylus Support	T-Pen (4096 pressure levels, tilt detection)
Security	Face Recognition
Audio	Symphony Sound System (Quad Speakers)
Certifications	GMS, Widevine L1, PSE, CE, FCC, TELEC

9. Warranty and Support

9.1 Manufacturer's Warranty

The TECLAST ArtPad Pro comes with a **12-month manufacturer's warranty** from the date of purchase. Please retain

your proof of purchase for warranty claims.

9.2 Contacting Support

If you have any questions, concerns, or require technical assistance, please contact TECLAST customer support:

- **Before Ordering:** On the product page, click on the store name "TECLAST Official Store" below the "Add to Cart" button, then click "Ask a Question" on the top right to send an email.
- **After Ordering:** Go to your Amazon Account > Order History > Select the relevant order > Contact Seller.
- **Support Hours:** Monday - Friday, 10:00 AM - 7:00 PM (Japan Standard Time). Responses to inquiries received outside these hours or on holidays will be provided on the next business day.

TECLAST is committed to providing quality products and excellent customer service. Your satisfaction is our priority.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F48931WD

More documents and user manuals: **https://manuals.plus/**