Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE ERF6B80HL

XINFUTE ERF6B80HL Voice TV Remote Control User Manual

Model: ERF6B80HL | Brand: XINFUTE

Introduction

This user manual provides comprehensive instructions for the XINFUTE ERF6B80HL Voice TV Remote Control. It is designed to be compatible with Hisense Class A7 and U8 Series televisions. Please read this manual carefully before using your new remote control to ensure proper operation and to maximize its features.

Product Overview

The ERF6B80HL remote control is constructed from durable ABS material and features an ergonomic design for comfortable handling. It includes dedicated buttons for popular streaming services and voice control functionality.



Figure 1: Front view of the ERF6B80HL remote control, showing all buttons including power, navigation, volume, channel, and dedicated app buttons for Netflix, YouTube, Prime Video, Disney+, Tubi, and News. It also features a voice control button.



Figure 2: Side view of the ERF6B80HL remote control, illustrating its slim profile and ergonomic curvature.



Figure 3: Back view of the ERF6B80HL remote control, highlighting the battery compartment cover.

Package Contents:

- 1 x ERF6B80HL Voice TV Remote Control
- *Note: Batteries are not included.*

Setup

Installing Batteries:

The ERF6B80HL remote control requires two (2) AAA batteries for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control (refer to Figure 3).

2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries. Remove batteries if the remote control will not be used for an extended period.

Operating Instructions

This remote control is designed for seamless operation with compatible Hisense Class A7 and U8 Series TVs. It utilizes both Bluetooth and Infrared connectivity.

Basic Functions:

- **Power Button ( ):** Turns the TV on or off.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and select items. The **OK** button confirms selections.
- **Back Button ( ):** Returns to the previous screen or menu.
- **Home Button (⌂):** Accesses the TV's home screen or smart TV interface.
- **Volume Buttons (VOL +/-):** Adjusts the TV's volume level.
- **Channel Buttons (CH +/-):** Changes TV channels.
- **Mute Button ( ):** Mutes or unmutes the TV's audio.
- **Menu Button:** Opens the TV's main menu for settings and options.
- **Play/Pause Button (▶/):** Controls media playback.
- **123 Button:** Accesses a numeric keypad or additional functions.

Voice Control:

The ERF6B80HL remote features a dedicated voice control button. To use voice commands:

1. Press and hold the Voice Control button (often depicted as a microphone icon).
2. Speak clearly into the microphone located on the remote control.
3. Release the button when you have finished speaking.

Voice commands can be used to search for content, change settings, launch apps, and more, depending on your TV's capabilities.

Dedicated App Buttons:

The remote includes one-touch access buttons for popular streaming services:

- Netflix
- YouTube
- Prime Video
- Disney+
- Tubi
- News

Pressing these buttons will directly launch the corresponding application on your Hisense TV, provided the app is installed and your TV is connected to the internet.

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Avoid Drops:** Protect the remote from physical shocks and drops, which can damage internal components.

Troubleshooting

If you experience issues with your XINFUTE ERF6B80HL remote control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote has limited range or intermittent response.	Low batteries; Obstruction between remote and TV; Interference.	Replace batteries. Ensure a clear line of sight to the TV's IR receiver. Move away from sources of interference (e.g., strong lights, other electronic devices).
Voice control not working.	Remote not paired via Bluetooth; Microphone blocked; TV settings.	Ensure the remote is properly paired with your TV via Bluetooth (refer to your TV's manual for pairing instructions). Ensure the microphone is not covered. Check TV's voice control settings.
Dedicated app buttons not launching apps.	TV not connected to internet; App not installed or updated.	Verify your TV's internet connection. Ensure the specific app is installed and up-to-date on your TV.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Model Number	ERF6B80HL
Compatibility	Hisense Class A7 U8 Series TVs
Material	ABS Material
Connectivity Technology	Bluetooth, Infrared
Special Features	Ergonomic Design, Voice Search, Dedicated App Buttons
Power Source	2 x AAA Batteries (not included)
Product Dimensions	6 x 3 x 1 inches

Feature	Detail
Item Weight	2.82 ounces

Warranty and Support

Warranty Information:

XINFUTE offers a one-year warranty on all purchases of this remote control. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

Customer Support:

If you are not satisfied with your purchase or encounter any issues, please contact XINFUTE customer support within 24 hours of receipt. All goods are inspected before shipment to ensure quality.
For support, please visit the XINFUTE Store on Amazon or refer to your purchase documentation for direct contact information.

© 2025 XINFUTE. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where is the exit button on my XINFUTE ERF6B80HL remote control?

Based on the manual for the XINFUTE ERF6B80HL, there is no button explicitly labeled "Exit." Instead, the remote uses the following buttons to navigate away from menus or apps: Back Button ( ): Use this...

Read full answer

Open the live page

https://manuals.plus/asin/B0F4QJ5V25

More documents and user manuals: **https://manuals.plus/**