Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC Power Cord Replacement

onerbl AC Power Cord for Westionc Elliptical Machines User Manual

Models: HJDFGSS, KMS011M, KMSO16M

Introduction Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides instructions for the safe and effective use of your onerbl AC Power Cord. This power cord is designed as a replacement for the original power supply unit of specific Westionc Under Desk Elliptical Machines, including models HJDFGSS, KMS011M, and KMSO16M. It converts standard AC power from an electrical outlet into the DC power required by your elliptical machine, enabling its operation and battery charging (if applicable).
Please read this manual thoroughly before connecting and using the power cord to ensure proper function and safety.

2. Setup

Follow these steps to properly connect your onerbl AC Power Cord to your Westionc elliptical machine.

1. **Unpack the Power Cord:** Carefully remove the power cord from its packaging. Inspect the cord and connectors for any visible damage. Do not use if damaged.
2. **Locate the Power Input Port:** Identify the power input port on your Westionc Under Desk Elliptical Machine. This port is typically located on the back or side of the machine.
3. **Connect to Elliptical Machine:** Insert the DC output connector of the onerbl AC Power Cord firmly into the power input port of your elliptical machine. Ensure a snug fit.
4. **Connect to Power Outlet:** Plug the AC input end of the power cord into a standard 100V-240V electrical wall outlet. Ensure the outlet is easily accessible and not overloaded.
5. **Verify Connection:** Once connected, the elliptical machine should receive power. Refer to your elliptical machine's manual for indicators of power reception (e.g., display lighting up).



Image 1: The onerbl AC Power Cord. This image shows the power cord with its two ends: the AC plug for the wall outlet and the DC connector for the elliptical machine. The cord is black and approximately 6 feet long.

3. Operation

The onerbl AC Power Cord functions as a power supply for your Westionc elliptical machine. Once properly connected, it continuously provides the necessary electrical power for the machine's operation.

- **Power On/Off:** Use the power switch on your Westionc elliptical machine to turn it on or off. The power cord itself does not have an on/off switch.
- **Continuous Power:** The power cord is designed for continuous power delivery during your workout sessions.
- **Charging Functionality:** If your elliptical machine has a rechargeable battery, the power cord will also facilitate charging when connected. Refer to your elliptical machine's manual for battery charging status indicators.

Always ensure the power cord is securely connected during use to prevent interruptions or damage.

4. Maintenance

Proper care and maintenance will extend the lifespan of your onerbl AC Power Cord.

- **Cleaning:** Disconnect the power cord from both the wall outlet and the elliptical machine before cleaning. Wipe the

cord and connectors with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.

- **Storage:** When not in use, store the power cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cord sharply, as this can damage the internal wires.
- **Inspection:** Periodically inspect the power cord for any signs of wear, cuts, fraying, or damage to the insulation. If any damage is observed, discontinue use immediately and replace the cord.
- **Avoid Stress:** Do not pull on the cord to disconnect it from the outlet or the machine. Always grasp the plug or connector firmly. Avoid placing heavy objects on the cord or running it under carpets where it could be pinched or overheated.

5. Troubleshooting

If you encounter issues with your onerbl AC Power Cord, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Elliptical machine does not power on.	• Power cord not fully connected. • Wall outlet is not active. • Power cord is damaged. • Elliptical machine's power switch is off.	• Ensure both ends of the power cord are securely plugged in. • Test the wall outlet with another device. Check circuit breaker. • Inspect the power cord for damage. Replace if necessary. • Turn on the elliptical machine's power switch.
Intermittent power to the elliptical.	• Loose connection. • Damaged power cord.	• Re-seat both ends of the power cord firmly. • Inspect for damage. Replace if necessary.
Power cord feels warm.	• Normal operation (slight warmth). • Overload or internal damage (excessive heat).	• Slight warmth is normal. • If excessively hot, disconnect immediately. Ensure the elliptical machine is compatible with the power cord's specifications. Replace the cord if it continues to overheat.

If these steps do not resolve the issue, please contact customer support.

6. Specifications

Technical specifications for the onerbl AC Power Cord:

- **Input Voltage:** 100V-240V AC
- **Cable Length:** 6 Feet (approximately 1.8 meters)
- **Color:** Black
- **Special Feature:** Short Circuit Protection
- **Compatibility:** Westionc HJDFGSS, KMS011M, KMSO16M Under Desk Elliptical Machines
- **Manufacturer:** Shenzhen Waweis Technology Co., Ltd
- **ASIN:** B0F4QMFRQR

7. Warranty & Support

Warranty Information

This onerbl AC Power Cord comes with a standard manufacturer's warranty. Please refer to the product packaging or the retailer's website for specific warranty terms and duration. The warranty typically covers defects in materials and workmanship under normal use.
Note: Damage resulting from misuse, accident, modification, or unauthorized repair is not covered by the warranty.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact onerbl customer support through the retailer's platform where the product was purchased. Have your product model number and purchase date ready when contacting support.

© 2026 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4QMFRQR

More documents and user manuals: **https://manuals.plus/**