ANCHEER AMA005417

ANCHEER Elliptical Exercise Machine User Manual

Model: AMA005417

1. Introduction

Thank you for choosing the ANCHEER Elliptical Exercise Machine. This manual provides essential information for the safe and effective assembly, operation, and maintenance of your new fitness equipment. Please read this manual thoroughly before initial use and retain it for future reference.



Figure 1.1: The ANCHEER Elliptical Exercise Machine, a compact and efficient fitness solution for home use.

2. Safety Information

Before using the elliptical machine, please observe the following safety precautions:

- Consult with a physician before starting any new exercise program.
- Ensure all parts are securely assembled before each use.
- Keep children and pets away from the machine during operation.
- Place the machine on a flat, stable surface.
- Wear appropriate athletic footwear and clothing.
- Do not exceed the maximum weight capacity of 380 lbs.
- Stop exercising immediately if you feel faint, dizzy, or experience pain.

3. Package Contents

Verify that all components are present in the package:

- 1 x ANCHEER Elliptical Exercise Machine (main unit)
- 1 x User Manual (this document)
- 1 x Assembly Tool Kit (includes necessary wrenches and screws)

4. Setup and Assembly

The ANCHEER Elliptical Machine is designed for effortless assembly. Follow the detailed instructions provided in the included user manual and refer to the installation video for visual guidance.

4.1 Assembly Video

Your browser does not support the video tag.

Video 4.1: Official ANCHEER Elliptical Exercise Machine overview and usage demonstration. This video provides visual steps for assembly and highlights key features.

4.2 Placement and Portability

The compact design of the elliptical machine allows it to fit into various home spaces. It features handy transport wheels for easy relocation without the need for an external power source.



Figure 4.2: The elliptical machine features front-mounted transport wheels for easy movement and storage.

5. Operating Instructions

Familiarize yourself with the machine's features for an optimal workout experience.

5.1 Resistance Levels

The elliptical machine features 8 dynamic resistance levels, controlled by a magnetic drive system. Adjust the tension knob to increase or decrease the workout intensity to suit your fitness goals.



Figure 5.1: The resistance knob allows for quick and easy adjustment of workout intensity across 8 levels.

5.2 Ultra-Silent Operation

The internal magnetic drive system ensures an ultra-quiet exercise experience, with noise levels kept under 20 dB. This allows for workouts at any time without disturbing others.



Figure 5.2: The magnetic flywheel system provides smooth and quiet operation, minimizing noise during workouts.

5.3 LCD Monitor and Pulse Rate Grips

The integrated digital monitor tracks key workout data, including TIME, SPEED, DISTANCE, CALORIES, and PULSE. Grip the pulse rate sensors on the handlebars to monitor your heart rate during exercise.



Figure 5.3: The LCD monitor provides real-time feedback on your workout progress, including pulse rate from the integrated grips.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your elliptical machine:

- **Cleaning:** Wipe down the machine with a damp cloth after each use to remove sweat and dust. Avoid abrasive cleaners.
- **Check Connections:** Periodically check all bolts and nuts to ensure they are tight and secure. Tighten if necessary.
- **Lubrication:** No specific lubrication is required for the magnetic drive system. If any moving parts develop squeaks, apply a small amount of silicone-based lubricant.
- **Storage:** Store the machine in a dry, cool place away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter any issues with your elliptical machine, refer to the following common troubleshooting tips:

- **Machine is unstable/wobbles:** Ensure the machine is placed on a level surface. Adjust the leveling feet at the base if available. Check that all assembly bolts are tightened.
- **Squeaking or grinding noises:** Check for loose parts and tighten them. Ensure no foreign objects are lodged in the moving parts. If the noise persists, contact customer support.
- **LCD monitor not displaying:** Check the battery compartment for proper battery insertion and charge. Ensure all cable connections to the monitor are secure.
- **Resistance not changing:** Verify that the resistance knob is functioning correctly and that the internal mechanism is not obstructed.

For issues not covered here, please contact ANCHEER customer support.

8. Specifications

Key technical specifications for the ANCHEER Elliptical Exercise Machine:

Feature	Detail
Model Name	5417
Brand	ANCHEER
Color	Gray
Product Dimensions (LxWxH)	40.9"D x 18.9"W x 63"H
Material	Aluminum
Resistance Mechanism	Magnetic
Maximum Weight Recommendation	380 Pounds
Maximum Stride Length	15 Inches
Item Weight	34 Kilograms
Number of Resistance Levels	8



Figure 8.1: The elliptical machine's design emphasizes a 15-inch stride and robust construction for durability.

9. Warranty and Support

ANCHEER is committed to providing excellent customer service and product support.

9.1 Warranty Information

ANCHEER guarantees a **Lifetime Service** for all products and offers free replacement of all accessories. Please refer to your purchase documentation for specific warranty terms and conditions.

9.2 Customer Support

Our dedicated customer service team pledges to respond within 12 hours. If you have any questions, concerns, or require assistance, please do not hesitate to reach out to us. Contact information can typically be found on the product packaging or the official ANCHEER website.

© 2025 ANCHEER. All rights reserved.