Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MIUZZY M245

MIUZZY M245 Cordless Vacuum Cleaner User Manual

Model: M245

Brand: MIUZZY

Introduction

This manual provides comprehensive instructions for the MIUZZY M245 Cordless Vacuum Cleaner, covering assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity. Please read this manual thoroughly before first use and keep it for future reference.



The MIUZZY M245 Cordless Vacuum Cleaner with all included accessories: main unit, extension wand, motorized brush head, crevice tool, dust brush, cleaning tool, and wall mount.

What's Included

Verify that all components are present in the packaging:

- Main Vacuum Cleaner (1)
- Rechargeable Battery (1)
- Fast-charging Adapter (1)
- Anti-tangle Motorized Brush (1)
- Dust Brush (1)
- Long Crevice Tool (1)
- Wall Mount (1)
- Cleaning Tool (1)
- User Manual (1)

Product Features

- **Powerful Suction:** Features 190AW suction power and 48KPa pressure in Max mode for effective cleaning.
- **Extended Runtime:** Equipped with a 4000mAh high-capacity battery, providing up to 60 minutes of runtime in Eco mode, 40 minutes in Mid mode, and 20 minutes in Max mode.
- **Anti-Hair Wrap Technology:** The motorized brush head incorporates a comb-tooth design to minimize hair tangling, making it suitable for homes with pets.
- **Efficient Multi-Cone Filtration:** Utilizes a genuine multi-cone filtration system to maintain suction power and prevent clogs, eliminating the need for a HEPA filter.
- **Large Dustbin & LED Display:** Features a 1.5L dust cup with a one-button release for easy emptying and an LED display for real-time monitoring of suction levels and status.
- **Lightweight & Self-Standing Design:** Lightweight construction allows for easy conversion to a handheld vacuum. The self-standing design enables convenient pausing during cleaning.
- **Brushless Motor:** Powered by a 350W brushless motor for enhanced durability and performance.



The MIUZZY M245 Cordless Vacuum in action, demonstrating its powerful suction on hard floors, effectively picking up debris.



Illustrates the MIUZZY M245's versatile runtime across different power modes: Eco (60 min), Mid (40 min), and Max (20 min), suitable for various cleaning tasks.



Demonstration of the anti-hair wrap technology on the motorized brush head, showing how it prevents hair from tangling, ideal for pet owners.

Setup

1. **Unpack Components:** Carefully remove all items from the packaging and verify against the "What's Included" list.
2. **Charge the Battery:** Before first use, fully charge the rechargeable battery using the provided fast-charging

adapter. The battery can be charged while attached to the main unit or separately. Charging time is approximately 4 hours.

3. **Assemble the Vacuum:**
    - Insert the extension wand into the main vacuum cleaner unit until it clicks securely.
    - Attach the motorized brush head to the other end of the extension wand until it clicks.
    - Alternatively, for handheld use, attach desired accessories (dust brush, long crevice tool) directly to the main vacuum cleaner unit.
4. **Install Wall Mount (Optional):** If desired, install the wall mount in a convenient location using appropriate hardware (not included) to store the vacuum.



The detachable and rechargeable battery can be charged independently or while connected to the vacuum unit.

Operation

1. **Power On/Off:** Press the power button located on the main unit handle to turn the vacuum on or off.
2. **Adjust Suction Mode:** The vacuum has three suction modes: Eco, Mid, and Max. Press the mode selection button (next to the power button) to cycle through the modes. The current mode will be displayed on the LED screen.
    - **Eco Mode:** For light cleaning and maximum battery life (up to 60 minutes).
    - **Mid Mode:** For everyday cleaning (up to 40 minutes).
    - **Max Mode:** For deep cleaning and stubborn debris (up to 20 minutes).
3. **Cleaning Surfaces:**
    - For floors and carpets, use the motorized brush head. The brush head swivels for easy maneuverability around furniture.
    - For upholstery, stairs, or car interiors, detach the extension wand and use the main unit with the dust brush or long crevice tool.
4. **Monitoring Battery and Status:** The LED display provides real-time information on battery level and selected suction mode.



Close-up of the LED display on the MIUZZY M245, providing real-time monitoring of suction levels and operational status.



The MIUZZY M245 Cordless Vacuum's self-standing design, allowing for convenient pausing during cleaning without needing to lean it against a surface.



Showcases the versatility of the MIUZZY M245, easily converting into a handheld vacuum for cleaning upholstery, stairs, and tight spaces using various attachments.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

1. **Emptying the Dustbin:**

- Press the dustbin release button to open the bottom flap and empty debris into a trash can.
- The built-in spring mechanism helps to eject all debris effortlessly.
- Empty the dustbin regularly, especially when it reaches the MAX fill line.

2. **Cleaning the Multi-Cone Filter:**
   - Twist and pull to remove the multi-cone filter assembly from the dustbin.
   - Tap the filter gently to dislodge dust. If necessary, rinse under cool running water.
   - Ensure the filter is completely dry before reinserting it into the dustbin.
3. **Cleaning the Motorized Brush Head:**
   - Periodically check the brush roll for tangled hair or debris.
   - Use the provided cleaning tool to cut and remove any wrapped hair or fibers from the brush roll.
   - Ensure the brush roll spins freely after cleaning.



The built-in spring mechanism in the dustbin automatically scrapes all debris for easy and hygienic emptying.

Diagram detailing the efficient multi-cone filtration system of the MIUZZY M245, designed to maximize suction and prevent clogs without the need for a HEPA filter.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged or not properly installed.	Ensure the battery is fully charged and securely clicked into place.
Low suction power.	Dustbin is full, filter is clogged, or brush roll is obstructed.	Empty the dustbin. Clean the multi-cone filter. Remove any obstructions from the brush roll.
Brush roll not spinning.	Hair or debris tangled around the brush roll.	Turn off the vacuum and remove any tangled hair or debris from the brush roll using the cleaning tool.
Short battery runtime.	Vacuum is used primarily in Max mode, or battery is not fully charged.	Ensure the battery is fully charged before use. Use Eco or Mid mode for longer cleaning sessions.

Specifications

Feature	Detail
Model Name	M245 Cordless Vacuum
Suction Power	190AW / 48KPa (Max mode)
Motor	350W Brushless DC Motor
Battery Capacity	4000mAh (Lithium-ion)
Max Runtime	Up to 60 minutes (Eco mode)
Charging Time	Approx. 4 hours
Dustbin Capacity	1.5 Liters
Filtration Type	Genuine Multi-Cone Filtration (Metal Filter)
Noise Level	63 dB
Item Weight	8 pounds
Product Dimensions	18"L x 7"W x 17"H
Special Features	Anti-Hair Wrap, LED Display, Self-standing Design, 3 Suction Modes

Warranty and Support

MIUZZY is committed to providing quality products and exceptional service.

- **Warranty:** A 24-month warranty is provided on purchases.
- **Refund Policy:** Enjoy a 90-day full refund period.
- **Customer Service:** For any questions, issues, or support needs, please contact MIUZZY customer service. Response times are typically within 4-24 hours.

For further assistance, please refer to the contact information provided on the product packaging or the official MIUZZY website.

© 2025 MIUZZY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4XLTHKG

More documents and user manuals: **https://manuals.plus/**