Aiwa AI6006-WHT-T49-2

AIWA Exos Home Speaker User Manual

Model: AI6006-WHT-T49-2 | Brand: Aiwa

Introduction

The AIWA Exos Home Speaker is a premium 30W RMS sound system designed to deliver an immersive audio experience. It features dual 1-inch tweeters and dual 2-inch bass units with individual amplifiers for unparalleled clarity and rich, resonant lows. This versatile system includes a built-in CD player, FM radio with 20 preset stations, Bluetooth connectivity for wireless streaming, and an optical digital input for enhanced TV sound. An infrared remote control is included for convenient operation.

Setup

1. Unpacking and Placement

Carefully remove all components from the packaging. Ensure the main unit and the remote control are present. Place the speaker on a stable, flat surface, away from direct sunlight, heat sources, and excessive moisture. Allow adequate ventilation around the unit.



Image: The AIWA Exos Home Speaker in white, shown with its accompanying remote control. The speaker features a central display and speaker grilles on either side.

2. Power Connection

Connect the provided power adapter to the DC IN port on the rear of the speaker. Plug the other end of the adapter into a standard wall outlet. Use the Power On/Off switch located on the rear panel to turn the unit on or off.



Image: A close-up of the rear panel of the AIWA Exos Home Speaker, highlighting the Optical Input, Headphones Input, Aux Input, DC IN power port, and the Power On/Off switch.

3. FM Antenna Connection

For optimal FM radio reception, extend the built-in FM antenna wire located at the back of the unit. Position it for the best signal quality.

4. Connecting External Devices

- **Optical Digital Input:** Use an optical cable (not included) to connect the speaker to your TV or other audio source for high-quality digital sound.
- **Auxiliary Input:** Connect devices with a 3.5mm audio output (e.g., MP3 players, smartphones) to the AUX IN port using a 3.5mm audio cable (not included).
- **Headphones Input:** Connect headphones to the dedicated headphone jack for private listening.

Operating Instructions

1. Power On/Off

Press the **POWER** button on the remote control or use the switch on the rear panel to turn the unit on or off.

2. Source Selection

Press the **SOURCE** button on the remote control to cycle through available input modes: CD, Bluetooth, FM Radio, Optical, and AUX.

3. CD Player Operation

1. Press the **OPEN/CLOSE** button on the remote control to open the CD tray.
2. Place a CD (CD-R/RW compatible) gently into the tray with the label side facing up.
3. Press **OPEN/CLOSE** again to close the tray. The unit will automatically begin playing the CD.
4. Use the **PLAY/PAUSE**, **SKIP FORWARD**, and **SKIP BACKWARD** buttons on the remote for playback control.

4. Bluetooth Pairing

1. Select Bluetooth mode using the **SOURCE** button. The display will show "BT" and flash, indicating pairing mode.
2. On your mobile device, enable Bluetooth and search for "AIWA EXOS HOME".
3. Select "AIWA EXOS HOME" to pair. Once connected, the "BT" indicator will stop flashing.
4. You can now stream audio wirelessly from your device.

5. FM Radio Operation

1. Select FM Radio mode using the **SOURCE** button.
2. Press the **SCAN** button on the remote to automatically scan and save available stations to presets.
3. Use the **PRESET +/-** buttons to navigate through saved stations.
4. To manually tune, use the **TUNE +/-** buttons.

6. Remote Control Functions

The included IR remote control provides full functionality for the speaker. Key buttons include:

- **POWER:** Turns the unit on/off.
- **SOURCE:** Selects input mode.
- **VOLUME +/-:** Adjusts volume level.
- **MUTE:** Mutes/unmutes audio.
- **PLAY/PAUSE, SKIP FORWARD/BACKWARD:** CD/Bluetooth playback control.
- **SCAN, PRESET +/-:** FM radio control.
- **DIMMER:** Adjusts display brightness.
- **DISPLAY:** Changes display information.



Image: A detailed view of the AIWA Exos Home Speaker's remote control, showing its various buttons for power, source selection, volume, playback, and radio functions.

Maintenance

1. Cleaning the Unit

Wipe the exterior of the speaker with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. For the display, use a soft, lint-free cloth. Avoid spraying cleaners directly onto the unit.

2. CD Player Care

Handle CDs by their edges to avoid fingerprints and scratches. If a CD is dirty, wipe it gently with a soft, lint-free cloth from the center outwards. Do not use abrasive materials or solvents on CDs. Periodically, you may use a CD lens cleaner disc (not included) to clean the CD player's lens.

3. General Care

To ensure longevity, avoid placing heavy objects on the speaker. Keep the unit away from strong magnetic fields. If the unit will not be used for an extended period, unplug it from the power outlet.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not securely connected; Power switch off; Power outlet not working.	Ensure power cord is firmly plugged into the unit and wall outlet. Check the Power On/Off switch on the rear. Test the outlet with another device.
No sound	Volume too low; Mute function active; Incorrect source selected; Loose audio cables.	Increase volume. Press MUTE on the remote. Select the correct input source. Check all audio cable connections.
CD not playing	CD inserted incorrectly; CD is dirty or scratched; Disc format not supported.	Ensure CD is inserted label-side up. Clean the CD. Try a different CD. The unit supports standard audio CDs (CD-R/RW).

Problem	Possible Cause	Solution
Bluetooth pairing failed	Bluetooth not enabled on device; Device too far; Speaker not in pairing mode.	Ensure Bluetooth is enabled on your device. Move device closer to the speaker. Select Bluetooth source on speaker to enter pairing mode.
Poor FM reception	Antenna not extended or poorly positioned; Interference from other electronics.	Fully extend and reposition the FM antenna. Move the unit away from other electronic devices.
Remote control not working	Batteries are dead or inserted incorrectly; Obstruction between remote and unit; Remote sensor blocked.	Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure the remote sensor on the unit is clear.

Specifications

Feature	Detail
Model Number	AI6006-WHT-T49-2
Power Output	30W RMS
Speaker Configuration	Dual 1" Tweeters + Dual 2" Bass Units
Connectivity	Bluetooth, CD Player, FM Radio, Optical Digital Input, Auxiliary Input (3.5mm)
FM Presets	20 Stations
Dimensions (L x W x H)	17.6 x 6.3 x 11 inches (44.7 x 16 x 27.9 cm)
Item Weight	7.11 pounds (3.23 kg)
Included Accessories	IR Remote Control

Warranty and Support

This AIWA Exos Home Speaker is manufactured by Sakar International. For specific warranty details, please refer to the warranty card included with your product or contact Sakar International directly. Keep your purchase receipt as proof of purchase for any warranty claims.
For technical support or service inquiries, please visit the official Aiwa website or contact their customer service department. Contact information can typically be found on the manufacturer's website or in the product packaging.

© 2025 Aiwa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question