Minthouz GXZ-F96

Minthouz Desk Fan Mini GXZ-F96 User Manual

Model: GXZ-F96

1. Safety Instructions

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the fan or power cord in water or other liquids.
- Keep the fan away from heat sources, direct sunlight, and flammable materials.
- Ensure the power supply voltage matches the specifications of the fan.
- Do not insert fingers or any objects into the fan grille when it is operating.
- Unplug the fan from the power source before cleaning or when not in use for extended periods.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate the fan with a damaged cord or plug. Contact customer support for assistance.

2. Product Overview

The Minthouz Desk Fan Mini GXZ-F96 is a compact and portable fan designed for personal cooling. It features multiple speed settings, oscillation, and a rechargeable battery for cordless operation.

Package Contents:

- Minthouz Desk Fan Mini (GXZ-F96)
- USB-C Charging Cable
- User Manual



Image: The Minthouz Desk Fan Mini GXZ-F96 shown with its retail packaging and included USB-C charging cable.

3. Specifications

Model Number	GXZ-F96
Brand	Minthouz
Dimensions (L x W x H)	11.8 x 9.5 x 17 cm (4.65 x 3.77 x 6.69 inches)
Item Weight	440 g
Power/Wattage	5 watts
Voltage	5 Volts (DC)
Material	Plastic

Number of Speeds	3
Noise Level	45 Decibels
Special Features	Adjustable Tilt, Oscillation
Battery Capacity	2000 mAh



Image: The physical dimensions of the Minthouz Desk Fan Mini, measuring 11.8 cm (4.65 in) in width, 9.58 cm (3.77 in) in depth, and 17 cm (6.69 in) in height.



Image: The Minthouz Desk Fan Mini operating, highlighting its ultra-quiet performance with a noise level of 45 decibels.

4. Setup

4.1 Charging the Fan

Before first use, fully charge the fan. The fan is equipped with a 2000 mAh rechargeable battery.

1. Connect the provided USB-C charging cable to the charging port on the back of the fan.
2. Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a computer USB port.
3. The charging indicator light will illuminate (color may vary) to show that the fan is charging.
4. Once fully charged, the indicator light will change or turn off. A full charge can provide up to 10.5 hours of operation on the lowest setting.



Image: The Minthouz Desk Fan Mini being charged via its Type-C interface, connected to a wall adapter. The image also highlights the 2000 mAh battery capacity.

4.2 Placement

Place the fan on a stable, flat surface. Ensure there are no obstructions to the airflow at the front or back of the fan.

5. Operating Instructions

5.1 Power On/Off and Speed Adjustment

The fan features a single control button located on the base.

1. **To Power On:** Press the control button once. The fan will start at Level 1 (low speed).
2. **To Adjust Speed:** Press the button repeatedly to cycle through the speed settings: Level 1 (2.0 m/s), Level 2 (2.8 m/s), Level 3 (3.5 m/s).
3. **To Power Off:** After Level 3, pressing the button again will turn the fan off.



Image: The Minthouz Desk Fan Mini demonstrating its 3-level airflow adjustment: Level 1 (2.0 m/s), Level 2 (2.8 m/s), and Level 3 (3.5 m/s), providing a natural breeze.

5.2 Oscillation Function

The fan offers an automatic wide-angle oscillation feature.

- **To Activate Oscillation:** Double-press the control button while the fan is running. The fan head will begin to swing automatically.
- **To Deactivate Oscillation:** Double-press the control button again. The fan head will stop oscillating.

5.3 Manual Tilt Adjustment

The fan head can be manually adjusted up and down to direct airflow.

- Gently hold the fan head and tilt it to your desired angle. The fan allows for a manual tilt adjustment of up to 15 degrees.



Image: The Minthouz Desk Fan Mini illustrating its wide-angle automatic oscillation (90 degrees) and manual up-and-down tilt adjustment (15 degrees).

6. Maintenance

Regular cleaning helps maintain the fan's performance and extends its lifespan.

- **Before Cleaning:** Always ensure the fan is turned off and unplugged from any power source.
- **Cleaning the Exterior:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Cleaning the Fan Grille/Blades:** Use a soft brush or a vacuum cleaner with a brush attachment to gently remove dust from the front and rear grilles and fan blades. Do not attempt to disassemble the fan for cleaning.
- **Storage:** When not in use, store the fan in a cool, dry place, away from direct sunlight and moisture.

7. Troubleshooting

If you encounter issues with your Minthouz Desk Fan Mini, please refer to the following common problems and solutions:

- **Fan does not turn on:**
  - Ensure the fan is charged. Connect it to a power source using the USB-C cable.
  - Verify the USB-C cable and power adapter are working correctly.
  - Press the power button firmly.
- **Weak airflow:**
  - Check the fan speed setting and increase it if necessary.
  - Ensure the fan grilles are not obstructed by dust or other objects. Clean if needed.
  - Confirm the fan is placed in an open area, not against a wall or other large object.
- **Fan does not oscillate:**
  - Double-press the control button to activate the oscillation function.
  - Ensure the fan is on a stable, level surface.
- **Charging issues:**
  - Ensure the USB-C cable is securely connected to both the fan and the power source.
  - Try a different USB-C cable or power adapter to rule out faulty accessories.
  - Confirm the power source is active.

If the problem persists after trying these solutions, please contact Minthouz customer support.

8. Warranty and Support

Minthouz products are designed and manufactured to the highest quality standards. This product is covered by a limited warranty from the date of purchase. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Minthouz website.

For technical support, troubleshooting assistance, or warranty claims, please contact Minthouz customer service through the contact information provided on the official website or your purchase platform.

Please have your model number (GXZ-F96) and proof of purchase ready when contacting support.

© 2025 Minthouz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question