Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GreenPan CC006004-001

GreenPan Bistro 12-inch Round Electric Skillet User Manual

Model: CC006004-001

1. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before operating the appliance.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse the temperature control probe, cord, or plug in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "OFF", then remove plug from wall outlet.
13. Do not use appliance for other than intended use.
14. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

2. Product Overview & Components

The GreenPan Bistro Electric Skillet is a versatile 6-in-1 multifunction pan designed for various cooking tasks. It features a durable, PFAS-free ceramic nonstick coating and a built-in heating element for efficient cooking.



Image: GreenPan Bistro Electric Skillet highlighting its key features including the glass lid, carrying handles, detachable temperature dial, and nonstick surface.

Included Components:

- Electric Skillet (12-inch, 3.3QT capacity)
- Tempered Glass Lid
- Detachable Temperature Control Probe/Cord

Key Features:

- **6-in-1 Multifunction:** Fry, Sauté, Steam, Simmer, Sear, Stir-Fry.
- **PFAS-Free Ceramic Nonstick:** Diamond-infused Thermolon Volt coating for durability and easy cleaning.
- **Built-in Heating Element:** Ensures quick and even heat distribution.

- **Detachable Temperature Dial:** Provides precise temperature control from 195°F to 450°F.
- **Easy Carrying Handles:** For safe and convenient transport.
- **Tempered Glass Lid:** Allows monitoring of cooking progress without releasing heat.

3. Setup

1. **Unpack:** Carefully remove all packaging materials and any promotional labels from the skillet and its components.
2. **Initial Cleaning:** Before first use, wash the skillet bowl and glass lid with warm, soapy water. Rinse thoroughly and dry completely. Do NOT immerse the temperature control probe or cord in water.
3. **Assemble:** Insert the detachable temperature control probe firmly into the receptacle on the side of the skillet. Ensure it clicks securely into place.
4. **Placement:** Place the electric skillet on a stable, heat-resistant, and dry surface away from the edge of the counter. Ensure there is adequate clearance around the appliance for ventilation.

4. Operating Instructions

4.1 Connecting to Power & Setting Temperature

1. Ensure the temperature control probe is securely inserted into the skillet.
2. Plug the power cord into a standard 120V AC electrical outlet.
3. Turn the temperature dial to your desired setting. The indicator light will illuminate, signaling that the skillet is heating.
4. Allow the skillet to preheat for 5-10 minutes, or until the indicator light turns off, indicating the set temperature has been reached. The light will cycle on and off during cooking to maintain the temperature.



Image: Detailed view of the detachable temperature dial, showing settings from 195°F to 450°F and an 'OFF' position.

4.2 Cooking Functions

The GreenPan Bistro Electric Skillet offers a variety of cooking methods:



Image: Visual guide to the 6-in-1 cooking capabilities of the skillet, including frying eggs and bacon, sautéing vegetables, steaming, simmering, searing meats, and stir-frying.

- **Frying:** Ideal for eggs, bacon, and other breakfast items. Use a medium heat setting (e.g., 300-350°F).
- **Sautéing:** Perfect for vegetables, onions, and garlic. Use a medium-high heat setting (e.g., 350-400°F).
- **Steaming:** Add a small amount of liquid and use the glass lid to steam vegetables or dumplings. Use a medium heat setting (e.g., 250-300°F).
- **Simmering:** Great for sauces, stews, and braising. Use a low heat setting (e.g., 195-250°F).
- **Searing:** Achieve a perfect crust on meats like steaks or pork chops. Use a high heat setting (e.g., 400-450°F).
- **Stir-Frying:** Cook ingredients quickly at high temperatures. Use a high heat setting (e.g., 400-450°F).

Always use heat-resistant nylon, silicone, or wooden utensils to protect the nonstick surface.

4.3 Using the Glass Lid

The tempered glass lid helps to retain heat and moisture, allowing you to simmer, steam, and braise effectively. It also allows you to monitor your food without lifting the lid, preserving cooking temperatures.



Image: The electric skillet with its tempered glass lid in place, demonstrating its use for cooking and retaining heat.

5. Maintenance and Cleaning

1. **Disconnect Power:** Always unplug the skillet from the electrical outlet and remove the temperature control probe before cleaning.
2. **Cool Down:** Allow the skillet to cool completely before attempting to clean it.
3. **Cleaning the Skillet Bowl:** The skillet bowl (without the probe) is dishwasher safe. For hand washing, use warm, soapy water and a soft sponge or cloth. Avoid abrasive cleaners, scouring pads, or metal utensils that can damage the nonstick coating.
4. **Cleaning the Glass Lid:** The glass lid is also dishwasher safe. For hand washing, use warm, soapy water and a soft sponge.
5. **Cleaning the Temperature Control Probe:** Wipe the temperature control probe with a damp cloth. Do NOT immerse it in water or any other liquid.

6. **Storage:** Ensure all parts are completely dry before storing. Store the skillet and its components in a dry place.



Image: A person hand-washing the skillet bowl, demonstrating its easy-to-clean nonstick surface.

6. Troubleshooting

Problem	Possible Cause	Solution
Skillet does not heat up.	Power cord not plugged in; temperature probe not fully inserted; outlet malfunction.	Ensure cord is securely plugged into a working outlet. Check that the temperature probe is fully inserted into the skillet. Test the outlet with another appliance.
Food is sticking to the surface.	Insufficient oil/fat; heat setting too high; nonstick coating wear.	Use a small amount of cooking oil or butter. Reduce heat setting. Ensure proper cleaning and avoid metal utensils.
Temperature indicator light is not working.	Faulty temperature probe; electrical issue.	Ensure the probe is correctly inserted. If the skillet heats but the light doesn't work, contact customer support. If it doesn't heat at all, refer to 'Skillet does not heat up'.
Skillet smokes excessively.	Excessive oil/fat; food residue; heat setting too high.	Reduce the amount of oil. Clean the skillet thoroughly after each use. Lower the temperature setting.

7. Specifications

- **Model Number:** CC006004-001
- **UPC:** 885837049503
- **Capacity:** 3.3 Quarts
- **Diameter:** 12 inches
- **Material:** Ceramic (nonstick coating), Glass (lid), Stainless Steel (body)
- **Color:** Stainless Steel

- **Wattage:** 1800 watts
- **Temperature Range:** 195°F – 450°F
- **Product Dimensions (D x W x H):** 12"D x 14"W x 4.5"H
- **Item Weight:** 7.7 pounds
- **Special Features:** Non Stick Coating, Temperature Control

8. Warranty and Support

GreenPan products are manufactured to high-quality standards. For warranty information, product registration, or customer support, please visit the official GreenPan website or contact their customer service department.

You can find more information and support by visiting theGreenPan Store on Amazon.

© 2023 GreenPan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F5B9QBFQ

More documents and user manuals: **https://manuals.plus/**