Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QT32HGF9A-BP320HSG9800

ALLIMITY Voice Remote Control User Manual

Compatible with EKO, Blaupunkt, Q.BELL TVs

1. Introduction

This user manual provides detailed instructions for the ALLIMITY Voice Remote Control, designed for seamless compatibility with various EKO, Blaupunkt, and Q.BELL TV models. Please read this manual carefully before using the remote control to ensure proper operation and longevity.

2. Product Overview

The ALLIMITY Voice Remote Control is an ergonomically designed, lightweight, and fully functional replacement or spare remote for your compatible television. It offers stable performance and a long transmission distance.



Figure 2.1: Front view of the ALLIMITY Voice Remote Control, showing all buttons including power, volume, channel, navigation, voice assistant, and dedicated app buttons for YouTube, Netflix, Prime Video, and Disney+.



Figure 2.2: Close-up of the voice assistant button, highlighted to show its position and icon, indicating voice control functionality.



Figure 2.3: Side view of the remote control, illustrating its ergonomic profile and compact dimensions (14.5 cm / 5.71 in length, 4 cm / 1.57 in width).

Package Contents:

- 1 x ALLIMITY Voice Remote Control
- (Batteries not included)

3. Setup

3.1 Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery cover by sliding it back into place until it clicks securely.

3.2 Pairing (If Applicable)

This remote control is designed for immediate use with compatible models without requiring programming or complex setup. Simply insert batteries and point it towards your TV.
For voice control functionality, ensure your TV supports voice commands and is properly connected to the internet. Refer to your TV's user manual for specific instructions on enabling voice control and pairing Bluetooth devices, if necessary.

4. Operating Instructions

The ALLIMITY Voice Remote Control provides intuitive access to all standard TV functions and dedicated smart features.

4.1 Button Functions

Button	Function
Power ( )	Turns the TV on or off.
Mute ( )	Mutes or unmutes the TV sound.
Voice Assistant ( )	Activates the TV's voice assistant for commands and search.
Settings (⚙)	Opens the TV's settings menu.
Navigation Ring (Up, Down, Left, Right, OK)	Navigates through menus and selects options.
Back (←)	Returns to the previous screen or menu.
Home (⌂)	Goes to the TV's home screen or smart hub.
Input/Source ( )	Changes the TV input source (HDMI, AV, etc.).
Volume Up/Down (VOL +/-)	Adjusts the TV volume.
Channel Up/Down (CH +/-)	Changes TV channels.
123.	Accesses the numeric keypad for direct channel input or other numeric functions.
MENU	Opens the TV's main menu.
YouTube	Direct access to the YouTube application.
Netflix	Direct access to the Netflix application.
Prime Video	Direct access to the Amazon Prime Video application.
Disney+	Direct access to the Disney+ application.

4.2 Using Voice Control

To use the voice control feature, press and hold the Voice Assistant button () and speak clearly into the microphone located on the remote. Release the button when you are finished speaking. Ensure your TV is connected to the internet and voice control is enabled in its settings.

5. Maintenance

5.1 Cleaning the Remote Control

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray cleaner directly onto the remote.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote's performance degrades (e.g., reduced range, unresponsive buttons). Always replace both batteries at the same time with new ones of the same type (AAA). Dispose of used batteries according to local regulations.

6. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries, ensuring correct polarity (+/-).
Remote range is poor.	Weak batteries; obstruction between remote and TV; infrared sensor on TV is blocked.	Replace batteries. Ensure a clear line of sight to the TV's IR sensor. Remove any obstructions.
Voice control not working.	TV not connected to internet; voice control not enabled on TV; remote not paired (if required by TV).	Check TV's internet connection. Enable voice control in TV settings. Refer to TV manual for pairing instructions.
Specific buttons not working.	Button stuck or damaged; remote not fully compatible with all TV functions.	Gently press the button multiple times. Verify your TV model is listed as compatible.

7. Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	QT32HGF9A-BP320HSG9800
Compatible Devices	QT32HGF9A, BP320HSG9800, BP240HSG9800, BP400FSG9800, BP550USG9, BP650USG9, BP500USG9800K320UGT, K400UGT, K550UGT, K320HGT, K32HGT (EKO, Blaupunkt, Q.BELL TVs)
Connectivity Technology	Infrared (IR)
Special Feature	Ergonomic, Voice Control
Maximum Range	10 Meters

Feature	Detail
Dimensions (L x W x H)	17 x 5 x 1 cm (approx. 6.7 x 2 x 0.4 inches)
Weight	59 grams (approx. 2.1 ounces)
Batteries Required	2 x AAA (not included)

8. Warranty and Support

For any issues or inquiries regarding your ALLIMITY Voice Remote Control, please contact the seller or refer to the product listing on Amazon for support information.
This product is designed to be a direct replacement and is typically covered by standard consumer guarantees as per local regulations. Please retain your proof of purchase for any warranty claims.
Seller: ZHICHENGMAO
Amazon Product Link: Product Page

© 2025 ALLIMITY. All rights reserved.
Manual Version: 1.0

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F5HD843F

More documents and user manuals: **https://manuals.plus/**