Elevon GYJ40-88

Elevon 800W Portable Clothes Dryer User Manual

Model: GYJ40-88

1. Introduction

Thank you for choosing the Elevon 800W Portable Clothes Dryer. This compact and efficient electric drying machine is designed to provide convenient laundry solutions for apartments, RVs, dorms, and other small living spaces. Featuring a durable stainless steel tub and multiple drying modes, it ensures your clothes are dried effectively and gently. Please read this manual thoroughly before operation to ensure safe and optimal performance of your new dryer.



Figure 1.1: Front view of the Elevon Portable Clothes Dryer.

2. Important Safety Information

To reduce the risk of fire, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Do not dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances, as they emit vapors that could ignite or explode.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Before the appliance is removed from service or discarded, remove the door to the drying compartment.
- Do not reach into the appliance if the drum is moving.

- Do not install or store this appliance where it will be exposed to the weather.
- Do not tamper with controls.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in this user-maintenance instructions or in published user-repair instructions that you understand and have the skills to carry out.
- Do not use fabric softeners or products to eliminate static unless recommended by the manufacturer of the fabric softener or product.
- Do not use heat to dry articles containing foam rubber or similarly textured rubber-like materials.
- Clean lint screen before or after each load.
- Do not allow lint to accumulate around the dryer.
- Do not operate the dryer with missing or damaged parts.
- Do not obstruct the flow of ventilation air.
- The interior of the appliance and exhaust duct should be cleaned periodically by qualified service personnel.
- Do not place items exposed to cooking oils in your dryer. Items contaminated with cooking oils may contribute to a chemical reaction that could cause a load to catch fire.
- Always contact the manufacturer for any issues or repairs.

3. Product Overview

3.1 Components

The Elevon Portable Clothes Dryer features a robust design with key components for efficient drying:

- **Stainless Steel Inner Drum:** Reduces wear and tear on clothes and ensures even heat distribution.
- **Control Panel:** Simple rotary dial for selecting drying modes and time.
- **Door:** Features a 170° opening angle for easy loading and unloading. Automatic stop function when opened.
- **Outlet Filter:** Collects lint and debris, requiring regular cleaning.
- **Exhaust Pipe:** For venting hot, moist air.
- **Adjustable Feet:** For leveling the dryer on uneven surfaces.



Figure 3.1: Key components of the dryer.

3.2 Dimensions and Capacity

This compact dryer is designed to fit into various small spaces while offering a generous drying capacity.

- **Dimensions (L x W x H):** 19.29" x 18.11" x 23.43"
- **Capacity:** 2.6 cubic feet



Figure 3.2: Compact size and versatile placement options.

4. Setup and Installation

The Elevon Portable Clothes Dryer offers flexible installation options to suit your living space:

- **Freestanding:** Place the dryer on a stable, level surface. Ensure adequate clearance around the unit for ventilation.
- **Wall-mounted:** A bracket is included for wall mounting. Follow the detailed instructions provided with the mounting kit for secure installation.
- **Stacking:** The dryer can be stacked on top of a compatible washing machine. Ensure the washing machine is stable and capable of supporting the dryer's weight.
- **Side-by-side:** Place the dryer next to a washing machine or other appliance.

Regardless of the installation method, ensure the dryer is connected to a proper power outlet and the exhaust pipe is correctly vented to allow hot air to escape.



Figure 4.1: Multiple mounting options for flexible placement.

5. Operating Instructions

5.1 Loading the Dryer

- Open the dryer door (170° opening angle for easy access).
- Load clothes loosely into the stainless steel drum. Do not overload the dryer, as this can reduce drying efficiency and cause wrinkles.
- Close the door securely. The dryer will automatically stop if the door is opened during operation.



Figure 5.1: Easy loading with wide door opening.

5.2 Selecting Drying Modes and Time

The dryer offers multiple drying modes to cater to different fabric types and laundry sizes. Use the rotary dial on the control panel to select your desired setting.

Mode	Approximate Time	Description
Cool Down	0-20 mins	Used to cool down clothes after a heated cycle, reducing wrinkles.
Anti-Wrinkle	30-60 mins	Helps prevent wrinkles by tumbling clothes without heat.
Air Dry	0-80 mins	Dries clothes using ambient air, suitable for delicate items.
Warm	60-150 mins	Standard drying for most fabrics.
Hot	150-200 mins	For heavier fabrics or larger loads requiring more heat.



Figure 5.2: Control panel and drying mode guide.

5.3 Reference for Drying Pieces

The following table provides a general reference for the number of pieces you can dry per load:

Item Type	Approximate Quantity
T-shirts	10
Towels	20
Sweaters	4
Quilt Covers	1



Figure 5.3: Drying capacity reference.

6. Maintenance

Regular maintenance ensures the longevity and efficient operation of your dryer.

6.1 Cleaning the Lint Filter

The dryer features a multi-filtration system to capture lint. It is crucial to clean the lint filter before or after each load to maintain optimal drying performance and prevent fire hazards.

- Locate the lint filter, typically inside the dryer door opening or at the back of the drum.
- Remove the filter and gently pull off any accumulated lint.
- For thorough cleaning, you can use a soft brush or a vacuum cleaner to remove fine dust and debris from the filter components (air inlet filter, inner cylinder filter, air outlet filter).
- Reinsert the clean filter securely before operating the dryer.



Figure 6.1: Multi-filtration system for lint collection.

6.2 Exterior Cleaning

Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.

7. Troubleshooting

If you encounter issues with your dryer, refer to the following table for common problems and solutions. If the problem persists, please contact customer support.

Problem	Possible Cause	Solution
Dryer does not start	Not plugged in; Door not closed properly; Power outage.	Ensure power cord is securely plugged in; Close door firmly; Check household circuit breaker.
Clothes not drying completely	Lint filter clogged; Overloaded dryer; Incorrect drying mode selected; Poor ventilation.	Clean lint filter; Reduce load size; Select appropriate drying mode; Ensure exhaust vent is clear.
Dryer is noisy	Dryer not level; Foreign object in drum; Loose parts.	Adjust leveling feet; Check drum for small items; Contact customer support if noise persists.
Dryer stops during cycle	Door opened; Overheating.	Ensure door is closed; Allow dryer to cool down, check for blocked vents.

The working noise of the clothes dryer is typically 58-62dB, which is considered low and should not affect normal conversation or sleep.

8. Specifications

Feature	Detail
Brand	Elevon
Model Number	GYJ40-88
Power	800W
Capacity	2.6 Cubic Feet
Item Weight	37.5 pounds
Package Dimensions	25.98 x 23.03 x 19.69 inches
Material	Stainless Steel, Plastic
Color	White
Certification	ETL
Noise Level	58-62dB
Door Opening Angle	170°

9. Warranty and Support

9.1 Warranty Information

This Elevon Portable Clothes Dryer comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accident, unauthorized repair, or normal wear and tear.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Elevon Portable Clothes Dryer, please contact our customer support team. Have your model number (GYJ40-88) and purchase date ready when contacting support. *Contact information for customer support is typically found on the product packaging, official website, or purchase receipt.*

© 2025 Elevon. All rights reserved.