Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE G00-B

XINFUTE G00-B TV Remote Control User Manual

Model: G00-B | Brand: XINFUTE

1. Introduction

Thank you for choosing the XINFUTE G00-B TV Remote Control. This manual provides comprehensive instructions for setting up, operating, and maintaining your new remote control. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

This remote control is designed to be compatible with various LED TV models, including specific BGH, TELEFUNKEN, and Kodak units. It is an original replacement unit, ensuring seamless compatibility and functionality.

2. Product Overview

The XINFUTE G00-B is a high-quality replacement remote control made from durable ABS material. It is designed for ease of use and provides all essential functions for controlling your compatible television.

Key Features:

- Direct compatibility with B5020UK6 C00-T, TKLE3218RTX, TKLE4918RTUX, TKLE4318RTFX, and other specified models.
- Ergonomic design for comfortable handling.
- No programming required; ready to use after battery installation.
- Durable ABS material construction.

Product Images:



Figure 2.1: Front view of the XINFUTE G00-B TV Remote Control, showing all buttons including power, input, number pad, navigation, volume, channel, and dedicated app buttons.



Figure 2.2: Side profile of the XINFUTE G00-B TV Remote Control, highlighting its slim and ergonomic design.



Figure 2.3: Back view of the XINFUTE G00-B TV Remote Control with the battery cover removed, showing the battery compartment for two AAA batteries.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.

Important: Batteries are not included with the remote control. Please use new, high-quality AAA batteries for best performance.

3.2 Initial Use (No Programming Required)

The XINFUTE G00-B remote control is designed for immediate use with compatible TV models. No complex programming or code entry is required. Simply insert the batteries, point the remote at your TV, and begin using it.

4. Operating Instructions

This remote control provides standard functions for your television. Ensure there is a clear line of sight between the remote control's infrared emitter and your TV's IR receiver.

Common Button Functions:

- **Power (Red Button):** Turns the TV on or off.
- **INPUT:** Cycles through available input sources (HDMI, AV, etc.).
- **Number Pad (0-9):** Directly enters channel numbers.
- **CH RTN:** Returns to the previously viewed channel.
- **LIST:** Displays a list of channels or programs.
- **HOME:** Accesses the TV's smart home screen or main menu.
- **NETFLIX** / **YouTube:** Dedicated buttons for quick access to these streaming services.
- **MENU:** Opens the TV's main settings menu.
- **Q.MENU:** Accesses quick settings or a shortcut menu.
- **Navigation Buttons (Up, Down, Left, Right, OK/Center):** Used to navigate menus and confirm selections.
- **BACK:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or application.
- **VOL +/-:** Adjusts the volume level.
- **CH ^/v:** Changes the channel up or down.
- **Mute:** Mutes or unmutes the TV sound.
- **GUIDE:** Displays the electronic program guide (EPG).
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop):** Controls media playback.
- **INFO:** Displays information about the current program or input.
- **PICTURE:** Accesses picture settings.
- **SOUND:** Accesses sound settings.
- **C/SUBTITLE:** Toggles closed captions or subtitles.
- **MTS/AUDIO:** Selects audio tracks or MTS (Multi-channel Television Sound) options.

5. Maintenance

5.1 Cleaning

To clean your remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's surface or internal components.

5.2 Battery Care and Storage

- If the remote control will not be used for an extended period (e.g., one month or more), remove the batteries to prevent leakage and potential damage to the remote.

- Store the remote control in a cool, dry place, away from direct sunlight and extreme temperatures.
- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries responsibly according to local regulations.

6. Troubleshooting

Remote Control Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh batteries if necessary.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared receiver.
- **Distance:** Ensure you are within the effective operating range of the remote control.
- **TV Compatibility:** Verify that your TV model is listed as compatible with this remote control. While this remote is designed for broad compatibility, some specific TV models may not be fully supported.

If the issue persists after trying these steps, please refer to the Warranty and Support section for further assistance.

7. Specifications

Feature	Specification
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Batteries Required	2 x AAA batteries (not included)
Connectivity Technology	Infrared (IR)
Compatible Devices	Television (BGH, TELEFUNKEN, Kodak LED TV models: B5020UK6 C00-T, TKLE3218RTX, TKLE4918RTUX, TKLE4318RTFX)
Max Number of Supported Devices	1
Special Features	Ergonomic, No Programming Required

8. Warranty and Support

8.1 Warranty Information

This XINFUTE remote control comes with a**one-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

8.2 Customer Support

All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact the seller within 24 hours of receiving your product. For warranty claims or technical assistance, please reach out to XINFUTE customer support through the platform where you made your purchase.

Please have your order number and product model (G00-B) ready when contacting support to facilitate a quicker resolution.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F5Q2SBBN

More documents and user manuals: **https://manuals.plus/**