Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HCDZ Replacement Remote Control (Compatible with 7015B / 7023B)

HCDZ Replacement Remote Control User Manual

For CAMECHO, UTUT, QOOK, iMars, EKAT 7015B & 7023B Touch Screen Car Stereos

1. Introduction

Thank you for choosing the HCDZ Replacement Remote Control. This manual provides essential information for the proper setup, operation, and maintenance of your remote control. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product. This remote is designed as a direct replacement for various car stereo models, including CAMECHO, UTUT, QOOK, iMars, and EKAT 7015B and 7023B touch screen car stereos.

2. Product Overview

The HCDZ Replacement Remote Control provides convenient access to the functions of your compatible car stereo. Below is an image of the remote with a description of its buttons.



Figure 1: HCDZ Replacement Remote Control. This image displays the black remote control with teal-colored buttons featuring white labels and numbers. Key buttons include Power, Mode, USB/SD, Band/AMS, Volume controls, Select, Enter/Play/Pause, track navigation, menu, number pad (0-9), and call answer/end buttons.

Button Functions:

- **Power Button** (**G**): Turns the car stereo on or off.
- **MODE**: Cycles through available input sources (e.g., Radio, USB, SD, Bluetooth, AUX).
- **USB/SD**: Selects USB or SD card as the audio source.
- **BAND/AMS**: In radio mode, cycles through radio bands (FM1, FM2, FM3, AM1, AM2) or performs automatic memory scan.
- **VOL-** / **VOL+**: Decreases or increases the volume level.
- **SEL (Select)**: Enters menu options or confirms selections.
- **ENT (Enter)** / **Play/Pause** (►II): Confirms selections or plays/pauses media playback.
- **Previous Track** (K◄): Skips to the beginning of the current track or the previous track.
- **Next Track** (►►I): Skips to the next track.
- **Arrow Buttons** (Up, Down, Left, Right): Navigates through menus or adjusts settings.
- **MENU**: Accesses the main menu or settings.
- **Number Buttons (0-9)**: Direct input for radio station frequencies, track numbers, or other numerical selections.
- **Call/Answer Button** ( ): Answers an incoming call or initiates a call (if supported by the car stereo).

- **End Call/Reject Button** ( ): Ends an active call or rejects an incoming call.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert **one (1) AAA battery**, ensuring the correct polarity (+ and -) as indicated inside the compartment. *Note: Batteries are not included with the remote control.*
4. Close the battery compartment cover securely.

3.2 Initial Use

This HCDZ Replacement Remote Control requires **no programming**. Once new batteries are correctly inserted, it will work immediately with compatible car stereo models.

4. Operating Instructions

To operate your car stereo using the remote control, point the remote directly at the IR sensor of your car stereo. Ensure there are no obstructions between the remote and the stereo.

- **Power On/Off:** Press the **Power Button**.
- **Adjust Volume:** Use the **VOL+** and **VOL-** buttons.
- **Change Source/Mode:** Press the **MODE** button repeatedly to cycle through available inputs (e.g., Radio, USB, SD, Bluetooth).
- **Navigate Menus:** Use the **Arrow Buttons** to move through menu options. Press **SEL** or **ENT** to confirm a selection.
- **Radio Functions:**
  - Press **BAND/AMS** to change radio bands.
  - Use the **Arrow Buttons** or **Number Buttons** for station tuning or preset selection.
- **Media Playback (USB/SD):**
  - Press **USB/SD** to select the source.
  - Use **K◄** and **►►I** to skip tracks.
  - Press **►II** to play or pause.
- **Bluetooth Call Functions:**
  - Press the **Call/Answer Button** to answer an incoming call.
  - Press the **End Call/Reject Button** to end or reject a call.

5. Maintenance

5.1 Battery Replacement

When the remote control's range decreases or buttons become unresponsive, it is time to replace the AAA battery. Always replace with a new battery; do not mix new and old batteries.

5.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the

surface or internal components.

5.3 Storage and Precautions

- Do not leave the remote control in an extremely hot or humid place.
- Do not expose the remote sensor to direct sunlight or strong lighting, as this may cause malfunction.
- If you do not use the remote for an extended period, remove the batteries to prevent possible damage from leakage and corrosion.

6. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote control malfunctions:** Replace the remote control batteries.
- **Remote not responding:** Check battery terminals to ensure they are clean and making proper contact.
- **Limited range or intermittent response:** The remote may be out of range. Move closer to the car stereo.
- **No response from stereo:** Remove any obstructions between the remote control and the IR sensor of the car stereo.
- **Stereo not responding to any input:** Make sure the power cord to your car stereo is plugged in and the stereo is turned on.

7. Specifications

- **Brand:** HCDZ
- **Compatible Devices:** Car Stereo (CAMECHO, UTUT, QOOK, iMars, EKAT 7015B, 7023B)
- **Batteries Required:** 1 x AAA (not included)
- **Special Feature:** No Programming Required
- **Color:** Black
- **Max Number of Supported Devices:** 1

8. Warranty and Support

No specific warranty information is provided for this replacement remote control. For any issues not covered in this manual or for further assistance, please contact the seller or your point of purchase directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F62F4XJW

More documents and user manuals: **https://manuals.plus/**