Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE SHWRMC0121

XINFUTE SHW/RMC/0121 Remote Control User Manual

For Sharp Aquos HD LCD LED TVs with Freeview Play

Introduction

Welcome to the user manual for your new XINFUTE SHW/RMC/0121 replacement remote control. This manual provides essential information on how to set up, operate, and maintain your remote control for Sharp Aquos HD LCD LED TVs with Freeview Play functionality. Please read these instructions carefully to ensure optimal performance and longevity of your device.

Product Overview

The XINFUTE SHW/RMC/0121 is a replacement remote control designed to be compatible with various Sharp Aquos HD LCD LED TV models. It features an ergonomic design and requires no programming, functioning immediately upon battery installation.



Figure 1: Front view of the XINFUTE SHW/RMC/0121 remote control. This image displays the full layout of the remote control, including the power button, number pad, volume and channel controls, navigation buttons, and dedicated buttons for Freeview Play, Netflix, YouTube, and other applications. The remote has a brushed silver finish with grey buttons.

Setup: Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Note: Batteries are not included with the remote control. Always use new batteries for optimal performance.



Figure 2: Back view of the remote control with the battery compartment open. This image shows the location for inserting two AAA 1.5V batteries, with clear markings for positive and negative terminals. The battery cover is shown detached.

Operating Instructions

This remote control is designed for immediate use with compatible Sharp Aquos HD LCD LED TVs. No programming or pairing is required. Simply insert the batteries, point the remote at your TV, and begin operation.

Basic Functions:

- **ON/OFF (Power)**: Turns the TV on or off.
- **Number Buttons (0-9)**: Selects TV channels directly.
- **VOL +/-**: Adjusts the volume level.
- **CH +/-**: Changes TV channels sequentially.
- **SOURCE**: Selects input sources (HDMI, AV, etc.).
- **MENU**: Accesses the TV's main menu.
- **OK / Navigation Arrows**: Navigates through menus and confirms selections.
- **EXIT**: Exits the current menu or function.
- **BACK**: Returns to the previous screen or menu.

Special Function Buttons:

- **Freeview Play**: Direct access to Freeview Play services.
- **TV GUIDE**: Displays the electronic program guide.
- **INFO**: Shows information about the current program.
- **TEXT**: Accesses teletext services.
- **SUBTITLE**: Toggles subtitles on or off.
- **FAV**: Accesses favorite channels list.
- **NETFLIX**: Direct access to the Netflix application.
- **YouTube**: Direct access to the YouTube application.
- **APPS**: Opens the TV's applications menu.
- **PVR Menu / REC LIST / GOTO? / REC**: Controls for Personal Video Recorder functions (if supported by your TV).
- **Media Playback Controls** (Play, Pause, Stop, Fast Forward, Rewind, Skip): Controls for media playback.
- **Colored Buttons** (Red, Green, Yellow, Blue): Functionality varies depending on the TV menu or application.

Compatible Models

This remote control is compatible with the following Sharp Aquos HD LCD LED TV models:

- LC32HG5141KF
- LC-32HG5141KF
- LC32HG5142KF
- LC-32HG5142KF
- LC32HG5151KF
- LC-32HG5151KF
- LC32HG5152KF
- LC-32HG5152KF
- LC32HG5341KF
- LC-32HG5341KF

This list may not be exhaustive. If your TV model is not listed but is a Sharp Aquos HD LCD LED TV with Freeview Play, the remote may still be compatible.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Environment:** Avoid exposing the remote control to extreme temperatures, direct sunlight, moisture, or dust.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote control is not working.	• Dead or incorrectly inserted batteries. • Obstruction between remote and TV. • Remote control sensor on TV is blocked.	• Replace batteries with new AAA batteries, ensuring correct polarity. • Ensure a clear line of sight between the remote and the TV's infrared sensor. • Check if anything is blocking the TV's remote sensor.
Remote control works intermittently.	• Low battery power. • Interference from other electronic devices.	• Replace batteries. • Move other electronic devices away from the TV or remote.

Specifications

- **Model Number:** SHWRMC0121
- **Brand:** XINFUTE
- **Material:** ABS Material
- **Color:** As Shown (typically silver/grey)
- **Connectivity Technology:** Infrared
- **Compatible Devices:** Television (Sharp Aquos HD LCD LED TVs)
- **Max Number of Supported Devices:** 1
- **Special Features:** Ergonomic, No Programming Required
- **Batteries Required:** 2 x AAA 1.5V (not included)
- **Product Dimensions:** 6 x 3 x 1 inches (approximately)
- **Item Weight:** 2.82 ounces (approximately)

Warranty and Support

Warranty: This product comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.
Support: For any issues, questions, or support inquiries regarding your XINFUTE remote control, please contact the seller or refer to the retailer's customer service channels. All goods are inspected before shipment. If you are not satisfied with your purchase, you may contact the seller within 24 hours of receipt.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F62S9V1W

More documents and user manuals: **https://manuals.plus/**