Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR YS-604

VEVOR 2200W 2-in-1 Electric Hot Pot and Grill

Model: YS-604

Instruction Manual

1. Product Overview

The VEVOR 2200W 2-in-1 Electric Hot Pot and Grill (Model YS-604) is designed for versatile cooking, combining a hot pot and a grill in one unit. It features independent temperature controls for each cooking zone, a non-stick surface, and a design suitable for 1-6 people.



Image 1.1: The VEVOR 2-in-1 Electric Hot Pot and Grill in use, featuring a hot pot section and a grilling surface with shrimp and chicken wings.

- **High Power Performance:** With 2200W total power, the unit provides rapid and continuous heating for both hot pot and grilling functions.
- **Large Capacity:** The hot pot measures 10.24 x 2.76 inches (260 x 70 mm) and the grill pan is 12.4 x 10.04 inches (315 x 255 mm), with a 2.7 L hot pot capacity, suitable for 1-6 users.
- **Independent Temperature Control:** Dual knobs allow for stepless heat adjustment for each cooking zone, providing precise control without interference.

- **Non-stick Coating:** The cooking surfaces feature a non-stick coating for easy food handling and simplified cleaning, reducing smoke and oil.
- **Convenient Design:** Includes oil leakage outlets and an oil collection box for efficient grease management and easier cleaning.



Image 1.2: Illustration of the 2200W power performance, indicating 1100W for the grill and 1100W for the hot pot, with temperature rise curves.

2. Safety Instructions

Please read and understand all safety instructions before operating the appliance to prevent injury or damage.

- **Electrical Safety:** Ensure the voltage rating of the appliance matches your local power supply. Do not use with a damaged power cord or plug. Always plug into a grounded outlet.
- **Water and Liquids:** Never immerse the main unit, power cords, or electrical components in water or other liquids. Keep electrical connections dry.
- **Hot Surfaces:** The appliance surfaces become very hot during operation. Use oven mitts or heat-resistant gloves when handling. Avoid direct contact with hot surfaces.
- **Children and Pets:** Keep the appliance out of reach of children and pets. Close supervision is necessary when the appliance is used near children.
- **Ventilation:** Use the appliance in a well-ventilated area to prevent smoke accumulation.
- **Stable Surface:** Always place the appliance on a stable, flat, heat-resistant, and dry surface.
- **Unplug When Not in Use:** Always unplug the appliance from the power outlet when not in use, before cleaning, and before adding or removing parts.
- **Do Not Overfill:** Do not overfill the hot pot to prevent boiling over.
- **Proper Use:** Use the appliance only for its intended purpose as described in this manual.

3. Product Components

The VEVOR 2-in-1 Electric Hot Pot and Grill package includes the following items:



Image 3.1: Visual representation of the main unit and its accessories, including the glass lid, power cords, and oil box.

- 1 x Electric Hot Pot with Grill Unit
- 1 x Glass Lid
- 2 x Power Cords
- 1 x Oil Box
- 1 x User Manual (this document)

4. Setup

Follow these steps to set up your VEVOR Electric Hot Pot and Grill:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the main unit on a stable, flat, heat-resistant, and dry surface, ensuring adequate space around the appliance for ventilation.
3. **Insert Oil Box:** Ensure the oil collection box is correctly inserted into its designated slot beneath the grill section.
4. **Connect Power Cords:** Insert the two power cords securely into the corresponding sockets on the appliance. Then, plug the other ends of the power cords into separate, grounded electrical outlets.
5. **Initial Cleaning:** Before first use, wipe the hot pot and grill surfaces with a damp cloth and mild detergent, then dry thoroughly.

5. Operating Instructions

Operating your VEVOR Electric Hot Pot and Grill is straightforward:



Image 5.1: Detail of the dual temperature control knobs, allowing independent adjustment for the hot pot and grill.

1. **Prepare Hot Pot:** Fill the hot pot section with your desired broth or liquid. Do not exceed the maximum fill line to prevent overflow during boiling.
2. **Prepare Grill:** Lightly brush the grill surface with a small amount of cooking oil if desired, especially for foods prone to sticking.
3. **Power On:** Ensure the power cords are securely connected to both the unit and the electrical outlets.
4. **Set Temperature:** Turn the independent temperature control knobs for the hot pot and grill to your desired heat settings. The indicator lights will illuminate when heating.
5. **Preheat:** Allow the unit to preheat for approximately 5-10 minutes until it reaches the set temperature.

6. **Add Ingredients:** Carefully add ingredients to the hot pot for boiling or to the grill for cooking.
7. **Adjust Heat:** Adjust the temperature knobs as needed during cooking to maintain optimal heat for different foods.
8. **After Use:** Once cooking is complete, turn both temperature control knobs to the "OFF" position and unplug the appliance from the electrical outlets. Allow the unit to cool completely before cleaning.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your appliance.



Image 6.1: Features highlighting the non-stick coating, raised texture, oil box, and overall ease of cleaning.

1. **Cool Down:** Always ensure the appliance is unplugged and has cooled down completely before attempting any cleaning.
2. **Main Unit:** Do not immerse the main unit or its electrical components in water. Wipe the exterior with a damp cloth.
3. **Cooking Surfaces:** For the non-stick hot pot and grill surfaces, use a soft sponge or cloth with mild dish soap. Avoid abrasive cleaners, metal scrubbers, or sharp objects that could damage the non-stick coating.
4. **Oil Box:** Remove the oil collection box and empty any accumulated oil. Wash it with warm soapy water, rinse, and dry thoroughly before reinserting.
5. **Glass Lid:** The glass lid can be washed by hand with warm soapy water or placed in a dishwasher.
6. **Drying:** Ensure all parts are completely dry before storing or next use.
7. **Storage:** Store the appliance in a dry, cool place.

7. Troubleshooting

If you encounter issues with your VEVOR Electric Hot Pot and Grill, refer to the following troubleshooting guide:

- **Unit does not turn on:**
  - Check if the power cords are securely plugged into both the unit and the electrical outlets.
  - Verify that the electrical outlets are functioning correctly by testing with another appliance.
  - Ensure the temperature control knobs are turned to an active setting (not "OFF").
- **Food not cooking evenly:**
  - Ensure the unit is placed on a flat, stable surface to allow for even heat distribution.
  - Adjust temperature settings as needed for different types of food.
  - Avoid overcrowding the grill or hot pot sections, which can reduce cooking efficiency.
- **Excessive smoke:**
  - Ensure the oil collection box is properly installed and emptied regularly.
  - Reduce the amount of oil or fat used on the grill surface.
  - Ensure the appliance is clean and free from food residue from previous uses.
- **Hot pot not boiling or grill not heating sufficiently:**
  - Confirm that the respective temperature control knob is set to a high enough setting.
  - Allow sufficient preheating time.
  - Check if the power cords are fully inserted.

If the problem persists after following these steps, please contact VEVOR customer support.

8. Specifications



Image 8.1: Detailed dimensions of the hot pot and grill pan, including overall unit size.

Feature	Specification
Model Number	YS-604
Total Power	2200W (1100W Hot Pot + 1100W Grill)
Voltage	220V (AC)
Hot Pot Capacity	2.7 Liters

Hot Pot Dimensions	10.24 x 2.76 inches (260 x 70 mm)
Grill Pan Dimensions	12.4 x 10.04 inches (315 x 255 mm)
Overall Product Dimensions	26.77"D x 6.46"W x 11.02"H (680 x 283 x 164 mm)
Item Weight	6.61 lbs (3 kg)
Material	Electrical Components + Cast Aluminum, Plastic
Special Features	Lightweight, Non-stick Coating, Independent Temperature Control
UPC	197988509752

9. Warranty and Support

This VEVOR product comes with a limited warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or visit the official VEVOR website.

For technical assistance, troubleshooting beyond this manual, or to inquire about warranty claims, please contact VEVOR customer service. Contact information can typically be found on the VEVOR official website or through the retailer where the product was purchased.

Please have your model number (YS-604) and proof of purchase ready when contacting support.

© 2025 VEVOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F647D3QD

More documents and user manuals: **https://manuals.plus/**