INFURTURE BH127AR

INFURTURE Wearable Bluetooth Speaker BH127AR Instruction Manual

Model: BH127AR

INTRODUCTION

This manual provides detailed instructions for the INFURTURE Wearable Bluetooth Speaker, Model BH127AR. Please read this manual carefully before use to ensure proper operation and to maximize the product's lifespan. Keep this manual for future reference.

PACKAGE CONTENTS

- INFURTURE Wearable Bluetooth Speaker (BH127AR)
- USB-C Charging Cable
- User Manual

PRODUCT FEATURES

- **Wearable Design:** Features a sturdy carabiner clip for secure attachment to clothing, bags, or belts, allowing for hands-free audio.
- **Waterproof & Durable:** Boasts an IPX7 waterproof rating, making it resistant to rain, spills, and accidental submersion (up to 30 minutes at 1 meter depth). It is also dustproof and shock-resistant.
- **Extended Battery Life:** Provides up to 15 hours of continuous audio playback on a single charge.
- **Advanced Bluetooth 5.4:** Ensures a stable wireless connection and faster pairing with devices, offering a range of up to 100 feet.
- **Built-in Microphone:** Equipped with a noise-canceling microphone for clear, hands-free communication during calls.
- **Integrated Lighting:** Includes a 2-level white LED light for visibility in low-light conditions and an RGB light feature for ambiance.
- **Compact & Lightweight:** Weighs approximately 90g (3.17oz) with dimensions of 1.1"D x 1.97"W x 3.15"H, ensuring easy portability.

PRODUCT OVERVIEW

Refer to the image below for a visual guide to the speaker's components and controls.

This image displays the front of the INFURTURE BH127AR speaker, highlighting its compact design, speaker grille, control panel with volume and power buttons, and the integrated LED light at the bottom.

- **Speaker Grille:** Main audio output.
- **Control Panel:** Contains buttons for Power/Bluetooth, Volume Up/Next Track, and Volume Down/Previous Track.
- **LED Light Button:** Activates and cycles through LED light modes.
- **USB-C Charging Port:** Located under a protective cover for charging the device.
- **Carabiner Clip:** For attaching the speaker to various items.

SETUP

Charging the Speaker

Before initial use, fully charge the speaker to ensure optimal performance.

1. Connect the provided USB-C cable to the speaker's charging port. Ensure the port cover is fully open.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. It will turn off or change color once fully charged (approximately 1.5 hours).

This image illustrates the speaker connected to a USB-C charging cable, emphasizing its fast charging capability and extended battery life.

Bluetooth Pairing

Follow these steps to connect your speaker to a Bluetooth-enabled device.

1. Power on the speaker by pressing and holding the Power/Bluetooth button for approximately 3 seconds until you hear an audible prompt and the LED indicator flashes.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "INFURTURE BH127AR" from the list of devices.
4. Once successfully paired, you will hear a confirmation sound, and the LED indicator will remain solid.

This video demonstrates the initial Bluetooth pairing process for the INFURTURE Wearable Bluetooth Speaker BH127AR, showing how to power on the device and connect it to a smartphone.

OPERATING INSTRUCTIONS

Basic Audio Control

- **Power On/Off:** Press and hold the Power/Bluetooth button for 3 seconds.
- **Volume Up:** Short press the '+' button.

- **Volume Down:** Short press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.
- **Play/Pause:** Short press the Power/Bluetooth button.

Call Management

- **Answer/End Call:** Short press the Power/Bluetooth button when a call comes in or during a call.
- **Reject Call:** Press and hold the Power/Bluetooth button for 2 seconds when a call comes in.

Voice Assistant Activation

Double-tap the Power/Bluetooth button to activate your device's voice assistant (e.g., Siri, Google Assistant).

This image illustrates the hands-free functionality of the speaker, including the ability to activate voice assistants like Siri with a double-tap, and manage music and calls while engaged in other activities.

LED Light Operation

- **White LED Light:** Short press the LED Light button to cycle through the two brightness levels of the white LED light.
- **RGB Light:** Long press the LED Light button for 2-3 seconds to switch between the available RGB light modes.

2 Level Led Light LED

Easy to carry when going out at night
can easily light up the dark area

This image demonstrates the speaker's 2-level LED light feature, showing how it can illuminate the path for night activities like running, enhancing safety and visibility.

This image highlights the multi-color RGB flashlight feature of the speaker, which can be used to enhance the music experience or provide ambient lighting.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these may damage the surface or internal components.
- **Water Exposure:** While the speaker is IPX7 waterproof, it is recommended to avoid prolonged submersion. Always ensure the USB-C charging port cover is securely closed before exposing the speaker to water. After exposure to water, dry the speaker thoroughly before charging.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Battery Care:** To preserve the lifespan of the internal battery, charge the speaker at least once every three months if it is not in regular use. Avoid fully discharging the battery frequently.

TROUBLESHOOTING

- **Speaker not powering on:**
  Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable and try again.
- **Unable to pair via Bluetooth:**

- Make sure the speaker is in pairing mode (LED indicator flashing).
- Ensure Bluetooth is enabled on your device.
- Move the speaker closer to your device to reduce interference.
- If previously paired, try forgetting the device from your phone's Bluetooth settings and attempting to pair again.
- Ensure no other devices are currently connected to the speaker.

- **No sound or low volume:**

  - Check the volume levels on both the speaker and your connected device.
  - Ensure the speaker is properly paired and connected.
  - Try playing a different audio source to confirm the issue is not with the media file.

- **Poor sound quality:**

  - Move closer to your connected device to minimize potential wireless interference.
  - Ensure the speaker grille is not obstructed.

TECHNICAL SPECIFICATIONS

Feature	Detail
Model	BH127AR
Brand	INFURTURE
Connectivity Technology	Bluetooth 5.4
Waterproof Rating	IPX7
Playtime	Up to 15 hours
Charging Time	Approximately 1.5 hours (USB-C)
Speaker Maximum Output Power	10 Watts
Item Weight	0.09 Kilograms (3.2 ounces)
Product Dimensions (D x W x H)	1.1" x 1.97" x 3.15"
Material	Metal, Plastic
Special Features	Built-in Microphone, 2-Level LED Light, RGB Flashlight

WARRANTY AND CUSTOMER SUPPORT

Warranty Information

This product comes with a Limited Warranty. For specific terms and conditions, please refer to the warranty card included in your package or visit the official INFURTURE website for detailed information.

Customer Support

If you encounter any issues or have questions not covered in this manual, please contact INFURTURE customer support for assistance.

- **Online Support:** Visit the INFURTURE Store on Amazon.