Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DUMOS SF-5021C-M2

DUMOS Recliner Chair User Manual

Model: SF-5021C-M2

Introduction

Thank you for choosing the DUMOS Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read it thoroughly before use and retain it for future reference.

Safety Instructions

To ensure safe operation and prolong the life of your recliner, please observe the following safety guidelines:

- Always ensure the chair is on a stable, level surface to prevent tipping.
- Do not exceed the maximum weight limit of 275 lbs (125 kg).
- Keep the chair away from heat sources, open flames, and sharp objects to prevent damage to the upholstery and potential injury.
- Keep children and pets away from the reclining mechanism to prevent injury.
- Do not stand on the footrest or armrests.
- Ensure there is adequate space around the chair when reclining to avoid obstructions.

Package Contents

Please check that all components are present before beginning assembly:

- Recliner Backrest
- Recliner Seat Base with Armrests
- Chair Legs (4x)
- Power Adapter for Massage Function
- Massage Remote Control
- Instruction Manual (this document)

Assembly Instructions

The DUMOS Recliner Chair is designed for quick and easy assembly, typically requiring no tools.

1. **Attach the Legs:** Carefully turn the seat base upside down. Align each leg with the pre-drilled holes on the bottom

of the chair and screw them in securely by hand. Ensure all four legs are firmly attached.

2. **Attach the Backrest:** With the seat base upright, slide the backrest into the metal slots on the rear of the seat base. Push down firmly until you hear a click, indicating it is locked into place.
3. **Connect Power (for Massage Function):** Locate the power cable extending from the chair. Connect it to the provided power adapter, then plug the adapter into a standard electrical outlet.



Figure 1: Backrest attachment mechanism. Ensure a secure connection.

Operating Instructions

Reclining Function

The DUMOS Recliner Chair offers adjustable reclining positions from 90° to 160° and an extendable footrest from 0° to 90°.

- **To Recline:** Lean back gently while pushing on the armrests. The backrest will recline, and the footrest will extend simultaneously. Continue to lean back until you reach your desired angle.
- **To Return Upright:** Lean forward and push down on the footrest with your legs. The footrest will retract, and the backrest will return to its upright position.



Figure 2: Reclining positions for various activities.

Massage Function

Your recliner is equipped with 8 massage modes for personalized comfort. The massage function is controlled via the wired remote control located in the side pocket.

1. **Power On/Off:** Press the 'Power' button on the remote to activate or deactivate the massage function.
2. **Select Mode:** Use the 'Mode' button to cycle through the 8 available massage modes.
3. **Adjust Intensity:** Use the 'Intensity' buttons (+/-) to increase or decrease the massage intensity.
4. **Set Timer:** Use the 'Timer' buttons to set the desired duration for your massage session.



Figure 3: Massage remote control and its functions.

Video 1: Demonstration of the DUMOS Recliner Chair's features, including assembly, reclining, and massage functions.

Maintenance

Proper care will help maintain the appearance and functionality of your recliner.

- **Cleaning:** The PU leather upholstery can be wiped clean with a damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Mechanism Care:** Periodically check all bolts and screws to ensure they are tight. Lubricate moving parts of the reclining mechanism if they become stiff or noisy (use a silicone-based lubricant).
- **General Care:** Avoid direct sunlight exposure for prolonged periods to prevent fading. Keep pets from scratching the upholstery.



Figure 4: Cleaning the PU leather upholstery.

Troubleshooting

If you encounter issues with your DUMOS Recliner Chair, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Chair does not recline smoothly or is stuck.	Obstruction in mechanism; loose connections; mechanism needs lubrication.	Check for any objects obstructing the mechanism. Ensure backrest is fully engaged. Apply silicone lubricant to moving parts.
Massage function not working.	Power adapter not connected; remote control issue; power outlet issue.	Ensure power adapter is securely plugged into both the chair and the wall outlet. Check if the outlet is functional. Try a different outlet. Ensure remote control cable is not damaged.
Chair feels unstable or wobbly.	Loose legs; uneven floor.	Tighten all chair legs. Ensure the chair is on a flat, level surface.

Specifications

Detailed specifications for the DUMOS Recliner Chair (Model: SF-5021C-M2):

- **Brand:** DUMOS
- **Model Number:** SF-5021C-M2
- **Color:** Black
- **Material:** Metal frame, Faux Leather upholstery, Foam fill
- **Product Dimensions (Upright):** 30"D x 27"W x 38.6"H (76.2 cm D x 68.6 cm W x 98 cm H)
- **Item Weight:** 53 Pounds (24 kg)
- **Maximum Weight Recommendation:** 275 Pounds (125 kg)
- **Reclining Positions:** 3 (Adjustable from 90° to 160°)
- **Massage Modes:** 8
- **Included Components:** Arm Pad, Massage Remote Control
- **Assembly Required:** Yes (Minimal)
- **Indoor/Outdoor Usage:** Indoor



Figure 5: Product dimensions and weight capacity.

Warranty and Support

For warranty information or technical support, please contact DUMOS customer service. Details can typically be found on the product packaging or the official DUMOS website.
When contacting support, please have your model number (SF-5021C-M2) and purchase date available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6LL7L85

More documents and user manuals: **https://manuals.plus/**