Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VERMESS 5CYMJ-BK

VERMESS 46.5" Dresser with Clothes Rack, Charging Station & LED Lights

Model: 5CYMJ-BK

1. Introduction

Thank you for choosing the VERMESS 46.5" Dresser. This innovative storage solution combines a traditional 5-drawer dresser with a convenient clothes rack, a built-in charging station, and dynamic LED lighting. Designed to maximize your storage space and enhance your room's ambiance, this dresser is perfect for organizing clothing, accessories, and personal items. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.



Image: The VERMESS 46.5" Dresser, showcasing its integrated clothes rack, five fabric drawers, and sleek black design.

2. Safety Information

Always adhere to the following safety guidelines to prevent injury or damage to the product:

- **Anti-Tip Safety:** Secure the dresser to the wall using the provided anti-tip kit to prevent accidental tipping, especially in households with children or pets.
- **Weight Capacity:** Do not exceed the maximum weight capacities for the top surface, drawers, or hanging rod. Refer to the specifications section for details.
- **Electrical Safety:** Ensure the charging station is connected to a properly grounded power outlet. Do not overload the outlets. Keep liquids away from electrical components.
- **Assembly:** Assemble the unit on a soft, clean surface to avoid scratches. Ensure all screws and fasteners are tightened securely before use.
- **Placement:** Place the dresser on a level surface to ensure stability.

3. Setup and Assembly

The VERMESS dresser is designed for straightforward assembly. Each part is numbered, and clear instructions are provided in the packaging. An installation video is also available to guide you through the process.

3.1. Before You Begin

- Verify all parts and hardware are present by comparing them with the included parts list.
- Gather necessary tools (typically a screwdriver, not included).
- Clear a spacious area for assembly.

3.2. Assembly Steps

Follow the step-by-step instructions provided in the separate assembly manual included with your product. Pay close attention to diagrams and ensure all connections are secure.



Image: Dimensional diagram of the dresser, indicating overall size and individual weight capacities for the top, hanging rod, bottom shelf, and drawers.

4. Operating Instructions

4.1. Using the Charging Station

The dresser is equipped with a convenient charging station featuring 3 AC power outlets and 2 USB ports. This allows you to charge various devices directly from your dresser, eliminating the need for extra extension cords.

- Plug the dresser's power cord into a standard wall outlet.
- Connect your mobile phones, tablets, headphones, watches, laptops, or desk lamps to the available AC outlets or USB ports.
- Ensure devices are compatible with the charging station's output.



Image: Detail of the integrated charging station on the dresser's top, showing 3 AC outlets and 2 USB ports in use.

4.2. Controlling the LED Lights

Enhance your room's atmosphere with the built-in RGB LED light strip. The lights offer adjustable colors and brightness, controlled via a remote.

- Use the provided remote control to power the lights on/off.

- Select from 20 different colors to match your mood or decor.
- Choose from 21 dynamic modes for various lighting effects.
- Adjust the speed of dynamic modes and the brightness of the lights using the remote.



Image: The dresser displaying its LED lighting capabilities, with examples of different colors and the remote control for operation.

4.3. Utilizing Storage Space

The dresser offers ample storage with 5 large deep drawers, a clothes hanger, a spacious top surface, and open storage shelves.

- **Drawers:** Use the five fabric drawers for folded clothing such as t-shirts, sweaters, pants, and undergarments.
- **Clothes Rack:** Hang shirts, dresses, jackets, or other garments on the integrated clothes rack.
- **Bottom Shelves:** The open bottom shelves are ideal for shoes, storage boxes, or other accessories.
- **Top Surface:** The sturdy top surface can hold decorative items, books, or frequently used personal belongings.



Image: An infographic highlighting the dresser's versatile storage capabilities, including space for hanging clothes, folded items in drawers, and shoes on the bottom shelf.

5. Maintenance

Regular maintenance will help prolong the life and appearance of your VERMESS dresser.

- **Cleaning:** Wipe the metal frame and wooden top surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Drawers:** For fabric drawers, spot clean with a mild detergent and cold water. Allow to air dry completely. Do not machine wash.
- **Electrical Components:** Keep the charging station and LED lights free from dust. Do not attempt to disassemble or repair electrical parts yourself.
- **Fasteners:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

6. Troubleshooting

If you encounter any issues with your dresser, refer to the following common problems and solutions:

- **LED Lights Not Working:**
  - Ensure the dresser's main power cord is securely plugged into a working outlet.
  - Check the remote control battery.
  - Ensure the LED strip connection is secure.
- **Charging Station Not Powering Devices:**
  - Verify the dresser's main power cord is plugged in.
  - Test the wall outlet with another device.
  - Ensure your device's charging cable is functional.
  - Avoid overloading the charging station with too many high-power devices simultaneously.
- **Drawers Are Sticking or Difficult to Open/Close:**
  - Ensure the dresser is placed on a level surface.
  - Check that the fabric drawers are fully expanded and correctly inserted into their slots.
  - Do not overload the drawers beyond their weight capacity.
- **Dresser Feels Unstable:**
  - Ensure all assembly screws are tightened.
  - Verify the dresser is on a flat, even surface.
  - Utilize the adjustable feet to level the dresser if your floor is uneven.
  - Install the anti-tip kit as instructed.

If problems persist, please contact customer support.

7. Specifications

Feature	Detail
Brand	VERMESS
Model Name	5CYMJ-BK
Product Dimensions	46.5"D x 15.7"W x 46.9"H
Color	Black
Mounting Type	Floor Mount
Room Type	Bedroom
Special Feature	Adjustable Feet, Charging Station, LED Lights, Clothes Rack
Assembly Required	Yes
Item Weight	43.2 pounds
Top Surface Weight Capacity	Up to 110 lbs
Hanging Rod Weight Capacity	Up to 50 lbs

Bottom Shelf Weight Capacity	Up to 40 lbs
Drawer Weight Capacity	Up to 20 lbs per drawer

8. Warranty and Support

8.1. Warranty Information

Specific warranty details for your VERMESS dresser are typically included with the product packaging or can be obtained directly from the manufacturer or seller. Please retain your proof of purchase for warranty claims.

8.2. Customer Support

Our after-sales service team is dedicated to assisting you. If you have any questions, concerns, or require assistance with assembly, operation, or troubleshooting, please do not hesitate to contact us. We aim to reply to all inquiries within 24 hours.
For support, please refer to the contact information provided by your retailer or on the VERMESS official website.

© 2025 VERMESS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6SLBXTV

More documents and user manuals: **https://manuals.plus/**