AHENOD G16

AHENOD G16 MP3 Player User Manual

Model: G16 | Brand: AHENOD

1. Introduction

Welcome to the user manual for your AHENOD G16 MP3 Player. This guide provides detailed instructions on how to set up, operate, and maintain your device. Please read this manual thoroughly to ensure optimal performance and longevity of your player.

The AHENOD G16 is a versatile portable media player featuring a 4.02-inch IPS HD touchscreen, Android 9 OS, Wi-Fi, Bluetooth 4.1, and 144GB of storage. It is designed for music and video playback, app usage, and more.

2. Package Contents

Please verify that all items listed below are included in your package:

- 1 x AHENOD G16 MP3 Player
- 1 x 128GB SD card (pre-installed or separate)
- 1 x User Manual (this document)
- 1 x Type-C USB Cable
- 1 x Earphone
- 1 x Silicone Case
- 1 x Protective Film

3. Device Overview

Familiarize yourself with the physical components of your AHENOD G16 MP3 Player.



Figure 3.1: Front view of the AHENOD G16 MP3 Player, displaying the touchscreen interface with pre-installed applications.

The device features a 4.02-inch IPS HD touchscreen for navigation. On the sides, you will find power buttons, volume controls, and a Type-C USB port for charging and data transfer. A 3.5mm audio jack is also present for wired earphones. The device includes an internal speaker for audio playback without headphones.

4. Setup

4.1 Charging the Device

Before first use, fully charge your MP3 player.

1. Connect the provided Type-C USB cable to the charging port on the player.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The battery indicator on the screen will show charging status. A full charge typically takes a few hours.

4.2 Inserting the SD Card

Your player comes with a 128GB SD card for expanded storage.

1. Locate the SD card slot on the side of the device.
2. Gently insert the 128GB SD card into the slot until it clicks into place. Ensure the card is oriented correctly.
3. The device supports up to 512GB memory cards.



Figure 4.2: Illustration of inserting an SD card into the AHENOD G16 MP3 Player for expandable storage.

4.3 Initial Power On and Wi-Fi Connection

To power on the device for the first time and connect to a wireless network:

1. Press and hold the power button until the screen lights up.
2. Follow the on-screen prompts to select your language and region.
3. To connect to Wi-Fi, navigate to **Settings** > **Network & Internet** > **Wi-Fi**.
4. Select your desired Wi-Fi network from the list and enter the password if prompted.

4.4 Connecting Bluetooth Devices

The G16 player supports Bluetooth 4.1 for connecting to wireless headphones, speakers, or car stereos.

1. Ensure the Bluetooth device (e.g., headphones) is in pairing mode.
2. On your G16 player, go to **Settings** > **Connected devices** > **Bluetooth**.
3. Turn on Bluetooth and tap **Pair new device**.
4. Select your Bluetooth device from the list of available devices to pair.



Figure 4.4: The AHENOD G16 MP3 Player demonstrating its Duplex Bluetooth 4.1 capability by connecting to wireless earbuds.

5. Operating Instructions

5.1 Navigation and Interface

The G16 player operates using a touch-sensitive screen.

- **Tap:** Select an item or open an application.
- **Swipe:** Scroll through lists or switch between screens.
- **Press and Hold:** Access contextual menus or move app icons.

5.2 Music Playback

The player supports various audio formats including MP3, WAV, APE, FLAC, AAC, OGG, and WMA.

1. Open the **Music** application or a streaming app like Spotify, Deezer, or Amazon Music.
2. Browse music by folder, artist, or album.
3. Select a song to begin playback.
4. Playback modes can be selected: sequential play, single song loop, list loop, or random playback.



Figure 5.2: The AHENOD G16 MP3 Player's music interface, highlighting supported audio formats and playback options.

5.3 Video Playback

The device supports 1080P video playback and formats such as AVI, MKV, RMVB, MP4, MPG, MOV, and RM FLY.

1. Open the **Video** application or a streaming video app.
2. Select a video file to play.
3. Adjust volume and playback controls as needed.



Figure 5.3: The AHENOD G16 MP3 Player showcasing its 1080P HD full touch screen for video content.

5.4 App Management (Google Play Store)

The G16 player comes with the Google Play Store pre-installed, allowing you to download and install additional applications.

1. Open the **Play Store** app.
2. Search for desired applications.
3. Tap **Install** to download and install an app.
4. To uninstall an app, press and hold its icon on the home screen, then drag it to the **Uninstall** option.



Figure 5.4: Uninstalling an application on the AHENOD G16 MP3 Player.

5.5 Parental Controls

Parents can manage app usage and browser access using Google's Family Link.

1. Navigate to **Settings**.
2. Look for **Family Link** or **Digital Wellbeing & parental controls**.
3. Follow the on-screen instructions to set up parental controls, including passwords, browser access restrictions, and app approvals.



Figure 5.5: Setting up parental controls via Google Family Link on the AHENOD G16 MP3 Player.

6. Maintenance

6.1 Battery Management

The G16 player is equipped with a 2000mAh Li-ion battery. Proper battery care can extend its lifespan.

- Avoid fully discharging the battery frequently.
- Charge the device using the provided Type-C USB cable and a compatible charger.
- Do not expose the device to extreme temperatures, as this can degrade battery performance.
- A full charge provides approximately 25 hours of continuous music playback or 5 hours of video playback.



Figure 6.1: Internal view highlighting the 2000mAh battery and its performance metrics.

6.2 Cleaning and Storage

- Use a soft, lint-free cloth to clean the screen and body of the device.
- Avoid using harsh chemicals or abrasive materials.
- Store the player in a cool, dry place away from direct sunlight and extreme temperatures.
- When not in use for extended periods, charge the device to about 50% before storing.

7. Troubleshooting

If you encounter issues with your AHENOD G16 MP3 Player, refer to the solutions below.

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; software issue.	Charge the device for at least 30 minutes. If it still doesn't turn on, perform a force restart by holding the power button for 10-15 seconds.
Screen is unresponsive or glitching.	Temporary software glitch; excessive background apps.	Restart the device. Close unnecessary background applications. If the issue persists, consider a factory reset (back up your data first).
Cannot connect to Wi-Fi.	Incorrect password; router issue; device Wi-Fi disabled.	Ensure Wi-Fi is enabled in settings. Verify the Wi-Fi password. Restart your Wi-Fi router. Try connecting to a different network if available.
Bluetooth device not pairing.	Device not in pairing mode; too far from player; interference.	Ensure the Bluetooth accessory is in pairing mode. Move the devices closer. Turn off and on Bluetooth on both devices.
Music/video files not playing.	Unsupported file format; corrupted file.	Verify the file format is supported (MP3, WAV, APE, FLAC, AAC for audio; AVI, MKV, RMVB, MP4, MPG, MOV for video). Try playing a different file.

8. Specifications

Feature	Detail
Model Name	G16
Operating System	Android 9 OS
Processor	8-core MTK chip
RAM	2GB
Internal Storage (ROM)	16GB
Included SD Card	128GB
Max. Expandable Storage	512GB (Micro SD)
Screen Size	4.02 Inches IPS HD Touch Screen
Video Resolution Support	Up to 1080P
Connectivity	Wi-Fi (2.4G & 5G), Bluetooth 4.1 (Duplex)
Battery Capacity	2000mAh Li-ion
Music Playback Time	Up to 25 hours
Video Playback Time	Up to 5 hours
Dimensions	10.3 x 5.8 x 1.1 cm (4.06 x 2.28 x 0.43 inches)

Feature	Detail
Weight	95 grams (3.35 ounces)
Special Features	FM Radio, Pre-installed Google Play Store, Parental Controls

9. Warranty and Support

Your AHENOD G16 MP3 Player is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact AHENOD customer support. For technical assistance, troubleshooting beyond this manual, or warranty claims, please visit the official AHENOD website or contact their customer service department.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Is there a protective case or cover included with the AHENOD G16 MP4 player?

Yes, the AHENOD G16 MP3/MP4 player includes a protective case in the box. According to the "Package Contents" section of the user manual, the following items are included with your purchase:1 x AHENOD G16...

Read full answer