PHILCO P40SAA

Philco P40SAA 40-inch Full HD Android Smart TV User Manual

Model: P40SAA

Introduction

This manual provides instructions for the Philco P40SAA 40-inch Full HD Android Smart TV. It features Full HD resolution with HDR10 technology for enhanced contrast and vibrant colors. The integrated Android TV operating system offers easy access to applications, movies, and series. Audio is supported by Dolby Audio with 20W RMS power. Built-in Chromecast allows content streaming from mobile devices.

Setup

1. Unpacking

- Carefully remove the TV from its packaging.
- Ensure all included components are present: AC power cable, remote control, quick start guide, base screws, and TV base.
- Retain packaging materials for future transport or service.

2. Stand Installation

Attach the TV stand to the bottom of the television using the provided screws. Ensure the stand is securely fastened for stability.



Dimensional diagram of the Philco P40SAA Smart TV, indicating height and width.

3. Connections

- **Power:** Connect the AC power cable to the TV and then to a power outlet.
- **HDMI:** Use HDMI ports for connecting external devices such as gaming consoles, Blu-ray players, or set-top boxes. The TV has 3 HDMI ports.
- **USB:** Two USB 2.0 ports are available for connecting USB storage devices.
- **Antenna/Cable:** Connect your antenna or cable TV signal to the appropriate input.
- **Network:** Connect to your home network via Wi-Fi or an Ethernet cable for internet access and smart TV features.

Operating Instructions

1. Initial Setup

- Upon first power-on, the TV will guide you through the initial setup process.
- Follow the on-screen prompts to select your language, connect to Wi-Fi, and sign in with your Google account to access Android TV features.
- Perform a channel scan to find available TV channels.

2. Remote Control

The included remote control uses infrared technology. Insert two AA batteries (not included) into the remote. Use the remote to navigate menus, adjust volume, change channels, and access smart TV functions.

3. Android TV Interface

The Android TV home screen provides access to installed applications, recommended content, and settings. Navigate using the directional buttons on your remote.



The Philco P40SAA Smart TV displaying the Android TV home screen with various streaming applications.

4. Streaming and Chromecast

- Access popular streaming services like Netflix, Disney+, and Apple TV directly from the Android TV interface.
- Utilize the built-in Chromecast (Google Cast) to stream photos, videos, and music from compatible mobile devices or computers to your TV.

Maintenance

Cleaning the Screen

- Turn off the TV and unplug it from the power outlet.
- Gently wipe the screen with a soft, dry, lint-free cloth.
- For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner (avoid harsh chemicals).
- Do not spray liquid directly onto the screen.

General Care

- Keep the TV in a well-ventilated area to prevent overheating.
- Avoid exposing the TV to direct sunlight, extreme temperatures, or high humidity.
- Do not place heavy objects on top of the TV.

Troubleshooting

No Power

- Ensure the power cable is securely connected to both the TV and the power outlet.
- Check if the power outlet is functioning by plugging in another device.
- Press the power button on the TV or remote control.

No Picture/Sound

- Verify the correct input source is selected (e.g., HDMI 1, TV).
- Check all cable connections (HDMI, antenna).
- Adjust the volume.

Remote Control Not Working

- Replace the batteries (AA size).
- Ensure there are no obstructions between the remote and the TV's IR sensor.

Slow Performance/App Freezing

- Restart the TV by unplugging it for a few minutes and then plugging it back in.
- Clear the cache of problematic applications through the TV's settings.
- Ensure a stable internet connection for streaming apps.

Specifications

Feature	Detail
Brand	PHILCO
Model Name	P40SAA
Screen Size	40 Inches
Display Technology	LED
Resolution	1080p (Full HD)
Refresh Rate	120 Hz (Motion Enhancement: 60Hz Refresh Rate)
Special Features	Android TV, HDR10, 2 x 10 Wrms Audio Power, Full HD Resolution
Included Components	AC power cable, Remote control, Quick Start Guide, Base screws, TV Base
Connectivity Technology	HDMI, USB, Wi-Fi, Bluetooth 5.1
HDMI Ports	3

Feature	Detail
USB Ports	2 (USB 2.0)
Aspect Ratio	16:9
Product Dimensions (D x W x H)	18 x 90 x 56 cm
Item Weight	4.85 Kilograms
Operating System	Android
Storage Capacity	8 GB
Audio Output Mode	Stereo
Speaker Description	2 Stereo Acoustic Boxes of 10W Each
Surround Sound Format	Dolby Audio
Voltage	100-240 VAC 50-60 Hz
Power Consumption	50 watts (Typical: 49.7 Watt)
Energy Efficiency	A
VESA Mounting Standard	200 x 100 mm
Supported Internet Services	Apple TV, Disney Plus, Browser, Netflix

Warranty Information

This Philco P40SAA Smart TV comes with a**12-month limited warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included with your product or visit the official Philco website.

Support

For technical assistance, troubleshooting, or service inquiries, please contact Philco customer support. You can find contact information on the official Philco website or in the quick start guide provided with your TV.
Online Resources: Visit the official Philco website for FAQs, software updates, and additional support materials.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question