XINFUTE RM-034S+, RM-L1599

XINFUTE HUAYU RM-034S+ RM-L1599 Universal TV Remote Control Instruction Manual

Model: RM-034S+, RM-L1599
Brand: XINFUTE

Introduction

This manual provides instructions for the XINFUTE HUAYU RM-034S+ RM-L1599 universal replacement remote control. This remote is designed to operate various LED TVs from brands such as Samsung, Sony, LG, and AOC without requiring complex programming.

Setup

Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.



Figure 1: Rear view of the remote control with the battery cover removed, illustrating the correct placement of two AAA batteries.



Figure 2: Rear view of the remote control with the battery compartment cover securely closed.

Note: Ensure batteries are inserted with correct polarity. Incorrect installation may prevent the remote from functioning.

Operating Instructions

This universal remote control is designed for direct use with most compatible TV models without requiring initial programming. Simply point the remote at your television and press the desired function button.



Figure 3: Front view of the XINFUTE universal remote control, displaying its button layout.

Key Functions

- **Power (●):** Turns the television on or off.
- **Mute ( ):** Mutes or unmutes the television audio.
- **Number Pad (0-9):** Used for direct channel selection or inputting numbers.
- **Volume (+/-):** Adjusts the television's volume level.
- **Channel (CH +/-):** Changes the television channel up or down.
- **Netflix, YouTube, My Apps:** Dedicated buttons for quick access to streaming services and smart TV applications.
- **P.MODE, S.MODE, GUIDE, INFO, AUDIO, DEFINE, 3D, SUB:** Various function buttons for picture mode, sound mode, program guide, information display, audio settings, custom functions, 3D mode, and subtitles.
- **USB, HDMI, ROTATE, Home:** Input selection and smart TV navigation buttons.

For specific functions related to your TV model, refer to your television's original instruction manual.

Maintenance

Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's performance degrades or it stops responding. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Troubleshooting

Problem	Possible Cause	Solution
Remote control does not work.	• Batteries are dead or incorrectly installed. • Obstruction between remote and TV. • Remote is too far from the TV.	• Check battery polarity and replace with new AAA batteries. • Remove any objects blocking the line of sight to the TV's infrared receiver. • Move closer to the television.
Some buttons do not respond.	• Button malfunction. • TV model incompatibility for specific advanced functions.	• Ensure the remote is pointed directly at the TV. • Some advanced functions may not be supported by all TV models.

If troubleshooting steps do not resolve the issue, please refer to the Warranty and Support section.

Specifications

Brand:
XINFUTE

Model Numbers:
RM-034S+, RM-L1599

Product Dimensions:
6 x 3 x 1 inches

Item Weight:
2.82 ounces

Batteries:
2 AAA batteries (not included)

Manufacturer:
XINFUTE

Special Feature:
Ergonomic, No Programming Required

Max Number of Supported Devices:
1

Compatible Devices:

Television (Samsung, Sony, LG, AOC LED TV, etc.)

Connectivity Technology:

Infrared

Warranty Information

This product comes with a one-year warranty from the date of purchase. For warranty claims or service, please retain your proof of purchase.

Support

For further assistance or if you encounter issues not covered in this manual, please contact the seller directly through the platform where the purchase was made. Ensure you have your product model number (RM-034S+, RM-L1599) and purchase details available.

Seller: Xinfute

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question