Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cofiyard VM-YC01

Cofiyard Propane 2-Burner Camping Stove (Model VM-YC01) Instruction Manual

Brand: **Cofiyard** | Model: **VM-YC01**

1. Introduction

Thank you for choosing the Cofiyard Propane 2-Burner Camping Stove. This portable and efficient stove is designed for outdoor cooking, offering a dual-burner setup with a total output of 17,000 BTU. Its foldable design and included carrying bag make it a convenient essential for camping, backpacking, tailgating, and other outdoor adventures. This manual provides essential information for safe and effective use of your camping stove.



Figure 1: Cofiyard Propane 2-Burner Camping Stove in use.

2. Safety Information

- **Outdoor Use Only:** This appliance is designed for outdoor use only. Do not operate indoors or in enclosed spaces.
- **Ventilation:** Ensure adequate ventilation when operating the stove to prevent carbon monoxide buildup.
- **Clearance:** Maintain a safe distance from combustible materials (e.g., tents, dry leaves, clothing).
- **Leak Checks:** Before each use, check all gas connections for leaks using a soapy water solution. Bubbles indicate a leak.
- **Fuel Connection:** Always connect and disconnect propane cylinders outdoors and away from ignition sources.
- **Hot Surfaces:** Stove surfaces become extremely hot during and after use. Allow the stove to cool completely before handling or storing.
- **Burner Discoloration:** It is normal for the stainless steel burners to oxidize and turn black after high-temperature cooking. This does not affect performance.

3. Setup

1. **Unpack:** Remove the stove from its woven carrying bag.
2. **Unfold:** Unfold the hexagonal stove sections until they are fully extended and locked into place.
3. **Connect Regulator:** Attach the provided gas stove connector/pressure regulator to the stove's gas inlet. Ensure it is securely tightened.
4. **Attach Propane Cylinder:** Screw a 16.4 oz (1 lb) propane cylinder onto the regulator. Hand-tighten only. Do not overtighten.
5. **Placement:** Place the stove on a stable, level, non-combustible surface.



Figure 2: Stove unfolded with propane tank connected.

4. Operation

1. **Prepare Cookware:** Place your pots or pans on the stove grates. The stove is designed to comfortably fit two 10-inch frying pans.

2. **Ignite Burner:** Turn the control knob for the desired burner counter-clockwise to the 'HI' position. The stove features a flick-style ignition; a clicking sound indicates ignition. If the burner does not light immediately, turn the knob to 'OFF', wait a few seconds, and try again.
3. **Adjust Flame:** Once lit, adjust the flame intensity by turning the control knob between 'MIN' and 'MAX' as needed for cooking.
4. **Extinguish:** To turn off a burner, turn its control knob clockwise to the 'OFF' position. Ensure the flame is completely extinguished.
5. **After Use:** After cooking, turn off both burners and close the valve on the propane cylinder. Allow the stove to cool completely before disassembling or storing.



Figure 3: Dual burners in operation, accommodating two pans.

5. Maintenance

- **Cleaning:** After each use, ensure the stove is completely cool. The stove rack can be easily removed for convenient cleaning. Wipe down all surfaces with a damp cloth. For stubborn stains, use a mild soap solution.
- **Grate Removal:** The corrosion-resistant grates are removable for thorough cleaning.

- **Storage:** Store the stove in its carrying bag in a cool, dry place away from direct sunlight and heat sources. Ensure the propane cylinder is disconnected before storage.



Figure 4: Removable grates for easy cleaning.

6. Troubleshooting

- **Burner Not Lighting:**
  - Check if the propane cylinder is properly connected and has fuel.
  - Ensure the gas control knob is turned to the 'HI' position during ignition.
  - Verify that the igniter is clicking. If not, check for debris or damage.
- **Low Flame:**
  - Check the propane cylinder for low fuel.
  - Ensure the gas control knob is fully open.
  - Confirm the regulator is functioning correctly and not obstructed.

- **Gas Leak Smell:**
    - Immediately turn off the stove and propane supply.
    - Move away from the area and ventilate.
    - Perform a soapy water leak test on all connections. Do not use the stove if a leak is detected.

7. Specifications

Feature	Specification
Brand	Cofiyard
Model Number	VM-YC01
Fuel Type	Propane
Material	Iron, Stainless Steel
Product Dimensions (Folded)	9.5"L x 9"W x 4.6"H
Maximum Energy Output	17,000 BTU (Total)
Item Weight	4.19 Pounds



Figure 5: Product dimensions and key specifications.

8. Warranty & Support

The Cofiyard Propane 2-Burner Camping Stove comes with a**1-Year Warranty**. For any questions, technical assistance, or warranty claims, please contact Cofiyard Customer Support. Our team is available **24/7** to provide assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6Y86NMW

More documents and user manuals: **https://manuals.plus/**