FAKJANK F417-D

FAKJANK F417-D Drone User Manual

Model: F417-D

1. Introduction

This manual provides essential instructions for the safe operation, setup, and maintenance of your FAKJANK F417-D Drone. Please read this manual thoroughly before operating the drone to ensure proper function and to prevent damage or injury.

Key Features:

- **1080P HD Camera:** Captures high-resolution photos and videos with a 90° electrically adjustable lens for diverse perspectives.
- **Optical Flow Positioning:** Enhances stability and provides precise hovering for clear footage.
- **Brushless Motors:** Offers powerful and efficient flight performance with reduced noise and increased durability.
- **Colorful LED Lighting:** Integrated LEDs provide enhanced visibility and visual appeal during nighttime flights.
- **App Control & WiFi Transmission:** Connects to a smartphone app for real-time FPV viewing and control, transmitting media directly to your device.
- **Modular Battery:** Designed for easy replacement and extended flight times.
- **Beginner-Friendly Functions:** Includes One Key Takeoff/Landing, Altitude Hold, Headless Mode, and Tap Fly for simplified operation.



Image: The FAKJANK F417-D drone, remote control, and a smartphone displaying the FPV feed.

2. Package Contents

Verify that all items listed below are present in your package:

- Drone x 1
- Remote Control x 1
- Battery x 1
- Propeller x 4 (spare)
- Protective Frame x 4
- Screwdriver x 1
- USB Cable x 1
- Carrying Case x 1
- Instruction Manual x 1



Image: All components included in the FAKJANK F417-D drone package.

3. Drone Components Overview

Familiarize yourself with the main parts of the F417-D drone:

- **Propellers:** Four rotating blades for lift and propulsion.
- **Motors:** Brushless motors drive the propellers.
- **Camera Module:** Front-facing 1080P camera with adjustable angle.
- **LED Lights:** Integrated lights for visibility and aesthetic effects.
- **Battery Compartment:** Located on the drone's body for the modular battery.
- **Optical Flow Sensor:** Located on the underside for stable hovering.
- **Foldable Arms:** Allows for compact storage and transport.



Image: The FAKJANK F417-D drone showcasing its colored LED lighting.

4. Setup Guide

4.1. Battery Installation and Charging

1. Insert the modular battery into the drone's battery compartment until it clicks securely.
2. To charge, remove the battery from the drone. Connect the USB charging cable to the battery and a suitable USB power source (e.g., computer, USB wall adapter).
3. The charging indicator light on the battery will show its status (refer to battery instructions for specific light patterns). A full charge typically takes approximately 3 hours.

4.2. Remote Control Setup

1. Install 3 AAA batteries (not included) into the remote control, observing correct polarity.

2. Extend the phone holder on the remote control and securely place your smartphone.

4.3. Propeller Installation (if necessary)

If propellers are not pre-installed or need replacement:

1. Match the 'A' and 'B' markings on the propellers with the corresponding 'A' and 'B' markings on the drone's motor arms.
2. Attach the propeller guards by snapping them onto the drone's motor arms for added protection.



Image: The FAKJANK F417-D drone equipped with propeller guards.

4.4. App Installation and Connection

1. Download the designated FAKJANK drone app from your smartphone's app store (iOS or Android).
2. Power on the drone and the remote control.
3. On your smartphone, go to Wi-Fi settings and connect to the drone's Wi-Fi network (usually named 'FAKJANK-F417-D' or similar).
4. Open the FAKJANK app. The live video feed from the drone's camera should appear, indicating a successful connection.

5. Operating Instructions

5.1. Pre-Flight Checklist

- Ensure the drone battery and remote control batteries are fully charged.
- Check that propellers are securely attached and undamaged.
- Verify that the drone's Wi-Fi is connected to your smartphone.
- Choose an open, clear area free from obstacles, people, and animals.
- Be aware of local drone regulations and weather conditions.

5.2. Basic Flight Controls

1. **Pairing:** Turn on the drone, then the remote. Push the left joystick up then down to pair.
2. **One Key Takeoff/Landing:** Press the dedicated One Key Takeoff/Landing button on the remote or in the app. The

drone will automatically ascend to a stable height or descend and land.

3. **Throttle (Left Joystick):** Push up to ascend, pull down to descend.
4. **Directional Control (Right Joystick):** Push forward to fly forward, pull back to fly backward, push left to fly left, push right to fly right.
5. **Yaw (Left Joystick Left/Right):** Push left to rotate counter-clockwise, push right to rotate clockwise.



Image: Visual representation of beginner-friendly features like One Key Takeoff/Landing, Headless Mode, and Altitude Hold.

5.3. Advanced Flight Modes

- **Altitude Hold:** The drone maintains a stable altitude automatically, allowing you to focus on directional control.
- **Headless Mode:** In this mode, the drone's orientation is relative to the pilot, eliminating the need to adjust for the drone's front direction.
- **Tap Fly:** Use the app to draw a path on your screen, and the drone will follow it automatically.
- **3 Speed Modes:** Adjust the drone's speed (low, medium, high) to suit your skill level and flying environment.

Image: The Tap Fly feature in action, illustrating the drone following a pre-drawn path on a smartphone screen.



Image: An illustration demonstrating the three available speed modes for the FAKJANK F417-D drone.

5.4. Camera Operation

- **Photo/Video Capture:** Use the dedicated buttons on the remote control or the app interface to take photos or start/stop video recording.
- **FPV (First Person View):** The live video feed is displayed on your connected smartphone via the app.
- **Camera Angle Adjustment:** The camera's 90° electric tilt can be adjusted via the remote control or app to capture different angles.
- **Smart Gesture Control:** Perform specific hand gestures in front of the camera to trigger photo or video recording (refer to app instructions for specific gestures).



Image: Detailed view of the FAKJANK F417-D drone's camera, highlighting 1080P HD resolution, 90° electric adjustment, 110° FOV, and LED lighting.




Image: A user demonstrating smart gesture control to activate photo or video capture with the FAKJANK F417-D drone.

6. Maintenance

6.1. Battery Care

- Do not overcharge or over-discharge the battery.
- Store batteries in a cool, dry place away from direct sunlight and heat.
- If not used for an extended period, charge the battery to approximately 50% capacity every three months.

Image: Illustration of the FAKJANK F417-D drone's modular battery, indicating a 17-minute flight time from a 1600mAh, 3.7V Lithium battery.

6.2. Propeller Replacement

If a propeller is damaged, replace it with a new one from the spare parts. Ensure the correct 'A' or 'B' propeller is installed on the corresponding motor arm.

6.3. Cleaning and Storage

- Clean the drone with a soft, dry cloth. Do not use solvents or harsh chemicals.
- Store the drone in its carrying case in a cool, dry environment when not in use.

7. Troubleshooting

Problem	Possible Cause	Solution
Drone does not respond to remote control.	Low battery in drone or remote; Not paired; Interference.	Charge batteries; Re-pair drone and remote; Move to an area with less interference.
Drone drifts during flight.	Not calibrated; Uneven propellers; Wind interference.	Perform gyroscope calibration; Check/replace propellers; Fly in calm conditions.

Problem	Possible Cause	Solution
No FPV video feed on smartphone.	Wi-Fi not connected; App not open; Interference.	Reconnect to drone's Wi-Fi; Open the app; Reduce distance to drone.
Poor camera image quality.	Dirty lens; Low light; Fast movement.	Clean camera lens; Fly in well-lit conditions; Reduce drone speed for photos/videos.
Short flight time.	Battery not fully charged; Old battery; Aggressive flying.	Ensure full charge; Consider replacing old batteries; Fly more conservatively.

8. Specifications

Feature	Detail
Brand	FAKJANK
Model Name	F417-D
Color	Black
Video Capture Resolution	1080p
Effective Still Resolution	2.1 MP
Connectivity Technology	Wi-Fi
Skill Level	Beginner
Item Weight	147 Grams (5.2 ounces)
Video Capture Format	MP4
Battery Cell Composition	Lithium Ion
Operating Temperature	20 Degrees Celsius
Supported Image Format	JPEG
Video Output Resolution	1080 pixels
Product Dimensions	8"L x 6"W x 2.13"H
Special Features	Adjustable, Foldable, Lightweight

9. Safety Guidelines

Adhere to the following safety guidelines to prevent accidents and ensure responsible drone operation:

- Always operate the drone in open areas, away from people, buildings, and obstacles.
- Maintain a safe distance from the drone during flight.
- Do not fly near airports or restricted airspace.
- Avoid flying in strong winds or adverse weather conditions.
- Keep fingers and loose clothing away from rotating propellers.

- Supervise children during drone operation.
- Regularly inspect the drone for any damage before and after each flight.

10. Warranty and Support

For warranty information, technical support, or any inquiries regarding your FAKJANK F417-D drone, please contact our customer service team.
Customer Support Email: fakjank@gmail.com



Image: FAKJANK customer support contact information.

© 2025 FAKJANK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question