Fitvids QD740-L2C-BLK

Fitvids 2 Pack LED Battery Powered Lanterns

Model: QD740-L2C-BLK

Brand: Fitvids

Introduction

Thank you for choosing the Fitvids 2 Pack LED Battery Powered Lanterns. These portable, waterproof, and collapsible lights are designed for various uses, including camping, emergencies, hurricanes, storms, and power outages. This manual provides essential information for the safe and effective use of your lanterns. Please read it thoroughly before operation and retain it for future reference.

Safety Information

- Always use the correct size and type of batteries as specified.
- Ensure batteries are inserted with correct polarity (+ and -).
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries from the lantern if it will not be used for an extended period to prevent leakage.
- Dispose of used batteries properly according to local regulations.
- Do not expose the lantern to extreme temperatures or open flames.
- Keep out of reach of children.
- Do not look directly into the LED light source to avoid eye strain.

Setup

1. Unpacking

Carefully remove the lanterns from their packaging. Inspect both lanterns for any signs of damage. If any damage is found, do not use the product and contact customer support.

2. Battery Installation

1. Locate the battery compartment cover on the bottom of each lantern.

2. Twist the cover counter-clockwise to remove it.
3. Insert three (3) AAA batteries into the compartment, ensuring the correct polarity (+ and -) as indicated inside the compartment. Batteries are not included.
4. Replace the battery compartment cover by twisting it clockwise until securely fastened.



The underside of the Fitvids LED Lantern with the battery compartment cover removed, illustrating where three AAA batteries are to be inserted. Batteries are not included.

Operating Instructions

1. Turning On and Off

The Fitvids LED Lantern features a simple expand-to-turn-on and collapse-to-turn-off mechanism. No separate power switch is required.

- **To Turn On:** Gently pull the top section of the lantern upwards until it is fully extended. The LED lights will illuminate automatically.
- **To Turn Off:** Push the top section of the lantern downwards until it is fully collapsed. The LED lights will turn off.



This image demonstrates the simple operation of the Fitvids LED Lantern. Gently pull the top section upwards to expand the lantern and activate the light. Push it down to collapse and turn off.

2. Using the Folding Handle

Each lantern is equipped with a folding handle for versatile placement.

- The metal handles can be folded upwards to carry the lantern or to hang it from a hook, tent loop, branch, or other suitable support for hands-free lighting.
- When not in use, the handles can be folded down against the lantern for compact storage.



This image shows the Fitvids LED Lantern in both its expanded (10 inches / 25.5 cm tall) and collapsed (7.4 inches / 18.8 cm tall) forms, highlighting its compact design. The base diameter is 3.4 inches (8.8 cm). The folding handle is visible in the expanded state.

Maintenance

Cleaning

To clean your lantern, wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the lantern in water. Ensure the battery compartment is dry before closing.

Storage

When not in use, store the lantern in a cool, dry place. Remove batteries if storing for extended periods to prevent potential leakage and damage to the device.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Lantern does not turn on.	1. Batteries are dead or low. 2. Batteries are inserted incorrectly. 3. Lantern is not fully expanded.	1. Replace with fresh AAA batteries. 2. Check battery polarity and reinsert correctly. 3. Ensure the lantern is fully pulled up to its expanded position.
Light is dim.	Batteries are low.	Replace with fresh AAA batteries.

Specifications

Model Number	QD740-L2C-BLK
Light Source	LED
Brightness	350 Lumens
Power Source	3 x AAA Batteries (per lantern, not included)
Operating Time	Up to 12 hours on full power (with fresh batteries)
Dimensions (Expanded)	3" L x 3" W x 10" H (7.6 cm L x 7.6 cm W x 25.5 cm H)
Dimensions (Collapsed)	3" L x 3" W x 7.4" H (7.6 cm L x 7.6 cm W x 18.8 cm H)
Individual Lantern Weight	Approx. 4 oz (0.25 lbs)
Water Resistance	Waterproof
Material	Alloy Steel
Color	Black
UPC	762232321192

Warranty Information

Your Fitvids LED Battery Powered Lanterns are covered by a 1-year manufacturer's warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual.

Please retain your proof of purchase for warranty claims.

Customer Support

If you have any questions, require assistance, or need to make a warranty claim, please contact Fitvids customer support. For more information, you can visit the official Fitvids store:

Fitvids Official Store