Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AUKABREX Yepbook

AUKABREX 15.6-inch Laptop User Manual

Model: Yepbook

1. Introduction

Thank you for choosing the AUKABREX 15.6-inch Laptop. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new device. Please read this manual thoroughly before using the laptop to ensure optimal performance and longevity.



Figure 1.1: AUKABREX 15.6-inch Laptop Overview

2. Safety Information

To prevent damage to your laptop or injury to yourself and others, observe the following precautions:

- Do not expose the laptop to extreme temperatures, humidity, or direct sunlight.
- Avoid placing heavy objects on the laptop.
- Keep liquids away from the device.
- Use only the provided power adapter and accessories.
- Do not attempt to disassemble or repair the laptop yourself. Refer to qualified service personnel.

3. Package Contents

Verify that all items are present in the package:

- AUKABREX 15.6-inch Laptop
- Power Adapter
- User Manual (this document)
- Webcam (integrated)

4. Product Overview

4.1. Display

The laptop features a 15.6-inch Full HD (1920x1080) IPS display with a 16:9 aspect ratio and ultra-thin 6mm bezels. The screen can be adjusted up to 180 degrees for versatile viewing angles.



Figure 4.1: High-Definition IPS Display

4.2. Keyboard and Touchpad

The laptop is equipped with a backlit QWERTY keyboard for comfortable typing in various lighting conditions. The spacious touchpad includes an integrated fingerprint sensor for secure and convenient login.



Figure 4.2: Backlit Keyboard and Fingerprint Sensor

4.3. Ports and Connectivity

The laptop offers multiple ports for external device connectivity and supports Wi-Fi and Bluetooth for wireless communication.

- **USB 3.0 Ports:** Two ports for high-speed data transfer.
- **HDMI Port:** For connecting to external displays.
- **3.5mm Earphone Jack:** For audio output.
- **DC Interface:** For power input.
- **Wi-Fi:** Dual-band 2.4G+5G for stable internet connection.
- **Bluetooth 4.2:** For connecting wireless peripherals.



Figure 4.3: Multiple Connectivity Ports

4.4. Internal Components

The laptop is powered by an Intel Celeron N5095 processor and features ample memory and storage for daily tasks.

- **Processor:** Intel Celeron N5095 CPU (Quad-core, up to 2.9 GHz).
- **RAM:** 16GB LPDDR4 for efficient multitasking.
- **Storage:** 512GB SSD for fast boot times and data access.
- **Graphics:** Integrated Intel UHD Graphics.
- **Battery:** 5000 mAh lithium polymer battery (3-6 hours autonomy).



Figure 4.4: Intel Celeron N5095 Processor

5. Setup

5.1. Initial Power On

1. Connect the power adapter to the laptop's DC interface and plug it into a power outlet.
2. Open the laptop lid.
3. Press the power button located on the keyboard to turn on the laptop.
4. Follow the on-screen instructions to complete the initial Windows 11 setup, including language selection, network connection, and user account creation.

5.2. Connecting Peripherals

You can connect various external devices to your laptop:

- **USB Devices:** Insert USB drives, mice, or keyboards into the USB 3.0 ports.
- **External Display:** Use an HDMI cable to connect to a monitor or TV via the HDMI port.
- **Headphones/Speakers:** Plug 3.5mm audio devices into the earphone jack.

6. Operating Instructions

6.1. Basic Navigation

- **Touchpad:** Use the touchpad for cursor control. Tap to click, use two fingers to scroll, and pinch to zoom.
- **Keyboard:** Standard QWERTY layout.

6.2. Fingerprint Unlock

To set up and use the fingerprint unlock feature:

1. Go to Windows Settings > Accounts > Sign-in options.
2. Select 'Fingerprint Recognition (Windows Hello)' and follow the instructions to register your fingerprint.
3. Once registered, you can log in by simply placing your finger on the fingerprint sensor on the touchpad.

6.3. Adjusting Keyboard Backlight

Press the **FN + F5** keys simultaneously to adjust the brightness of the keyboard backlight. Repeated presses will cycle through different brightness levels or turn the backlight off.

6.4. Wireless Connectivity

- **Wi-Fi:** Click the Wi-Fi icon in the taskbar, select your desired network, enter the password, and click Connect.
- **Bluetooth:** Go to Windows Settings > Bluetooth & devices, turn on Bluetooth, and pair with your desired device.

6.5. Using the Webcam

The integrated webcam allows for video conferencing and online communication. Open any video conferencing application (e.g., Zoom, Microsoft Teams) or the Camera app in Windows to use the webcam.

7. Maintenance

7.1. Cleaning

- Use a soft, lint-free cloth to clean the screen and exterior surfaces.
- For stubborn marks, dampen the cloth slightly with water or a screen cleaner.
- Avoid using harsh chemicals or abrasive materials.

7.2. Battery Care

- Avoid fully discharging the battery frequently.
- Do not leave the laptop plugged in constantly after it is fully charged.
- Store the laptop in a cool, dry place if not used for extended periods, with the battery charged to about 50%.

7.3. Storage Expansion

The laptop supports storage expansion via an M.2 2280 (SATA) SSD slot. Consult a professional for installation to avoid

damaging the device.

8. Troubleshooting

If you encounter issues with your laptop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Laptop does not power on.	Low battery or power adapter issue.	Ensure the power adapter is securely connected and the outlet is working. Charge the laptop for at least 30 minutes before attempting to power on again.
Screen is blank or flickering.	Display settings, driver issue, or hardware problem.	Try pressing **FN + F5** to adjust brightness. Restart the laptop. If connected to an external display, disconnect it. Update display drivers if possible.
Wi-Fi or Bluetooth not connecting.	Wireless adapter off, incorrect password, or driver issue.	Ensure Wi-Fi/Bluetooth is enabled in Windows settings. Verify network password. Restart the laptop and router. Update wireless drivers.
Laptop is running slow.	Too many applications open, low storage, or malware.	Close unnecessary applications. Check available storage. Run a virus scan. Consider a system restore or reinstallation if issues persist.

If the problem persists after trying these solutions, please contact customer support.

9. Specifications

Feature	Specification
Brand	AUKABREX
Model Name	Yepbook
Screen Size	15.6 Inches
Screen Resolution	1920 x 1080 (Full HD)
Processor	Intel Celeron N5095 (up to 2.9 GHz)
RAM	16 GB LPDDR4
Storage	512 GB SSD (expandable via M.2 2280 SATA slot)
Graphics Card	Integrated Intel UHD Graphics
Operating System	Windows 11
Connectivity	Wi-Fi (2.4G+5G), Bluetooth 4.2

Feature	Specification
Ports	2x USB 3.0, 1x HDMI, 1x 3.5mm Earphone, 1x DC Interface
Battery	5000 mAh (38 Wh)
Dimensions	36 x 23 x 2 cm
Weight	2.19 kg

10. Warranty and Support

This AUKABREX laptop comes with a 2-year warranty and lifetime customer service. If you have any questions or encounter quality issues with this product, please do not hesitate to contact us. Our support team is available to assist you.
For support, please refer to the contact information provided with your purchase or visit the official AUKABREX website.

© 2025 AUKABREX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7LRST1T

More documents and user manuals: **https://manuals.plus/**