Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

deli E91512

Deli Carbon Fiber Texture Gaming Desk E91512 User Manual

Model: E91512

1. Introduction

Thank you for choosing the Deli Carbon Fiber Texture Gaming Desk. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new desk. Please read these instructions carefully before assembly and retain them for future reference.

This desk is designed to enhance your gaming or workstation setup with its durable construction, ergonomic features, and integrated RGB LED lighting. It features a carbon fiber-like textured desktop, a reinforced steel frame, and adjustable feet for stability.



Image 1.1: The Deli Carbon Fiber Texture Gaming Desk in a typical setup.

2. Safety Information

- Always assemble the desk on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.
- Do not overload the desk. The tested load capacity is over 300 kg, but uneven distribution of weight can affect stability.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.
- Avoid placing hot items directly on the desktop without protection.
- Do not stand or sit on the desk.
- Ensure proper cable management to prevent tripping hazards and damage to electronic equipment.

3. Package Contents

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are

missing or damaged, please contact customer support.

- Desktop Panel (Carbon Fiber Texture)
- Left Leg Frame
- Right Leg Frame
- F1 Balance Bar / Crossbeam
- RGB LED Light Strips (pre-installed or separate)
- Control Box for RGB LED Lights
- Power Adapter for RGB LED Lights
- Adjustable Feet (4x)
- Assembly Hardware (screws, bolts, washers, Allen wrench)
- Cup Holder (Included Component)
- Headphone Hook (if applicable, not explicitly listed but common)
- Instruction Manual (this document)

Note: All assembly tools are included in the package.

4. Assembly Instructions

Follow these steps carefully to assemble your gaming desk. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent damage. Identify each component using the package contents list.
2. **Attach Leg Frames:** Secure the left and right leg frames to the underside of the desktop panel using the provided screws and Allen wrench. Ensure the orientation is correct for the F1 balance bar attachment.
3. **Install F1 Balance Bar:** Connect the F1 balance bar (crossbeam) between the two leg frames. This design provides enhanced stability and reduces wobble. Tighten all fasteners securely.



Image 4.1: Illustration of the F1 balance bar design and back triangles for mechanical reinforcement.

4. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of each leg frame. These feet allow for leveling the desk on uneven floors.
5. **Install Accessories:** Attach the cup holder and any other included accessories (e.g., headphone hook) to the designated locations on the desk.
6. **Cable Management:** Utilize the integrated cable management hubs to organize your cables. This helps maintain a neat setup and prevents cable damage.
7. **Final Check:** Once assembled, gently lift and place the desk in its desired location. Ensure all screws are tight and the desk is stable. Adjust the feet as needed to eliminate any wobbling.



Image 4.2: The desk's stabilizing mechanical reinforcements provide an easy load capacity of over 300kg.

5. Operating RGB LED Lights

Your Deli Gaming Desk features integrated RGB LED lighting to enhance your gaming atmosphere. The LED strips are typically pre-installed along the edges of the desktop.

1. **Connect Power:** Locate the power cable for the RGB LED lights, usually extending from the underside of the desktop. Connect it to the provided power adapter, then plug the adapter into a standard wall outlet.
2. **Control Panel:** The desk includes a control box or buttons, often located on the underside or edge of the desktop.
3. **Power On/Off:** Press the designated power button to turn the LED lights on or off.
4. **Change Modes:** Use the mode button to cycle through various lighting effects. These may include:
    - Solid colors (monochrome)
    - Color cycling
    - Gradient switching
    - Monochrome breathing effects

5. **Adjust Brightness/Speed:** Some control panels may offer buttons to adjust the brightness of the lights or the speed of dynamic effects.



Image 5.1: The upgraded full carbon fiber textured desktop with integrated RGB LED lighting.

6. Maintenance and Care

Proper care will ensure the longevity and appearance of your Deli Gaming Desk.

- **Cleaning the Desktop:** The carbon fiber textured desktop is waterproof and scratch-resistant. Wipe the surface with a soft, damp cloth and a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could damage the finish.
- **Cleaning the Frame:** The steel frame has an anti-corrosion finish. Clean with a soft, dry or slightly damp cloth.
- **Dusting:** Regularly dust the desk with a dry microfiber cloth to prevent dust buildup, especially around the LED lights and cable management areas.
- **Liquid Spills:** In case of spills, wipe them immediately to prevent any potential damage, although the desktop is designed to be waterproof.
- **Fastener Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if any looseness is

detected to maintain stability.

7. Troubleshooting

If you encounter any issues with your desk, refer to the following common problems and solutions:

- **Desk is wobbly:**
  - Ensure all assembly screws and bolts, especially those connecting the leg frames and the F1 balance bar, are securely tightened.
  - Adjust the leveling feet at the bottom of the desk legs to compensate for uneven floor surfaces.
- **RGB LED lights are not working:**
  - Check if the power adapter is securely plugged into both the desk's LED cable and a working wall outlet.
  - Ensure the power button on the LED control panel is pressed.
  - Verify that there are no visible damages to the LED strips or wiring.
- **Desktop surface is scratched:**
  - While the desktop is scratch-resistant, it is not scratch-proof. Avoid dragging sharp objects across the surface. Minor scratches may be less visible due to the carbon fiber texture.

8. Specifications

Feature	Detail
Brand	deli
Model Number	E91512
Product Dimensions (D x W x H)	60D x 100W x 75H centimetres
Item Weight	18000 Grams (18 kg)
Material Type	Engineered Wood (Desktop), Metal (Frame)
Finish Type	Black Wood Grain (Desktop), Black with LED Light (Furniture Finish)
Color	Black
Special Feature	RGB LED Lights, Lightweight (relative to strength)
Recommended Uses	Gaming, Computer Work, Study
Required Assembly	Yes (All assembly tools included)
Included Components	Cup Holder
Load Capacity	Over 300 kg (tested)



Image 8.1: Product dimensions of the Deli Carbon Fiber Texture Gaming Desk.

9. Warranty Information

This Deli Carbon Fiber Texture Gaming Desk comes with a**limited warranty**. Please refer to the warranty card included in your package or contact Deli customer support for specific terms and conditions regarding coverage, duration, and claims process.

The warranty typically covers manufacturing defects and material flaws under normal use. It does not cover damage resulting from improper assembly, misuse, accidents, modifications, or normal wear and tear.

10. Customer Support

For any questions, assistance with assembly, troubleshooting, or warranty claims, please contact Deli customer support.

- **Online Support:** Visit the official Deli website or the Deli Store on Amazon for FAQs and support resources.
- **Contact Information:** Refer to the contact details provided on your purchase receipt or the product packaging for direct customer service.

We are committed to providing you with a high-quality product and excellent service.

© 2026 Deli Group Co., Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7LYJ9Q2

More documents and user manuals: **https://manuals.plus/**