BOSWELL GM-AF04-B

BOSWELL GM-AF04-B 7.5QT Glass Air Fryer Instruction Manual

Model: GM-AF04-B | Brand: BOSWELL

Important Safety Instructions

Please read all instructions carefully before using your BOSWELL Glass Air Fryer. Retain this manual for future reference.

- **Electrical Safety:** Ensure the appliance is plugged into a grounded outlet. Do not immerse the main unit, cord, or plug in water or other liquids.
- **Hot Surfaces:** The air fryer's exterior and interior surfaces become very hot during operation. Always use the provided insulated gloves and silicone mat when handling hot components, especially the glass bowl.
- **Transparent Glass Bowl:** The heat-resistant glass bowl allows for real-time monitoring. Exercise caution as the glass bowl can be heavy when full; handle with care to prevent breakage or injury.
- **Ventilation:** Do not block the air inlet or outlet vents. Ensure adequate space (at least 6 inches) around the appliance during use. Note that hot air exhausts from the back of the unit.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Intended Use:** Use the appliance only for its intended household purpose. Do not use outdoors.
- **Damage:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

Product Overview

The BOSWELL 7.5QT Glass Air Fryer utilizes advanced 360° hot air circulation technology to cook food evenly and efficiently. Its transparent design allows for easy monitoring, ensuring perfect results every time.



The BOSWELL Glass Air Fryer, showcasing its transparent design and multiple cooking functions.

Key Features:

- **7.5 Quart Capacity:** Generous size for family meals.
- **Transparent Glass Bowl:** Monitor cooking progress without opening the lid.
- **360° Hot Air Circulation:** Ensures even cooking and crispy textures.
- **1200W Heating Element:** Rapid preheating and efficient cooking.
- **5 One-Touch Presets:** Seafood, French Fries, Steak, Chicken, Bake for simplified cooking.
- **Customizable Controls:** Manual adjustment of time (up to 60 minutes) and temperature (up to 400°F).
- **Easy-Clean & Non-Toxic Materials:** Dishwasher-safe glass inner pot and non-toxic coating.

Components and Accessories

Your BOSWELL Glass Air Fryer comes with the following components and accessories:



The BOSWELL Glass Air Fryer includes a cooking basket, silicone pad, glove, and tweezers.

- **Main Unit:** The primary appliance housing the heating element and control panel.
- **7.5QT Glass Cooking Basket:** The transparent, removable bowl for cooking.
- **Wire Rack:** Sits inside the glass basket to elevate food for optimal air circulation.
- **Non-Slip Silicone Pad:** For resting the hot glass basket safely on surfaces.
- **Insulated Air Fryer Glove:** For safe handling of hot components.
- **Cooking Tweezers:** For safely handling food during and after cooking.
- **Recipe Guide:** Provides cooking suggestions and recipes.

Setup

Follow these steps to set up your air fryer for first use:

1. **Unpack:** Carefully remove all packaging materials and promotional labels from the air fryer and its accessories.
2. **Clean:** Wash the glass cooking basket and wire rack with warm, soapy water or place them in the dishwasher. Wipe the main unit's exterior with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the main unit on a stable, level, heat-resistant surface. Ensure there is at least 6 inches (15 cm) of clear space around the back and sides of the appliance for proper ventilation. Avoid placing it directly against a wall or under cabinets, especially considering the hot air exhaust from the rear.
4. **Insert Basket:** Slide the clean glass cooking basket with the wire rack securely into the main unit.
5. **First Use (Burn-in):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. A slight odor or smoke may be present; this is normal.



Ensure proper placement on a stable, heat-resistant surface with adequate ventilation.

Operating Instructions

Operating your BOSWELL Glass Air Fryer is straightforward with its intuitive touch control panel.



The touch control panel features presets and manual adjustments for time and temperature.

1. **Power On:** Plug the air fryer into a standard 120V electrical outlet. The control panel will illuminate.
2. **Preheating (Manual):** This model does not have a dedicated preheat button. To preheat, set the temperature to your desired level (e.g., 400°F) and set the timer for 3-5 minutes. Press 'Start'.
3. **Load Food:** Once preheated (or if not preheating), carefully pull out the glass cooking basket using the handle. Place your food onto the wire rack inside the basket. Do not overfill to ensure proper air circulation.
4. **Select Cooking Mode:**
    - **Preset Functions:** Choose from the 5 one-touch presets: Seafood, French Fries, Steak, Chicken, or Bake. Each preset has a default time and temperature.
    - **Custom Settings:** For manual control, use the 'TEMP' buttons to adjust the temperature (40°F to 400°F) and the 'TIME' buttons to adjust the cooking duration (1 to 60 minutes).
5. **Start Cooking:** Press the 'Start/Cancel' button to begin the cooking cycle. The display will show the remaining time and current temperature.

6. **Monitor Progress:** The transparent glass bowl allows you to visually monitor your food as it cooks without interrupting the process.
7. **Shake/Flip Food:** For even cooking, especially with items like fries or chicken, you may need to pull out the basket halfway through the cooking time, shake or flip the food, and then reinsert the basket. The air fryer will automatically pause when the basket is removed and resume when reinserted.
8. **Power-Off Protection:** Removing the glass basket during operation will automatically pause the cooking cycle. Reinserting the basket will resume cooking from where it left off.
9. **End of Cycle:** The air fryer will beep when the cooking cycle is complete. Carefully remove the hot glass basket using the insulated glove and place it on the silicone mat.



Monitor your food through the transparent glass bowl for perfect results.

Official Product Video:

Watch this video for a visual guide on the BOSWELL Glass Air Fryer's features and operation, including 360° hot air circulation, transparent design, one-touch presets, and easy cleaning.

Cooking Tips

- **Even Cooking:** For best results, shake the basket or flip food items halfway through the cooking process.
- **Oil Usage:** While an air fryer requires significantly less oil than traditional frying, a light spray of oil can enhance crispness and flavor for some foods.
- **Batch Cooking:** If cooking large quantities, cook in smaller batches to ensure even air circulation and crispness.
- **Temperature & Time Adjustment:** Cooking times and temperatures may vary based on food type, quantity, and desired doneness. Refer to the included recipe guide or adjust settings as needed.
- **Using Accessories:** Always use the provided insulated gloves when handling the hot glass bowl and the silicone mat to protect your countertops.



Achieve perfectly cooked and crispy results with these cooking tips.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Glass Cooking Basket & Wire Rack:** These components are dishwasher-safe for convenient cleaning. For hand-washing, use warm, soapy water and a non-abrasive sponge. For stubborn food residue on the wire rack, soaking in hot soapy water for a period can help.
3. **Main Unit Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water or any other liquid.
4. **Interior (Heating Element):** If necessary, gently wipe the interior with a damp cloth. Avoid touching the heating element directly.
5. **Storage:** Ensure all parts are clean and dry before storing. Store the air fryer in a cool, dry place.

Troubleshooting

If you encounter any issues with your BOSWELL Glass Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on	Not plugged in; Basket not fully inserted	Ensure power cord is securely plugged into a working outlet. Push the glass basket firmly into the main unit until it clicks into place.
Food not cooked evenly	Basket overcrowded; Food not shaken/flipped	Cook in smaller batches. Shake or flip food halfway through cooking.
White smoke coming from appliance	Grease residue; Fatty food	Clean the basket and interior thoroughly. For fatty foods, drain excess oil during cooking.
Food not crispy	Not enough oil; Temperature too low; Cooking time too short	Lightly spray food with oil. Increase temperature or cooking time. Ensure not overcrowded.

If the issue persists after trying these solutions, please contact BOSWELL customer support.

Specifications

Detailed technical specifications for the BOSWELL GM-AF04-B Glass Air Fryer:

Brand	BOSWELL
Model Name	GM-AF04-B
Capacity	7.5 Quarts
Material	Glass
Output Wattage	1200 Watts
Voltage	120 Volts
Max Temperature Setting	400 Degrees Fahrenheit
Control Method	Push Button, Touch
Special Feature	Timer

Product Dimensions (DxWxH)	9.84"D x 9.84"W x 10.2"H
Item Weight	15.07 pounds
Dishwasher Safe (Glass Pot)	Yes
Nonstick Coating	Yes
Air Frying Technology	Cyclonic Air Flow
UPC	765452349120

Warranty and Support

BOSWELL stands behind the quality of its products. This appliance is covered by a manufacturer's warranty against defects in materials and workmanship under normal household use.

For detailed warranty information, product support, or to inquire about replacement parts, please visit the official BOSWELL store or contact customer service:

- **BOSWELL Store:** Visit the BOSWELL Store on Amazon
- **Customer Service:** Refer to your product packaging or the BOSWELL website for the most current contact information.

© 2025 BOSWELL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question