Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AWOW AIBOOK 11

AWOW AIBOOK 11 10.1-inch 2-in-1 Tablet PC User Manual

Model: AIBOOK 11

1. Introduction

Welcome to the user manual for your AWOW AIBOOK 11 2-in-1 Tablet PC. This device is designed to offer the flexibility of a tablet with the functionality of a laptop, featuring a detachable German keyboard. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and longevity.



Image: The AWOW AIBOOK 11 2-in-1 Tablet PC shown with its detachable keyboard, illustrating its versatile design.

2. Package Contents

Please check the package for the following items:

- AWOW AIBOOK 11 Tablet PC
- Detachable German Keyboard
- Power Adapter / Charger
- User Manual (this document)

3. Product Overview

Familiarize yourself with the physical components and ports of your AWOW AIBOOK 11.



Image: A detailed diagram highlighting the various ports and buttons on the AWOW AIBOOK 11, including Micro-HDMI, USB 3.0, USB-C, power button, volume keys, and camera locations.

Key Components:

- **10.1-inch HD Touchscreen:** For interactive input and display.
- **Power Button:** Located on the side for turning the device on/off or sleep/wake.
- **Volume Keys:** Adjust audio output.
- **5MP Front Camera:** For video calls and selfies.
- **8MP Rear Camera:** For capturing photos and videos.
- **Micro-HDMI Port:** Connect to external displays.
- **USB 3.0 Port:** For connecting USB devices.
- **USB-C Port (Full Function):** Supports charging, data transfer, and video output.
- **3.5mm Headphone Jack:** For audio output to headphones or external speakers.
- **Charging Port:** Dedicated port for the power adapter.

4. Initial Setup

4.1 Charging the Device

Before first use, fully charge your AWOW AIBOOK 11. Connect the provided power adapter to the dedicated charging

port on the device and plug it into a power outlet. The charging indicator light will typically show the charging status.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power Button until the screen lights up.
- **To Power Off:** From the Windows desktop, click the Start button, then Power, and select 'Shut down'. Alternatively, press and hold the Power Button for a few seconds and follow the on-screen prompts.
- **Sleep Mode:** Briefly press the Power Button to put the device into sleep mode or wake it up.

4.3 Attaching the Keyboard

The detachable keyboard connects magnetically to the bottom edge of the tablet. Align the magnetic connectors and gently push the tablet onto the keyboard until it clicks into place. The keyboard does not require separate pairing or charging.



Image: The AWOW AIBOOK 11 configured in laptop mode, demonstrating the tablet attached to its detachable keyboard.

5. Operating Modes

The AWOW AIBOOK 11 offers versatile usage modes to suit your needs.



Image: Three distinct usage scenarios for the AWOW AIBOOK 11: 'Creative Mode' with the tablet angled, 'Laptop Mode' with the keyboard attached, and 'Tablet Mode' used handheld.

5.1 Tablet Mode

Detach the keyboard to use the device as a standalone tablet. The 10.1-inch HD touchscreen supports 10-point multitouch for intuitive navigation and interaction with applications.

5.2 Laptop Mode

Attach the keyboard to transform your tablet into a compact laptop. This mode is ideal for typing, productivity tasks, and using applications that benefit from a physical keyboard and touchpad.

5.3 Dual-Screen Setup

Extend your workspace by connecting an external monitor via the Micro-HDMI port or the full-function USB-C port. This allows for enhanced multitasking and a more immersive viewing experience.



Image: The AWOW AIBOOK 11 connected to an external monitor, demonstrating a dual-screen setup for increased productivity or entertainment.

6. Connectivity

6.1 Wi-Fi Connection

The device supports Dual-Band Wi-Fi (2.4GHz + 5GHz, AX101) for stable internet access. To connect:

1. Go to Windows Settings > Network & Internet > Wi-Fi.
2. Turn Wi-Fi on and select your desired network from the list.
3. Enter the network password if prompted and click 'Connect'.

6.2 Bluetooth Devices

Connect wireless peripherals such as headphones, speakers, or mice via Bluetooth 5.0.

1. Go to Windows Settings > Bluetooth & devices.
2. Ensure Bluetooth is turned on.

3. Put your Bluetooth device into pairing mode.
4. Click 'Add device' and select 'Bluetooth' to find and connect to your device.

6.3 USB and HDMI Ports

- **USB 3.0:** For high-speed data transfer with compatible USB devices.
- **USB-C (Full Function):** This versatile port supports charging, data transfer, and video output to external displays.
- **Micro-HDMI:** Connect to TVs or monitors for video and audio output.

7. Maintenance

7.1 Cleaning the Device

- Use a soft, lint-free cloth to clean the screen and exterior.
- For stubborn marks, slightly dampen the cloth with water or a screen-cleaning solution.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays directly on the device.

7.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Store the device in a cool, dry place when not in use for extended periods.
- Use only the original charger provided with the device.

8. Troubleshooting

8.1 Device Not Powering On

- Ensure the device is charged. Connect the power adapter and wait a few minutes before attempting to power on.
- Press and hold the Power Button for 10-15 seconds to perform a hard reset.

8.2 Battery Not Charging

- Verify the power adapter is securely connected to both the device's charging port and a working power outlet.
- Ensure you are using the original power adapter. While the USB-C port supports charging, some USB-C Power Delivery (PD) chargers may not be fully compatible or provide sufficient power. Always prioritize the dedicated charging port with the provided adapter.
- Check for any visible damage to the charging cable or port.

8.3 Keyboard Not Responding

- Ensure the keyboard is securely attached to the tablet via the magnetic connectors.
- Detach and reattach the keyboard to reset the connection.
- Restart the tablet.

8.4 Wi-Fi Connectivity Issues

- Restart your Wi-Fi router and the tablet.
- Ensure you are within range of the Wi-Fi signal.
- Forget the network in Windows Wi-Fi settings and reconnect.

9. Specifications

Detailed technical specifications for the AWOW AIBOOK 11:



Image: A visual summary of the AWOW AIBOOK 11's key specifications, including Intel N95 Processor, 12GB LPDDR5 RAM, 256GB PCIe3.0 SSD, 10.1-inch HD display, Wi-Fi 6, Bluetooth 5.0, and camera details.

Feature	Detail
Brand	AWOW
Model Name	AIBOOK 11
Storage Capacity	256 GB (PCIe3.0 SSD)
Maximum Display Resolution	1280 x 800
Operating System	OS 11 HOME
Installed RAM Size	12 GB (LPDDR5)
Processor	Intel Alder Lake N95 (Quad-Core, 3.4 GHz Turbo Frequency)
Graphics Processor	Intel Integrated Graphics
Special Features	Expandable Storage, Fast Charging, Stereo Speakers
Model Year	2025
Included Components	Keyboard
Connectivity	Bluetooth 5.0, Micro-HDMI, USB 3.0, USB-C (Full Function)
Wireless Technology	Wi-Fi 6 (802.11ac, 802.11ax, 802.11g) Dual-Band (2.4GHz + 5GHz, AX101)
Item Dimensions (L x W x Thickness)	24.5L x 16.4W x 1D cm
Input Support	Touchscreen
Display Type	OLED
Aspect Ratio	16:10
Battery Capacity	3300 mAh (7.6V)

Feature	Detail
Video Capture Resolution	HD 720p
Camera Description	8MP Rear Camera + 5MP Front Camera
GTIN	788438871743

10. Warranty and Support

10.1 Product Warranty

The AWOW AIBOOK 11 comes with a**1-year limited warranty**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use conditions.

10.2 Customer Support

For further assistance, technical support, or warranty inquiries, please contact AWOW customer service. Refer to the official AWOW website or your purchase documentation for contact details.
You can also visit the AWOW Store on Amazon for additional product information and support resources.

© 2025 AWOW. All rights reserved. AWOW AIBOOK 11 User Manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F83PZYQ1

More documents and user manuals: **https://manuals.plus/**