Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE 06-520W37-G000X

XINFUTE 06-520W37-G000X Remote Control User Manual

Instruction Manual for TCL Smart LCD LED HDTV TV Remote Control

1. Introduction

This manual provides instructions for the XINFUTE 06-520W37-G000X Remote Control, designed for use with TCL Smart LCD LED HDTV televisions. This remote control offers a direct replacement or secondary control option without requiring complex setup procedures.

Product Overview:

- **Model:** 06-520W37-G000X
- **Brand:** XINFUTE
- **Compatibility:** Specifically designed for TCL Smart LCD LED HDTV TV models.
- **Material:** Durable ABS Material.



Image 1.1: Front view of the XINFUTE 06-520W37-G000X remote control, showing all buttons and their labels.

2. Setup

The XINFUTE 06-520W37-G000X Remote Control is designed for immediate use with compatible TCL televisions. No programming or pairing is required.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Note: Batteries are not included with the remote control and must be purchased separately.



Image 2.1: Back view of the remote control, highlighting the battery compartment.

3. Operating Instructions

Point the remote control directly at your TCL television's infrared receiver. Ensure there are no obstructions between the remote and the TV.

3.1 Button Functions

Button	Function
Power ( )	Turns the television on or off.
Mute ( )	Mutes or unmutes the television audio.

Button	Function
Number Buttons (0-9)	Direct channel selection.
DISPLAY	Displays current channel information or on-screen display.
SOURCE	Cycles through available input sources (HDMI, AV, etc.).
MENU	Accesses the television's main menu.
RETURN	Returns to the previous menu or screen.
Navigation Arrows (Up, Down, Left, Right)	Navigates through menus and options.
OK	Confirms selections in menus.
OPTION	Accesses context-sensitive options or sub-menus.
EXIT	Exits current menu or application.
VOL +/-	Adjusts the volume level.
CH +/-	Changes the television channel.
TV	Switches to TV mode.
USB	Accesses content from a connected USB device.
ZOOM	Adjusts screen zoom level.
P.EFFECT	Picture effect settings.
S.EFFECT	Sound effect settings.
SLEEP	Sets the sleep timer for the television.
F1, F2, F3, F4 (Colored Buttons)	Function buttons, typically used for specific features or teletext functions depending on the TV model.



Image 3.1: Angled view of the remote control, providing a clearer perspective of the button layout.

4. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries promptly when the remote's responsiveness decreases. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the remote control to water or other liquids.
- **Dropping:** Avoid dropping the remote control, as this can damage internal components.

5. Troubleshooting

If you experience issues with your XINFUTE remote control, refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm the remote is pointed directly at the TV.
- **Limited Range:**
  - Ensure batteries are fresh.
  - Remove any objects that might be blocking the signal path.
  - The effective range is typically within 20 feet (6 meters) of the TV.
- **Specific Buttons Not Working:**
  - This could indicate a faulty button or internal damage. Try replacing batteries first.
  - Ensure your TV model fully supports all functions of this replacement remote.

If problems persist after attempting these steps, please refer to the Warranty and Support section for further assistance.

6. Specifications

Feature	Detail
Model Number	06-520W37-G000X
Brand	XINFUTE
Compatible Devices	TCL Smart LCD LED HDTV Televisions
Power Source	2 x AAA Batteries (not included)
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Material	ABS Material
Special Feature	Ergonomic design
Max Number of Supported Devices	1

7. Warranty and Support

XINFUTE provides a one-year warranty on all purchases of this remote control. This warranty covers manufacturing defects and ensures your satisfaction with the product.
If you encounter any issues or are not satisfied with your purchase, please contact the seller within 24 hours of receipt. Our customer support team is available to assist you with troubleshooting or warranty claims.
Contact Information:

- For support, please refer to the seller's contact details on your purchase platform (e.g., Amazon seller "Xinfute").
- Please have your order number and product model (06-520W37-G000X) ready when contacting support.

All products are inspected before shipment to ensure quality. Your satisfaction is our priority.

© 2025 XINFUTE. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F8BGGGTF

More documents and user manuals: **https://manuals.plus/**