Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RM-L1535 PLUS

XINFUTE RM-L1535 Plus Universal TV Remote Control User Manual

Introduction

This manual provides instructions for the XINFUTE RM-L1535 Plus Universal TV Remote Control. This remote is designed as a direct replacement for various Haier TV models, including HTR-A10, HTR-U27E, and HTR-U29A. It offers full functionality without complex programming, working as well as the original remote control units.

Setup

Battery Installation

The RM-L1535 Plus remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Ensure batteries are inserted with correct polarity to prevent damage to the remote control.



Figure 1: Battery compartment with AAA batteries installed. This image illustrates the correct orientation for battery insertion.

Operating Instructions

The XINFUTE RM-L1535 Plus remote control provides intuitive access to your TV's functions. Below is an overview of the main buttons and their functions:



Figure 2: Front view of the remote control. This image displays the layout of all functional buttons.

- **Power (Red Button):** Turns the TV on or off.
- **Source:** Selects input sources (e.g., HDMI 1, HDMI 2, AV).
- **Netflix, YouTube, Prime Video:** Direct access buttons for these streaming services.
- **Number Buttons (0-9):** For direct channel selection or inputting numbers.
- **CH LIST/⇧⇨:** Displays the channel list or navigates through pages.
- **MENU:** Accesses the TV's main menu.
- **INFO/⇧⇨:** Displays program information.
- **FREEZE:** Pauses the current screen.
- **GUIDE:** Opens the electronic program guide.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **BACK:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or application.

- **VOL +/-:** Adjusts the volume level.
- **Mute:** Mutes or unmutes the TV sound.
- **CH ⇧/⇨:** Changes channels up or down.
- **P.MODE:** Cycles through picture modes.
- **S.MODE:** Cycles through sound modes.
- **TOOL:** Accesses quick settings or tools menu.
- **FAV:** Accesses favorite channels.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next):**Controls media playback.
- **APP:** Opens the applications menu.
- **3D:** Activates or deactivates 3D mode (if supported by TV).
- **CC (Closed Caption):** Toggles closed captions on or off.
- **SUBTITLE:** Selects subtitle options.
- **AUDIO:** Selects audio tracks or modes.

Maintenance

Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Troubleshooting

If you experience issues with your remote control, consider the following common solutions:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Point the remote directly at the TV.
- **Buttons are unresponsive:**
  - Clean the remote control, especially around the buttons, to remove any dirt or debris that might be causing sticking.
  - If only specific buttons are unresponsive, the remote may be damaged and require replacement.
- **Remote range is reduced:**

- This often indicates low battery power. Replace the batteries.
- Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the IR signal.

If these steps do not resolve the issue, please refer to the Warranty & Support section for further assistance.

Specifications

Feature	Specification
Model Number	RM-L1535 PLUS
Compatible Devices	Television (Haier HTR-A10, HTR-U27E, HTR-U29A, etc.)
Batteries Required	2 x AAA batteries (not included)
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Material	ABS Material
Special Feature	Ergonomic design

Warranty & Support

Warranty Information

The XINFUTE RM-L1535 Plus Universal TV Remote Control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

Customer Support

All goods are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact us within 24 hours of receiving your product. For warranty claims or technical assistance, please reach out to XINFUTE customer service through your purchase platform or the provided contact information at the time of purchase.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F8BLH4FM

More documents and user manuals: **https://manuals.plus/**